AXIS110J

ILS Localiser Simulator

User's Manual

Release 55

20 SEP 2024

© NANCO Software

Nordic Air Navigation Consulting

Software License Notice

This manual and software are copyrighted by Nanco Software with all rights reserved. This manual or software may not be copied in whole or part without written consent of Nanco Software, except in the normal use of the software or to make a backup copy of the software.

Warranty

Nanco Software warrants the files and documentation to be free of defects in workmanship for a period of 60 days from the date of purchase. In the event of a defect in material or workmanship during the warranty period, Nanco Software will replace the defective files or documentation. The remedy for this breach of warranty is limited to replacement only and shall not cover any other damages.

Liability

Nanco software can take NO responsibility for any damage or losses that can be traced back to the use of AXIS ILS SIMULATOR SOFTWARE. To get the optimum result from this software, the user should have a good knowledge of ILS theory and have proper experience in practical work with ILS equipment to use the computed results with caution.

In some cases where the simulated results from predicting signal quality due to scattering objects are in the same magnitude as the allowed tolerances, additional practical tests or advice from a second source of consultants should be considered.

Format

This file is formatted for printing double sided in A4, and then cut in half from A4 to A5 size to make a handier physical format.

Table of Content

1. Introduction
2. Usage areas
3. History of AXIS
4. Manual
4.1 Purpose and Scope
4.2 Organization
4.3 How to use this manual
4.4 Language
4.5 Conventions
5. Getting Started
5.1 System Requirements
5.2 User Code
5.3 Program diskette
5.4 New Features
5.5 Installing AXIS110
5.5.1 Making Backups
5.5.2 Installation
5.6 Starting the AXIS110 first time
5.7 Running the AXIS110
5.8 Structure of the AXIS110
5.9 Main steps
6. Updates
6.1 Earlier releases
6.2 Access code
7. System Configuring
7.1 Display Screen
7.2 Printer Drivers
7.3 The Default Setup
7.4 Startup Arguments

GEN General

•	•	•	•	•	•				•	•	•		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		• •		•	•	•••		1
																																													2
																																			_	_	_	_							3
																																		•	•										Δ
•	•	•	•	•															•	•	•			•	•	•	•	•	•	•	•	•	•	•	•	•	•		• •		1	•	• •		т Л
•	•	•	•	•					•	•	•		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •	• •	•	•	• •		4
•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •	• •	•	•	• •		4
•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •	• •	•	•	• •		5
•	•	•	•	•	•				•	•	•		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •	• •	•	•	•••		5
•	•	•	•		•									•		•	•	•	•	•	•	•	•			•	•	•	•	•	•	•	•	•	•	•	•				•	•	•••		5
•																																			•										7
																																													7
																																		•	•										7
•	•	•	•	•															•	•	•		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•					•	• •		' 7
•	•	•	•	•					•	•	•		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		• •	•	1	• •	•	7
•	•	•	•	•	•	•			•	•	•		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		• •	• •	•	•	• •		1
•	•	•	•	•	•	•			•	•	•		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •	• •	•	•	• •		8
•	•	•	•	•	•				•	•	•		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •	• •	•	•	• •		8
•	•	•	•	•	•				•	•	•		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		• •	• •	•	•	•••		8
•		•	•											•		•	•	•	•	•		•				•	•	•	•	•	•	•	•	•	•	•	•						•••		9
																																			•										9
																																											1	1	0
																																			-								1	1	n
•		•	•	•															•	•	•		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				•	•		1	2
•	•	•	•	•										1	•	1	1	1	•	•	•	1		•	•	•	•	•	•	•	•	•	•	•	•	•	•		• •	• •	•	•	1	1. 1.4	2
•	•	•	•	•	•	•			•	•	•		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •	• •	•	•			2
•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •	• •	•	•	1		2
•	•	•	•	•	•		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •	• •	•	•	1		3
•	•	•	•	•	•				•	•	•		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •		•	•	1	1:	3
•		•	•		•									•		•	•	•	•	•	•	•	•				•				•	•	•	•	•	•	•						1	1;	3
																																											1	1;	3
																																											1	1	4
-	-	-	ĩ		1									1	1	1	1	1	-	-	2	1	1		1		-	1	1	1	-	-	-		1			1			-	-	1		-

1.Introduction

The AXIS110J is an efficient tool for a practical ILS localiser simulation.

The simulation is based on a three-dimensional mathematical model of a localiser antenna system, reflection plane and up to 16 scattering objects.

The signal propagation model uses physical optics for treating reflection objects, which are rectangular sheets reflecting, diffracting, and shadowing the illuminated field. Also, horizontal wire stretches can be modeled.

Simulation experience on site models will increase confidence in predicting the performance of planned localiser systems.

A number of antenna systems from the most important manufacturers are included and can be tested and compared on particular airport models.

2. Usage areas

The AXIS110 usage is mainly in these six areas:

I Setting-up guidance

The Control Panel shows all physical and electrical settings together with readings from sample probes in the Antenna Distribution Unit (ADU) to guide in correct ground setup & phasing in order to minimize flight inspection time at the commissioning of the installation.

II Prediction of signal quality

The influence on the signal quality from the planned buildings or constructions on the airport area can be predicted by modelling the constructions.

III Finding optimum antenna system

Simulation of specific installations in a given airport model to compare the theoretical signal quality with the achieved Flight Inspection results. By adjusting the model so the simulations resemble the actual results, one gets control and understanding of the model performance and behavior. When a model is established, the simulator can find the optimum antenna system or adjustment settings to obtain the best possible signal quality.

IV Determine sensitive areas

Establish sensitive areas for a simulated aircraft tailfin, vehicle or construction crane with a given size and orientation. The object will be moved around and optionally rotated to the worst-case orientation to find the border of the sensitive area where this object will produce a specified bend amplitude at a selected receiver location or flight path. The objective is to obtain qualified restrictions for the movement of various aircraft and vehicle types as well as erecting buildings on the airport.

V Simulating the drifting of system parameters

Stability testing by introducing changes in both course and clearance antenna feeds and their mechanical positions to learn what impact this will have on both nearfield and far field signals. This is important in order to specify maintenance limits for the system in order to set the proper alarm limits in the monitors as well as finding the signal response at the ground measurement points on specific installations.

VI Training

Learn how the ILS Localiser system really works under all possible and impossible situations. A nearly unlimited "theory book" that adds neatly into any ILS theory course to supply the instructor with an animation and demonstration tool.

3. History

This Software has been under development for many years, and the code is optimized to give practical results based on extensive experience with field and Flight Inspection measurements.

The file !A110.NEW contains the historical development information.

Use the N-hot key in the Control Panel to read the file on screen. Any user that did suggest changes that have been carried out are named in brackets after the change description.

4. Manual

4.1 Purpose and Scope

This manual provides instructions on using AXIS110J to make a localiser simulation. You will find it useful regardless of your level of computer expertise.

This user's guide assumes you are familiar with the ILS theory and the concepts that pertain to the ILS-localiser.

At the end of this manual in the Appendix 3 there are briefly described the common definitions and abbreviations used in AXIS110J.

4.2 Organization

This manual is divided into sections. Every section describes completely one step (module) of the program. Three letters code are added into the page numbering for helping a search.

List of Sections

GEN -	General introduction (this section) CPN - Control Panel This section introduces how to enter all electrical and mechanical parameters of the current LOC-system.
SET -	Setup
	A subunit of the Control Panel for changing the default settings.
UTL -	Utilities
	A subunit of the Control Panel reserved for ILS-tools.
SCA -	Scattering object editor
	A module for entering and modifying up to 16 scattering objects.
PLY -	Playback mode
	A module for displaying the saved screen as a slide show.
ORB -	Orbit mode
	A module for simulating an orbit flight (cross over).
APP -	Approach mode
	A module for simulating an approach flight.
FIX -	Fixed Position mode
	This module is used to simulate the errors in one of the feed
	parameters while measuring CDI in two fixed points.
BND -	Bend Analysis mode
	A module for finding the source of reflections that produce bends on the LOC signal.
SNS -	Sensitive Area mode
	A module for defining the sensitive area of the airport where a given moving object will cause bends on the LOC signals.

Appendices

A1 - Localiser Model

The background information of the simulation model to be used in the AXIS110J.

A2 - Files and Directories Description of the directories structure and the content of the data files to be used in the AXIS110J.

A3 - Definitions and Abbreviations A list with a brief description of the commonly used definitions and abbreviations.

4.3 How to use this manual

The AXIS110 includes a lot of features divided into several modules.

Due to the organization of this manual, it is not necessary to read throughout the manual so you may ignore the sections you are not interested in.

In any way the usage of the AXIS110J is based on the site and LOC-system parameters that is necessary to enter before making any simulation.

These parameters are entered in the Control Panel (CPN) so it is most important to have a good understand of all parameters and functions available in the Control Panel.

If you are fairly new with the AXIS110J we recommend reading through the Control Panel section (CPN) before going to the run modes.

4.4 Language

All terms and abbreviations of this manual are following the English language. If any other language is used the terms will be changed according to the selected language.

So, if you like to follow the instructions of this manual while you are running the AXIS110, please select the English language by <3> Setup in the Control Panel.

4.5 Conventions

This document adheres to the following conventions:									
Bold	Courier	A text is di	splayed on the screen,						
		examples:							
		SBO	Ampl						
		FWD	Dist.(m)						
<nn></nn>		Angle brac examples: <1>,	ekets indicates the special keys on the keyboards; <enter>,<pgup></pgup></enter>						

Note: <CR> key is the same as <Return> or <Enter> key. CR is a short for Carriage Return used at typewriters.

Italics Italics are used in general to emphasize sections of text. In particular the notes and the warnings are printed in italics.

5. Getting Started

5.1 System Requirements

AXIS110 requires a computer system with Windows 7 to 12, 8MB internal memory.

5.2 User Code

AXIS 110 is delivered with different access levels to run the different MODES in the Menu. Each mode has its Access Code, which is included in the User Code that is entered the first time.

5.3 Downloading the software

The software is distibuted by downloads from our web site.

5.4 New Features

If you have used an earlier version of AXIS 110, you will find new features.

The !A110.NEW file has historical development information.

Any user who suggested changes that have been implemented, are named in brackets after the change description.

All files starting with "!" in the filename are information regarding this AXIS software family.

5.5 Installing AXIS110J

5.5.1 Making Backups

Make backup copies of the AXIS110J files to guard against loss.

5.5.2 Installation

The AXIS software family is written for JAVA and need JAVA to be installed on the PC.

We recommend downloading JAVA from this site: https://www.java.com/en/

When this is done, you are ready for the following steps:

Create a directory named "AXIS" directory on your computer as "C:> AXIS", or anywhere else you prefer. The software is contained in the downloaded ZIP-file.

Open the ZIP file and extract it to the created AXIS directory.

1. Navigate to the "AXIS" directory and start AXIS 110 by clicking on "axis110J.iar"

2. Enter the nine-digit user code for AXIS110J.

3. The Control Panel is opened. Press "Enter" and check that the menu contains these items:

- Orbit Cross over
- Approach
- Fixed Position
- Bend Analyzing
- Sensitive Area

If not, you have not entered the correct user code. Go to (3) Setup, next screen (5) Delete user code.

4. Create a shortcut for AXIS110J

a. Right-click on the PC main screen, and select NEW and "Shortcut"

b. Navigate to your AXIS-directory and select the file axis110J.jar, click NEXT and Complete.

5. Connect the icon to the shortcut

a. Right-click on the Java icon on the PC main screen and select Properties

b. Select change icon. Above all the thumbnails, select "Browse"

c. Select the A110-64 icon, and press "OK".

5.6 Starting the AXIS110J first time

First time you run the software, the user code must be entered. This code is different for each user and the registered access level, and is found in the attached registration letter that comes with the software.

You will only be asked for this code first time you run it on your machine.

5.7 Running the AXIS110J

The software is started with a click on the icon A110J.

With exception of first time running, the AXIS110 comes up after opening screen to its Control Panel, showing the standard default setup. This setup can be changed by running the configuration module through the <3> key on yhe Control Panel.

The Control Panel displays a number of parameters, that can be changed by value stepping keys, when the desired parameter is activated (highlighted) by the arrow keys.

Value stepping keys are :

Increment	Decrement	Factor
<insert></insert>	<delete></delete>	0.1
<pgup></pgup>	<pgdn></pgdn>	1
<ctrl-pgup></ctrl-pgup>	<ctrl-pgdn></ctrl-pgdn>	10

A brief help about the operating keys is avalable by <1> and the (H)elp keys. When all data are set to the desired values, press the <enter> key to proceed to the MENU.

MENU displays a list of modes you can run with the setup entered at the Control Panel.

5.8 Structure of the AXIS110

The AXIS110 consists of different modules. The number of available modules are depending on your access level coded into the user number.

When the software is started it begins with the control panel (CPN) showing the default settings. The control panel is used for setting all system and site data. When this is done you can proceed to the next step (module) by the <Enter> key or go backwards with the <Esc> key.



Fig. GEN501 The Main Modules of the AXIS110J

5.9 Main steps

The usage must follow these main steps.

- 1. Select if necessary the antenna array to be used in your simulation by the <9> key.
- 2. Set all the DATA on the upper part of the Control Panel by using the arrow keys and value stepping keys.
- 3. Enter reflection objects if desired using the <8>.
- 4. Enter antenna element errors if desired on the lower part of the Control Panel.
- 5. Press <enter> to proceed to the Main Menu.
- Select one of the Menu Items by the <Up/Dn> arrow keys and <enters. The screen will show the default values of the selected analysing mode.
- 7. If any data value should be changed, press R-key to re-enter and continue to answer all questions in two ways:

-Press <enter> if the shown value (default value) is accepted.

-Enter value from keyboard if another value is desired, and press <enter>.

- 8. If a wrong entry was made, or if the wrong menu item was selected, just press the <Esc> to start over again.
- 9. Set Toggles by the first letter of the toggle to get the desired computing parameters and the display settings.
- 10. Press <enter> to perform the computation.
- 11. To break a graphic computation or return from the module you are in use the <Esc>.
- 12. After the graph has been drawn, press the keys shown at the bottom of the screen for special functions.

Editorial NOTE about this User Manual

The <F1> through <F10> keys were one-stroke keys (hot key) in earlier versions, but on modern PCs the keys they became two-stoke keys, ie. not so easy to make rapid selections as before.

The <F1> through <F9> keys were therefore replaced by <1> through <9> keys, still one-stroke. The >F10> was replaced by the <Esc> key.

There might be several <F> keys in this manual figures, but bear in mind that you just omit the F, and use the numeric corrresponding key instead.

6.Updates

6.1 New releases

The AXIS110 comes in updated releases Rnn, where nn is the release number. When new versions of the software are issued, the new files should be updated.

Contact Nanco for more information.

6.2 Access code

The AXIS110 is delivered with different access levels to run the different items (MODES) in the Menu . Each mode has its Access Code, which is included in the User Code that is entered the first time.

If higher Access Code has been given after the Software has been taken into use, delete the present Code by using the <3> key in the Control Panel, press <enter> and select the (5) option from the SubMenu.

Restart the software and enter the new User Code.

The User Code/Access Level is written to the AL.001 file.

7. System Configuring

7.1 Display Screen

The graphic screen will be adjusted to the computer in use.

7.2 Printer Drivers

These are no longer used.

7.3 The Default Setup

When starting the software, the default setup configuration will come up.

This can be changed and saved as a new setup by using the <3> key of the Control Panel.

The setup configuration includes :

- antenna array
- site data (frequency and antenna front terrain data)
- receiver response (Low Pass Filter) and
- color palette

Detailed description is given in the SET-section.

AXIS110J User's Manual

Blank page

Table of Content

1. Description
2.Screen lavout
2.1 Info Fields
2.2 Data Fields
3. Data Entry
3.1 System Entry
3.1.1 Calculating Dimension
3.1.2 Antenna Array
3.2 Site Data
3.2.1 Operating Frequency
3.2.2 Course Sector
3.2.3 Forward Slope
3.2.4 Sideways Slope
3.2.5 Threshold Distance
3.2.6 Reflection Plane
3.3 Course Transmitter Data
3.3.1 Course SBO Amplitude
3.3.2 Course SBO Phase
3.3.3 ADU Attenuator Throughput.
3.3.4 Course Antenna Element Ty
3.3.5 Course Antenna Array Heigh
3.4. Clearance Transmitter Data
3.4.1 Clearance-SBO Amplitude
3.4.2 Clearance-SBO Phase
3.4.3 Clearance-CSB Amplitude
3.4.4 Clearance-Antenna Element
3.4.5 Clearance-Antenna Array He
3.5 Antenna Element Data
3.5.1 Antenna Element Number
3.5.2 Distance to Centreline
3.5.3 Forward Shift
3.5.4 Height
3.5.5 Azimuth Turn
3.5.6 Amplitude Error
3.5.7 Phase Error
3.6 Course Signals in the selected el
3.6.1 Course-SBO Amplitude
3.6.2 Course-SBO Phase
3.6.3 Course-CSB Amplitude

AXIS 110 ©NANCO Software

CPN Control Panel

	1
	2
	2
	4
	6
	6
	6
	6
	7
	7
	7
	8
	8
	9
	9
	10
	10
	.10
ut	10
Туре	10
ight	11
- 1	.11
9	11
	11
	11
ent Type	11
Height	11
-	.12
	12
	12
	13
	13
	13
	.14
	14
element	14
	14
	14
	14
	14

3.6.4 Course-CSB Phase	15
3.7 Clearance Signals in the selected element	15
3.7.1 Clearance-SBO Amplitude	15
3.7.2 Clearance-SBO Phase	15
3.7.3 Clearance-CSB Amplitude	15
3.7.4 Clearance-CSB Phase	15
4. Function Keys	
4.1 1 - Help	16
4.2 2 - DOS	16
4.3 3 - SetUp	16
4.4 4 - Util	16
4.5 5 - New	17
4.6 6 - Last	17
4.7 7 - File	17
4.7.1 Load file <2>	18
4.7.2 Save file <3>	18
4.7.3 Kill file <3>	18
4.7.4 New directory <5>	19
4.7.5 Make ASY-file <6>	19
4.7.6 Description <7>	19
4.7.7 Create new directory <8>	20
4.8 8 - Scatt	
4.9 9 - Ant	20
4.10 Esc - End	21
5. Hot Keys	22
6. Main Menu	

1. Description

The Control Panel is the most important panel of the localiser simulation containing all electrical and mechanical data of the current localiser system.

All data input parameters or settings are entered with easy-to-use arrow keys to change the values or introduce system errors directly on the screen. Any phase and amplitude change can be adjusted as well as any mechanical alignment of each individual antenna element.

For two frequency systems, the amplitude ratio and phase relationship between the course and clearance SBO/CSB signals can be set to any nominal or erratic value.

2. Screen layout

The Control Panel contains two types of fields :

1. Info Fields

2. Data Fields.

The info-fields cannot be changed on the screen as they are result of computed values and are just for information purposes.

The data-fields can be activated (highlighted) by the arrow keys and their contents can be changed.

2.1 Info Fields

There are seven info fields in the Control Panel:

- 1. Heading
- 2. Antenna array
- 3. Presence of utilities and a number of Scattering objects
- 4. ADU-fields
- 5. Registration info and Function keys

<pre> AXIS 1:</pre>	LO - ILS LOCALISER SIMULATO	DR (\$/N:047) {Time}
System 2D: TH-CSF 13el 1	Dual 4F9] Defa	ault setup
FRQ (MHz): 110.3 C.Sector: 4.000 FWD Slope: 0.000° SDW Slope: 0.000° THR Dist.: 3007m Refl.Pln.:MOIST EARTH	SB0 Ampl 0.00dB SB0 Phase: 0° ADU Att. : Ant Elmt : ThCSF FRAME Ant Hgts : 2.00m 20.00% : 26.0dE	CLR SBOA : 0.0dB CLR CLR SBOP : 0° ON CLR SBA : 0.0dB Ant Elnt :ThCSF FRAME Ant Hgts : 2.00m 20.00% 20.00% 26.0dB
BDI Scatters: No (F8) Ant No. : 1 of 13 Dist C/L : -12.10m Fwd Dist : 0.00m Height : 2.00m AZ Turn : 0.00° Ampl : 100% Phase : 0°	(Alt-G) (Alt-U) Course Signal SBO Ampl : 3.26% SBO Phase : -90° CSB Ampl : 0.00% CSB Phase : 0° CSB Phase : 0° (CSB Phase : 0° CSB Phase : 0° CSB Phase : 0°	(Alt-G) (Alt-U) Clearance Signal SBO Ampl : 0.00x SBO Phase : 0° CSB Ampl : 0.00x CSB Phase : 180° 0.0µA (40.00xSDM)

F1=Help F2=DOS F3=Setup F4=Util F5=New F6=Last F7=File F8=Scatt F9=Ant F10=End

Fig. CPN201 Info Fields of the Control Panel

Heading (1)

The Heading shows the Date, Time and the Software Identification with the serial number. The I-key will show the release version and date in the heading field.

Antenna Array (2)

The Antenna Array info shows the selected Antenna Array name and description. The <9> key is used to load a new antenna array from available systems

(*.ASY files) in the AXIS directory. Then the screen will show all available antenna systems, which can be loaded into the model by moving the cursor by the arrow keys and then pressing <enter>.

Use <5> to load antenna systems from other directories or a diskette. First type in the drive (eg. A:) or the directory name (eg. C:\USER).

The current antenna system can be saved in the AXIS directory by the (7 -Files) menu item and "save ASY file".

Common info and a number of Scatters (3)

- CDI /DDM CDI means the deviations in the ADU-fields are shown in uA as well as DDM means that deviations in the ADU-fields are shown in %
 - Note: <Alt-D> is used as toggle to select between CDI and DDM
- Scatters : 2 Number of entered scatters. The <8> key is used to enter Scattering Objects, or to view and modify the existing ones.

ADU fields (4)

There are two ADU fields in the lower part of the Control Panel displaying the CDI or DDM and the SDM at the ADU output probe for any setting of the system. Positive sign means FLY LEFT (150Hz predominance).

One field is for the combined Course and Clearance signal and the other shows the Clearance signal only. For reading the Course signal only, switch the Clearance off by the C-key toggle function.

For dual frequency systems, the capture effect is taken into account and the displayed value of the Course Signal ADU is the actual value to be measured by an ordinary ILS test receiver connected to this test output.

This information is very useful for on-site measurements on the system during setup or maintenance. Built-in probes in some ADU output sockets makes the setup and later checks a lot easier.

Reading between uA and % DDM is toggled by the <Alt-D>.

Registration info and Function keys (5)

The row for Registration info shows to whom the program has been registered.

On the last row of the display there are listed ten available keys <1>...<9> and the Esc key in the Control Panel.

Detailed description of the F-keys are given in this section chapter 4.

2.2 Data Fields

There are a lot of datafields in the Control Panel that can be changed. The data fields are grouped into the 6 groups as follows:

- 1. Site Data
- 2. Course Transmitter Data
- 3. Clearance Transmitter Data
- 4. Antenna Element Data
- 5. Course Signal part in each antenna element
- 6. Clearance Signal part in each antenna element



Fig. CPN202 Data fields of the Control Panel

Site Data (1)

The Site Data contents the operating frequency and the all the environment information necessary for calculation.

Course Transmitter Data (2)

This group includes the SBO-signal (Amplitude and Phase) of the Course transmitter and the type and the height of the antenna array elements. The course transmitter CSB signal is the reference for the entire system and has relative amplitude 100% or 0 dB and phase 0 degrees.

Clearance Transmitter Data (3)

This group includes the CSB-amplitude and SBO-signal (Amplitude and Phase) of the Clearance transmitter as well as the type and the height of the antenna array elements.

The clearance transmitter CSB phase signal is a reference of clearance 0 degrees. It also has a field for showing the low frequency (90/150Hz) phase

AXIS 110 ©NANCO Software

between the course and clearance transmitters. <Alt-Q> will toggle the LF tones between normal and quadrature.

Antenna Element Data (4)

This group allows adjusting the mechanical and electrical settings for each antenna element.

The first data of this group shows which antenna element is selected (Ant no).

Course Signals in the selected element (5) The feeds of CRS-signals of the selected antenna element.

Clearance Signals in the selected element (6) The feeds of CLR-signals of the selected antenna element.

The C-key is used to toggle CLR-signals on and off.

AXIS 110 User's Manual

3. Data Entry

There are 31 data fields in the Control Panel that can be highlighted, and the value or setting can be change on the screen directly.

Before entering any data, you should select the desired antenna system by using the <9> key. If the desired antenna array does not exist in the library, a similar one can be made by using the antenna array designer (<4> key), which is described in section UTL.

Another way is entering all data and then save them into the library with the <7> key. In this case also the reflection objects will be saved as part of the system. Detailed description about Function key <7> is in the chapter 4.7 of this sec-tion.

Data values are changed by moving the cursor with the arrow-keys to the desired data field and then use the value stepping keys.

The value stepping keys are:

Increment	Decrement	Factor
<insert></insert>	<delete></delete>	0.1
<pgup></pgup>	<pgdn></pgdn>	1
<ctrl-pgup></ctrl-pgup>	<ctrl-pgdn></ctrl-pgdn>	10

3.1 System Entry

The system entry includes the antenna array and the toggle for a two- or threedimensional model (2D/3D).

3.1.1 Image antennas (3D) or flat model (2D)

System 2D:

Select whether the array computation should be a general fast 2-dimensional algorithm for a general view of the azimuth diagram, or use the antenna height, FSL and SSL DATA to include the image antennas in the ground plane. 3-dimensional mode is somewhat slower since the number of antennas will be doubled, but must be used if reflection objects are included in the model, or if the antenna elements are mounted at different heights.

Toggle between 2D/3D using the <PgUp> / <PgDn> key.

If a scattering object is entered into the model or the clearance antennas have a different height than the course antennas, the 3D mode will be automatically invoked.

3.1.2 Antenna Array

System : nnnnnnn 9] nnnnnn

The selection of the antenna system is made by the key <9>. The chosen antenna system is displayed, and the 21 characters text field is describing the setup.

The antenna system will also be changed by the keys <3>, <4>, <5>, <F> and <7>. The details of those function keys are given under the function keys description.

3.2 Site Data

Site data contains the parameters which represent the environment and includes

1. FRQ (MHz):	Operating Frequency
2.C.Sector :	Course Sector
3. FWD Slope:	Forward Slope
4. SDW Slope:	Sideways Slope
5. THR Dist.:	Threshold Distance and
6. Refl.Pln.:	Reflection Plane Type

3.2.1 Operating Frequency

FRQ (MHz):

The operating frequency can be entered for localiser RF frequency. Select either 20 or 40 channels with <Alt-E>.

3.2.2 Course Sector

```
C.Sector : (°)
```



Fig. CPN301 The nominal Course Sector

The Course Sector is the nominal course sector angle in degrees (°).

When changes are made, the corresponding distance to the landing threshold (THR Dist) will be updated. The distance is automatically set so the Course Sector will be ± 105 m at the threshold.

Also the SBO attenuator will be updated to a new value that will produce the selected sector width.

If the ADU attenuator is adjusted, the course sector setting and the resulting value will be different.

AXIS 110 User's Manual

3.2.3 Forward Slope

FWD Slope: (° or %)

The average or weighted Forward Slope of the reflection plane of the first 300m in front of the antennas. This function should be used with caution if reflection objects are present in the model.



Fig. CPN302 The Forward Slope

For sloping upwards viewing from the antenna array, the FSL is positive. The <Alt-S> key toggles between degrees (°) or percent (%) slope.

3.2.4 Sideways Slope

```
SDW Slope: ( ° or %)
```

The average or weighted sideways slope of the reflection plane.



Fig. CPN303 The Sideways Slope

The SSL is positive if sloping upwards towards the FLY LEFT side of the runway.

The <Alt-S> key toggles between degrees (°) or percent (%) slope.

The slope settings are only for checking the impact on the far field radiation diagrams and will not behave correctly if there are scattering objects present since the model only changes the position of the image antennas. There is no limit of the size of the models reflection plane. If scattering objects are present in the model, the Forward and Sideways slopes will be de-activated.

3.2.5 Threshold Distance

THR Dist. : (m)

The theoretical distance between the localiser array and the landing threshold.

LLZ array []		THR
←	THR distance	\rightarrow

Fig. CPN304 The Threshold Distance

Changes will yield a corresponding change in the course sector data field C.Sector and the SBO attenuation.

3.2.6 Reflection Plane

Refl.Pln. :

The type of ground in the reflection plane. This parameter has an impact on the reflection factor of the ground plane and depends on the incident angle of the signal.

The selection of the ground plane are:

PERFECT SALT WATER FRESH WATER SOAKED SOIL MOIST EARTH WET SAND DRY EARTH DRY SAND CONCRETE

3.3 Course Transmitter Data

Transmitter data fields contain the parameters adjustable in the electronic cabinet for the COURSE-signals. The type of the antenna elements and their heights are also included.

3.3.1 Course SBO Amplitude

SBO Ampl : (dB)

Displays the general SBO amplitude from the modulator in deciBel (dB). Changes can be done in 0.01 dB steps. Nominal value is 0 dB and refers to the default values in the disk file.

3.3.2 Course SBO Phase

SBO Phase : (°)

Displays the general SBO phase from the modulator. Nominal value is 0 degrees.

By pressing the "1"-key (number one), -90°, and pressing the "9"-key (number nine), +90° phase shift will be added to this data field. This will also be seen in the lower part of the Control Panel Course Signal SBO Phase data field.

3.3.3 ADU Attenuator Throughput

ADU Att. : (dB)

If there exists an SBO attenuator in the selected antenna array ADU (Antenna Distribution Unit), the SBO to one on more antenna pair will pass through it.

Note : Positive value means higher amplitude and NOT higher attenuator setting. If no ADU attenuator exist, the field will not be activated. Adjustments will change both clearance and the resulting course width.

3.3.4 Course Antenna Element Type

Ant.Elmt :

The antenna element type used in the selected array. The element radiation diagrams are simulated with the theoretical diagram.

The available elements are:

ISOTROPIC	Omnidirectional
1/2L DIPOLE	Half wave dipole
DIPOLE W/R	Half wave dipole with reflector
LOG PERIOD.	Log Periodic Dipole Antenna (LPDA)
CAN. MARCONI	Canadian Marconi type
ThCSF FRAME	Thomson CSF frame antenna with reflector
V-DIPOLE	V-Dipole used for SEL-Clearance arrays

3.3.5 Course Antenna Array Height

Ant Hgts : (m)

The general height above the reflecting ground at the array center for antennas containing the course signal. Also valid if the clearance signal is present together with the course signal.

3.4. Clearance Transmitter Data

Clearance transmitter data fields contain the parameters adjustable in the electronic cabinet for the CLEARANCE-signals. The type of the antenna elements and their heights are also included.

Note: The CLEARANCE-data fields will not be activated for single frequency systems.

3.4.1 Clearance-SBO Amplitude

CLR SBOA : (dB)

For dual frequency systems, the relative level in clearance SBO. Positive values will give higher amplitudes out of the ADU (Antenna Distribution Unit).

3.4.2 Clearance-SBO Phase

CLR SBOP : (°)

For dual frequency system, the relative SBO phase to nominal value, 0°.

By pressing the <Alt-1> key, -90° and <Alt-9> key, +90° phase shift will be added to this data field. This will also be seen in the lower part of the Control Panel Clearance signal SBO Phase data field.

3.4.3 Clearance-CSB Amplitude

CLR CSBA : (dB)

For dual frequency systems, the relative Clearance CSB amplitude from the cabinet relative to the standard setup file on disk.

Note: CLR-SBOA/SBOP/CSBA values might be changed for standard setup by using the Antenna Array Designer <4>. See section UTL.

3.4.4 Clearance-Antenna Element Type

Ant Elmt :

The Clearance-antenna element type used in the selected array. The element radiation diagrams are simulated with the theoretical diagram.

The available elements are the same as in the Course-antennas, see 3.3.4.

3.4.5 Clearance-Antenna Array Height

Ant Hgts : (m)

The general height above the reflecting ground at the Clearance-array center for antennas containing the course signal.

Note: This is also valid if the clearance signal is present together with the course signal.

AXIS 110 User's Manual

3.5 Antenna Element Data

There are three data groups showing the physical and electrical data for each individual antenna element.

- 1. Antenna Element
- 2. Course-signals
- 3. Clearance-signals

3.5.1 Antenna Element Number :

Ant No.

The number shows which antenna element is displayed in the lower part of screen.

The antenna elements are numbered from no. 1 at the extreme element on the FLY LEFT side. The highest number is the extreme element on the FLY RIGHT side.



Fig. CPN305 The Antenna Element Numbering

The number shows which antenna element is displayed. Use the <PgUp> or <plus> key to step upwards, and the <PgDn> or <minus> key to step downwards.

3.5.2 Distance to Centreline

Dist C/L : (m)

The antenna element lateral distance from the antenna array center, (normally the course line). See figure CPN306.

3.5.3 Forward Shift

Fwd Dist : (m)

The longitudinal distance from the given antenna element to the defined array zero forward distance, measured along the course line axis. This value is normally zero, but a different value can be set to simulate misalignment of the selected antenna element.



Fig. CPN306 The Forward Shift of the Antenna Element

3.5.4 Height

Height : (m)

The height of the given antenna element above the effective ground level at the center of the antenna array.

3.5.5 Azimuth Turn

AZ Turn : (°)

The rotation of the given antenna in azimuth direction. Positive values are clockwise rotation. This value is normally zero but another value can be set to simulate misalignment of the selected antenna element. This can also simulate error in the antenna azimuth diagram



Fig. CPN307 The Azimuth Turn of the Antenna Element

AXIS 110 User's Manual

3.5.6 Amplitude Error

Ampl : (% or dB)

This data field is normally 100, showing the nominal percentage reference in the antenna output. To simulate antenna gain error, reduce or increase the value to any value.

The <Alt-B> toggles the display between % and dB.

Note: This setting will effect all signals in the particular antenna element.

3.5.7 Phase Error

Phase : (°)

This datafield is normally 0. To simulate phase errors, adjust the field to the desired value in degrees.

Note: This setting will effect all signals in the particular antenna element.

3.6 Course Signals in the selected element

3.6.1 Course-SBO Amplitude

SBO Ampl : (% or dB)

The relative SBO amplitude (relative to maximum CSB feed) for the given antenna defined as the 150 Hz sideband vector relative to the carrier vector in the reference CSB.

The <Alt-B> toggles the display between % and dB.

3.6.2 Course-SBO Phase

SBO Phase : (°)

The phase of the 150 Hz sideband vector relative to the carrier phase in reference CSB.

The nominal values are -90° on the antennas on the FLY LEFT side of the array, and +90° on the FLY RIGHT side.

The reference CSB is nominally one of the center pair antennas.

WARNING: Do not use "9" hotkey (number nine) to adjust a single antenna element phase. It adjusts the Course-transmitter phase shifting all Course-SBO-phases by 90 degrees.

3.6.3 Course-CSB Amplitude

CSB Ampl : (% or dB)

The CSB amplitude relative to a given reference, which is normally one of the antennas either single or in the pair having the highest amplitude. This reference is normally set to 100.

The <Alt-B> toggles the display between % and dB.

3.6.4 Course-CSB Phase

CSB Phase : (°)

The CSB phase relative to the Course CSB reference signal. Normally all elements will have 0° phase.

3.7 Clearance Signals in the selected element

3.7.1 Clearance-SBO Amplitude

SBO Ampl : (dB or %)

The relative clearance SBO amplitude for the given antenna defined as the 150 Hz sideband vector relative to the carrier vector in the reference clearance CSB.

The <Alt-B> toggles the display between % and dB.

3.7.2 Clearance-SBO Phase

SBO Phase : (°)

The phase of the 150 Hz sideband vector relative to the carrier phase in reference clearance CSB. The nominal values are -90° on the antennas on the FLY LEFT side of the array, and $+90^{\circ}$ on the other half. The reference clearance CSB is nominally one of the center pair antennas.

WARNING: Do not use the <Alt-9> to adjust a single antenna element phase. It will effect to the Clearance-transmitter shifting all Clearance-SBO-phases by 90 degrees.

3.7.3 Clearance-CSB Amplitude

CSB Ampl : (dB or %)

The clearance CSB amplitude relative to a given reference, which is normally one of the antennas either single or in the pair having the highest amplitude. this reference is normally set to 100.

The <Alt-B> toggles the display between % and dB.

3.7.4 Clearance-CSB Phase

CSB Phase : (°)

The clearance CSB phase relative to the clearance CSB reference signal, normally 0° in the middle antenna or antenna pair.

4. Function Keys

In the Control Panel there are ten function keys (1-9) available.

4.1 <1> - Help

The <1> key will display a short description on the function and navigation keys as well as the value stepping keys

<date> AXIS 110 - ILS LOCA</date>	LISER SIMULATOR (S/N:000) (Time)
F1 This Help Screen F2 SHELL to DOS F3 Change default Setup F4 Utilities F5 Load default Setup	F6 Load Last Used Setup F7 Load/Save model in Files Library F8 Enter/View Reflection Objects F9 New antenna system (Alt-F9 dir) F10 Ston/Regret/Escame/Ouit
 f Move Up a DATA Field J Move Down a DATA Field > Move to Next DATA Section < Move back one DATA Section Home First DATA Section End Last DATA Section 	ICTRLIPgUp Increase Value 10X PgUp Increase Value Ins Increase Value .1X Del Decrease Value .1X PgDn Decrease Value ICTRLIPgDn Decrease Value 10X
<enter> Continue TO MENU</enter>	+ Step Up - Antenna number - Step Down Antenna number
More help now: H – View Hot-keys in Main Screen	M Mouse Instructions

Fig. CPN401 Help Screen of the Control Panel

More help screens are displayed when pressing H or M keys.

H-key will display the hotkeys and M-key will display the mouse instruction.

4.2 <2> - Omitted

This key is no longer in use.

4.3 <3> - SetUp

The <3> opens the setup screen for configuring and saving the setup as a default.

You can set the system data, site data, language and the printer control as well as the screen type and the default colours. Detailed description is given in section SET.

4.4 <4> - Util

The <4> opens the utility selection screen. A complete description about the utility is given in section UTL.
4.5 <5> - New

This function gives you the default start-up values and erase all entries previously set. Alter the default values by using the <3> key to change the setup which is contained in the file AL.002. Appendix A2 describes the format and the content of AL.002.

4.6 <6> - Last

The <6> key will load the setup you actually were running last time. The file AL.003 contains this setup.

In the appendix A2 the format and the content of this file is described.

Note: AL.003 is identical to the library files in the WORK directory.

4.7 <7> - File

This function key <7> allows you handle (load/save/kill) your files on the disk.



(F2)Load (F3)Save (F4)Kill (F5)New directory (F6)Make ASY-file

Fig. CPN402 The screen after <7> selection

There are five function key commands available

- (2) Load file
- (3) Save file
- (4) Kill file
- (5) New directory
- (6) Make ASY-file

The default directory is the WORK\ subdirectory under the AXIS directory. <PgUp/PgDn> is used for selecting preset directories named WORK1\ through WORK50\.

AXIS 110 User's Manual

4.7.1 Load file <2>

This command is used to load earlier saved model to the AXIS. It will display all the modelling (setup) files in the selected directory. Above the filenames there is 21 character long description field, where you can read the model description.

<date></date>	AXIS 110 -	ILS LOCALISER SIMULATOR	(S/N:000)	<time></time>
	<cr> to select</cr>	Hammerfest 23 hang	<esc> to can</esc>	cel
HF23-1 . 84262912 Bytes	HF23-2 . free			

Fig. CPN403 Typical "Load file" Screen

The cursor appears on the first file name. Move it with the arrow keys and press <Enter> to load the file. Press <Esc> to return without loading any file.

4.7.2 Save file <3>

This function is used to save the model in the selected directory. It opens two fields which you have to enter for saving the file.

1. Enter file name ----- <Esc> to cancel

Press <Esc> for returning to Control Panel without saving any file otherwise type the file name (7 characters max and on extension) and then press <Enters.

2. Enter new Text | ----- |

Description |

The text field of 21 characters that gives a short description of the system and any particular settings or errors. This Text will be displayed at the top of the Control Panel.

The file is saved with all RUN-settings like orbit angle, scale, approach distances, increments etc.

4.7.3 Kill file <4>

This will display all the setup files in the WORK directory, and opens a 21 character field where you can read the file description.

The cursor appears on the first file name. Move it with the arrow keys and press <CR> to delete the file. Press <Esc> to avoid deleting any file.

The operation is similar as "Load file" expect you are warning and prompting

Are you sure (Y/N)?

before making any deleting.

AXIS 110 ©NANCO Software

4.7.4 New directory <5>

This command let you change the directory or disk drive for the files.

The menu for this option is:

Enter new directory <CR>=Default ->

The command is cancelled by <Enter> otherwise type the complete path and directory without the final backslash like the following examples:

C:\myfilesor A:

Note: <PgUp/PgDn> allows a quick selection of directory work1 through work50.

4.7.5 Make ASY-file <6>

This will save the current antenna array as an ASY file and add it into the antenna array selection that is called in Control Panel by <9>-key.

Entry take place in two steps :

1. Enter the file name

```
Enter file name : |---.ASY| <CR> if none
```

Cancel the command by pressing <Enter> otherwise type max 8 characters for file name and then press <Enter>.

2. Enter the description

```
Enter new Text |-----
```

:

Description |nnnnn

4.7.6 Description <7>

This command lets you write your own label in each directory. Type the text and press <enter> to create the label. This may be a simple description of what kind of files there are in this directory e.g. an airport name, testing scatter objects etc.

Description

The label can be rewritten anytime.

AXIS 110 User's Manual

4.7.7 Create new directory <8>

If a non-existing directory is selected, a warning will appear with a reminder that (8) can be pressed to create the directory. After pressing (8) the warn-ing disappears and the directory is ready for use. Use the (7) to make a memo label for the content.

<date></date>	AXIS	110 - ILS	LOCALISER	SIMULATOR	(S/N:000)	<time></time>
Files direc	tory					
Work direct	ories:	Select b	y PgUp/PgD	n		
Files direc	tory	=> WORK4	×			
(F7) Descri	iption	This (directory (does not ex	ist - (F8)	to make

Fig. CPN406 Creating a new directory by <8>

4.8 <8> - Scatt

This function enables insertion of the reflection objects into your simulation model. Detailed description is given in the SCA-section.

4.9 <9> - Ant

This <9> key is used to load a new antenna array from the disk library of ASY files.

<1)ate>	AXIS	110 -	ILS LOCALISE	R SIMULATO	R (S∕N:	000) <time></time>
<cr> t</cr>	o select	antenna	system	NM3524 12e	l Dual	<esc></esc>	to cancel
NMD12 PHLD20 TCD25 WXS14 CANS16 842629	.ASY .ASY .ASY .ASY .ASY .ASY 912 Bytes	NMD24 PLD12 CAND35 TCS13 CANS26 free	. ASY . ASY . ASY . ASY . ASY . ASY	NMSØ6 PLD24 WXD14 CANSØ9	-ASY -ASY -ASY -ASY -ASY	NMS12 TCD13 WXS08 CANS11	.ASY .ASY .ASY .ASY

Fig. CPN404 Typical Antenna Array Selection Screen

This key will display all the antenna systems (*.ASY) available on the AXIS directory. The cursor appears on the first file, and on top of the screen is shown a 21 character string describing the antenna system.

Use the arrow keys to highlight a wanted array and press <CR>. This will load the selected system as a new array for your simulator.

Press <Esc> to return to the Control Panel without loading any system.

Note: The new array does not contain any Site Data except the Course sector and the corresponding THR-distance. So check these values in case you are comparing different antenna systems. A warning is given to the user if the course sector has been changed on the Control Panel since last run.

4.10 Esc - End

The <Esc> key will terminate the AXIS 110 program.

Before terminating you are warning and prompting

Are you sure (Y/N)?

Pressing the Y-key the program will exit. Any other key will return to the Control Panel. If another language than English is used, the corresponding key for 'Y' in the other language must be used.

The <Esc> key is one of the most useful key as a "regret" function. It will interrupt computations, and subsequently exits the simulator level by level. AXIS 110 User's Manual

5. Hot Keys

There are many Hot Keys available in the Control Panel. The Hot Keys or an Alt Key combination execute a given action immediately when pressed. Here is a brief description about the Hot Keys in the Control Panel:

< B > black & white or colours

Hot key is a toggle selecting screen between Colour and B&W.

< H > hot keys table

Hot key <H> shows the help screen about the hot keys.

<date> AXIS 110 - ILS LO</date>	CALISER SIMULATOR (S/N:047) <time></time>
Hot-keys (Instant action without su	bsequent <enter> key):</enter>
B Black & White or Colours I Info on Version & Date Q Quit from Control Panel W Enable 4 independent windows	H This screen N News in Development 2 See startup arguments
1 Add -90° to Course SBO <alt-1> Add -90° to Clearance SBO</alt-1>	9 Add +90° to Course SBO <alt-9> Add +90° to Clearance SBO</alt-9>
<pre><alt-a> List antenna system feeds <alt-c> Clearance ON/OFF toggle <alt-g> Set modulation depths <alt-f> Expand ant aperture x times <alt-r> View Reflected signals only <alt-t> Add tolerances to the feeds</alt-t></alt-r></alt-f></alt-g></alt-c></alt-a></pre>	<pre><alt-b> Toggle amplitudes dB or % <alt-d> Toggle %DDM or CDI display <alt-m> Toggle measures meters/feet <alt-q> CLR 90/150 in ±Quadrature <alt-s> Slope (FSL & SSL) in ° or % <alt-u> Set Front/Back Ratio</alt-u></alt-s></alt-q></alt-m></alt-d></alt-b></pre>

<Alt-F9> Temporary change ASY directory

Fig. CPN502 Screen after hotkey H is pressed

< I > Info on version and date

Hot key <l> shows the program version and date. This info replaces the heading text of the Control Panel.

< N > news in development

Hot key <N> display the !A110news file, which briefly describe the AXIS 110J development phases.

< Q > quit from Control Panel

Hot key <Q> can be used instead of "X" in the upper right-hand corner to exit AXIS 110J

< Z > see start-up arguments

Hot key <Z> displays the switches (arguments) to be selected at start-up.

<1>/<9> adds -90°/+90° to the Course SBO

<Alt-1>/<Alt-9> adds -90°/+90° to Clearance SBO

AXIS 110 ©NANCO Software

<Date> AXIS 110 - ILS LOCALISER SIMULATOR (S/N:047) <Time>

Switches for startup AXIS software (User Guide has complete list) Preceed only first switch with ">" e.g: a110 >feet nodate BLACK - Remove colours to enable saving of graphic screens CUT - Cut the direct signal from the output leaving scatter only DDM - Uses >DDM instead of CDI in µA as default NODATE - No date/time on screen or printout QUAD - Clearance modulation in guadrature to course 90/150

- Fig. CPN503 The screen after hot key Z is pressed.
- < Alt-A > list antenna system feeds

<Alt-A> is used to display or print the antenna feeds in list form.

<pre> <date></date></pre>		AXI	S 110 -	- ILS	LOCALIS	ER SI	MULATO	R (S,	/N:000>	<time></time>
TH-CSF 13e1 Ant Distm 1 -12.10 2 -9.90 3 -7.20	1 Dual SBOA 3.26 6.84 10.35	I SBOP -90 -90 -90	Default CSBA 0.00 15.66 35.48	setur CSBP 0 0 0	SBOA 0.00 0.00 0.00	SBOP Ø Ø	CSBA 0.00 5.18 11.74	CSBP 180 180 180	<mark>CDI</mark> -999.0uA -0.0uA -0.0uA	<mark>С-СДІ</mark> 0. ФиА 0. ФиА 0. ФиА
$\begin{array}{c} 4 & -5.50 \\ 5 & -3.30 \\ 6 & -1.10 \\ 7 & 0.00 \\ 8 & 1.10 \\ 9 & 3.30 \\ 10 & 5.50 \\ 11 & 7.70 \\ 12 & 7.90 \\ 12 & 12.10 \end{array}$	11.62 9.06 3.59 0.00 3.59 9.06 11.62 10.35 6.84 3.26	-90 -90 90 90 90 90 90 90	60.95 86.09 100.00 100.00 86.09 60.95 35.48 15.66 0.00	5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5	U.UU 5.43 20.89 0.00 20.89 5.43 0.00 0.00 0.00 0.00	-90 -90 90 90 90 90 0	20.19 28.52 9.59 208.94 9.59 28.52 20.19 11.74 5.18 0.00	180 180 180 180 180 180 180 180 180	U.UuA U.OuA U.OuA U.OuA -O.OuA U.OuA U.OuA -O.OuA -O.OuA -9999.OuA	U - UuA U - OuA U - OuA U - OuA −U - OuA −U - OuA U - OuA U - OuA U - OuA U - OuA

Hit any key to continue... (F3)Print (F4)Print & Form feed

Fig. CPN501 Typical screen after hotkey A is pressed

With <3> and <4> you can have a hardcopy of the antenna feeds.

<Alt-B> toggle between dB and %.

<Alt-B> toggles all amplitudes between dB and %.

- <Alt- C > clearance transmitter ON/OFF <Alt-C> is a toggle switching clearance transmitter ON and OFF.
- <Alt-D> toggles displays between uA and %
- <Alt-G> Enter MOD BALANCE and MOD DEPTH Enter MOD BAL in uA or %DDM for the course transmitter, or MOD DEPTH for 90 and 150Hz separately for the clearance transmitter.

AXIS 110 User's Manual

<Alt-M> toggle between meters and feet

<Alt-P> Enabling setting of an antenna spacing factor x.

Enables entry of a value x for changing the lateral spacing between the antenna elements. 1 is default while 2 doubles the spacing and hence the aperture.

<Alt-Q> toggle for clearance 90/150 in Quadrature

<Alt-Q> toggles 30Hz synchronisation between course and clearance low frequency in quadrature. This makes the adverse impact of reflected clearance into the course signals far less.

<Alt-R> Remove direct signal - view scattered signal only.

This makes it possible to see and trace the scattered signal only so you can see where they propagate in the field.

<Alt-S> toggle for slopes FSL & SSL between ° and %.

<Alt-T> adds tolerances to the feeds

Add random tolerances to all antenna elements. This feature may simulate a practical installation where the feeds deviate from the ideal ones. This is useful when examining the system sensitivity for antenna feed errors.

Height 2.00m	CSB Hmp1 : U.UU%	USB Hmp1 : U.UUX
Random setup tolerances	CSB Phase : O ^o	CSB Phase : 180°
Phase $\langle 0 \rangle \langle \pm 3 \rangle$:	-999.0µA (999.00%SDM)	0.0µA (40.00%SDM)

Operator Test > F1=Help F2=D08 F3=Setup F4=Util F5=New F6=Last F7=File F8=Scatt F9=Ant F10=End F1=Help F2=D08 F3=Setup F4=Util F5=New F6=Last F7=File F8=Scatt F9=Ant F10=End F1=Help F2=D08 F3=Setup F4=Util F5=New F6=Last F7=File F8=Scatt F9=Ant F10=End F1=Help F2=D08 F3=Setup F4=Util F5=New F6=Last F7=File F8=Scatt F9=Ant F10=End F1=Help F2=D08 F3=Setup F4=Util F5=New F6=Last F7=File F8=Scatt F9=Ant F10=End F1=Help F2=D08 F3=Setup F4=Util F5=New F6=Last F7=File F8=Scatt F9=Ant F1=Help F2=D08 F3=Setup F4=Util F5=New F6=Last F7=File F8=Scatt F9=Ant F10=End F1=Help F2=D08 F3=Setup F4=Util F5=New F6=Last F1=F10=F10 F1=F10=F10 F10=F10 F10 F10 F10 F10 F10 F10 F10 F10

- Fig. CPN504 Random amplitude errors are added to the antenna feeds. In this case max ±5% amplitude and max ±3° phase in each element.
- <Alt-U> Adjust front-back amplitude ratio of the antenna elements.

All antenna elements have default front-back ratios, but these can be changed using this function. Default values cannot be changed.

<Alt-W> Allows using up to 4 independent Windows in DOSBox DOSBox can be opened in several windows so different tasks can be run on the same screen. In order to isolate each of them to save the individual run-files on the disc, a number (1-4) is assigned to each window. Only the numbers 2 through 4 are visible on the graphic screen.

6. Main Menu

The program execution comes into the main menu when <Enter> is pressed on the Control Panel.

<date></date>	AXIS 110 - IL	S LOCALISER SI	1ULATOR <	(8/N:047)	<time></time>
	MENU - Select	Mode by Number	r or Arrow	/ keys	
	0 - Control 1 - Playbac 3 - Orbit C 5 - Approac 6 - Fixed P 7 - Ground 8 - Bend An 9 - Sensiti	Panel (F10) k Screen files ross_Over h on course osition Current alysis ve Area			
	Current MOD	E: < 0 >			
Antenna system TH-CSR 13el Dual	Scatterers	XX response	Print FF	Active SHO	W Dir.

Fig. CPN601 Main Menu of the AXIS 110

The main menu shows the options. Available options are depending on the access level of the user. If you do not have access to the option you cannot highlight and use it.

Press the item number or move the cursor up or down with the arrow keys and press <CR> to select a run mode.

The number between the angle bracket below the menu list shows the current selection.

Here is the summary about menu selections:

0 - Control Panel (Esc) Return to Control Panel by selecting 0 or <Esc>

1 -Playback Screen files

The mode where you can see the saved graphic screens as a slide show. See section PLY.

3 - Orbit Cross Over

The orbit mode that simulates the orbit flight. See section ORB.

4 - Vertical Trace

This special option is not normally supplied with standard package.

AXIS 110 User's Manual

5 - Approach on course

The approach mode that simulates the approach path of the flight. See section APP.

6 - Fixed Position

The fixed position mode that allows you to simulate a simultaneous effect of a misalignment in the near field and far field. See section FIX.

7 - Ground Current

This mode will visualize the induced ground current in front of the antenna array. See section GND.

8 - Bend Analysis

The bend analysis mode is a tool for finding the source of reflections and multipath problems. See section BND.

9 - Sensitive Area

This module is a tool for computing the LOC-sensitive area for a given antenna system and airplane type. See section SNS.

Lower part of the main menu screen informs you some settings of the control panel.

- 1. Antenna System
- 2. Number of scattering objects
- 3. Receiver response (rad/s)
- 4. Printer form feed selection and
- 5. Type of screen

Table of Contents

1. Description	1	
2. Data Panel	2	
3. Data Entry	3	
3.1 Calculation Dimension and Antenna Array	3	
3.2 Site data	3	
3.2.1 Operating Frequency	3	
3.2.2 Forward Slope	3	
3.2.3 Sideways Slope	4	
3.2.4 Reflection Plane	4	
3.3 Printer, Screen and Receiver Settings	4	
3.3.1 Form Feed for the Printer	4	
3.3.2 Screen Type	5	
3.3.3 Receiver Filter	5	
3.3.4 Character Set	6	
4. Colour Settings	7	
4.1 Change Colours	7	
4.2 Colour Codes	7	
5.Command Panel		8
5.1 Language <2>		8
5.2 Save <3>	•••••	9
5.3 Delete User's Code <5>		9
5.4 Save current Run/Toggle settings		9
5.5 Delete Run/Toggle settings		10
5.6 Cancel	•••••	10

SET SetUp

1.Description

The SetUp utility is called from the Control Panel by <3> key.

The SetUp utility consists of three main functions:

- 1. startup configuration
- 2. language selection and
- 3. the user code deletion.

The setting of configuration will be used to initialize AXIS110 as the default setup whenever the software is started.

Language selection is used to determine the language that is seen in help screens and names of parameters / toggles all around the AXIS110.

The user code deletion is used for security purposes and for re-entering a new User Code with different access level.

SetUp procedure is divided into two parts (actually two screens).

In the first screen you are able to change parameter settings.

Secondly you proceed to the command screen where you have three commands available (save, language, delete usercode).

If you do not select any command but hit <enter> the program execution will return into the Control Panel without any changes.

2.Data Panel

The <3> in the Control Panel will start the setup procedure opening the first screen called Data Panel.

Data Panel configuration items are divided into four groups :

- 1. Model Dimension and Antenna Array
- 2. Site Data
- 3. Printer, Screen and Receiver Settings
- 4. Color Settings

<pre> AXIS 11</pre>	LO - ILS LOCALISER SIMULAT	OR (S/N:000) <time></time>
▶System 2D: TH-CSF 13el I	ual ∢F9] Def	ault setup
 ▶FRQ (MHz): 110.3 C.Sector : 4.00° ▶FWD Slope: 0.000° ▶SDW Slope: 0.000° THR Dist.: 3007m ▶Refl.Pln.:MOIST EARTH 	Language GB Work directory MORK Graph directory SHOW	CDIMetersForm FeedNOUGA - 640x480Rx Filter2.0 rad/sPrt ChrsRoman8
► = alterable This is the Se Set new colour	items - others must be se etup when starting up or b rs '1' & '2' - Heading '3' & '4' - Cursor t '5' & '6' - Screen t	t in TCD13 .ASY by pressing (F5) text/back ext/bar ext/Background

Press <CR> to proceed.....

Fig. SET201 The Data Panel of the Setup utility

Subdirectories.

The subdirectory names WORK and SHOW are the family names for all directories used for saving site data (WORK, WORK1 through WORK50) and showing black & white graphs for making animations from slowly changing parameters or moving obstacles (SHOW, SHOW1 through SHOW50).

The user can change the directory family names to anything else like "ARBEIT", "GROUP", "LAGER" etc.

This has to be done manually with an EDITOR in the file "AL.002" in the AXIS directory. The two default names "WORK" and "SHOW" can then be changed. After this has been done, the (7)-key will look for a directory called the new name when saving and storing.

3. Data Entry

The configuring will take place in two steps.

First you set the all-configuration parameter.

Secondly you will open another screen by <Enter> key called Action Menu where you can select save, language or ignore the configuration. In case of user code deletion you pass the first step (Data Panel) by <Enter> key and proceed directly to the Action Menu where you can select the User Code deletion.

In the Data Panel the values can be changed by highligting the item with arrow keys and using PgUp/PgDn-keys to get the new value in the same way as in the Control Panel.

The small triangles in front of the items indicate that the item may be changed.

NOTE: activated and changed but they will be not saved. tion object is present. (nnn.ASY) and MUST be set differently.

3.1 Calculation Dimension and Antenna Array

System 2D : nnnnn

The calculation dimension is toggled between 2D and 3D by <PgDn> /<PgUp> keys.

The Antenna Array can be selected by <9> key which opens the array selection screen in the same way as in the Control Panel.

3.2 Site data

Site data group is excatly same as in the Control Panel allowing to change the parameters with value stepping keys <PgUp>,<PgDn>.

NOTE: Only triangled items are effective in the configure.

3.2.1 Operating Frequency

FRQ (MHz):

The operating frequency can be entered for localizer RF frequency. Selection between 20 and 40 channels must be made in the Control NOTE:

Panel by <Alt-E> hot-key.

3.2.2 Forward Slope

FWD Slope: (° or %)

The average or weighted Forward Slope of the reflection plane of the first 300m in front of the antennas.

For sloping upwards viewing from the antenna array, the FSL is positive.

NOTE: The selection between degrees (°) or percent (%) slope must be set in the Control Panel by <Alt-S> key.

Non triangled items 2D/3D, C.sector and THR distance can be also

Model dimension will be set automatically to 3D-mode if the reflec-

C.sector and THR distance are included in the antenna array file

3.2.3 Sideways Slope

SDW Slope: (° or %)

The average or weighted sideways slope of the reflection plane.

The SSL is positive if sloping upwards towards the FLY LEFT side of the runway.

NOTE: The selection between degrees (°) or percent (%) slope must be set in the Control Panel by <Alt-S> key.

3.2.4 Reflection Plane

Refl.Pln. :

The type of ground in the reflection plane. This parameter has an impact on the reflection factor of the ground plane and depends on the incident angle of the signal. The selection of the ground plane are:

PERFECT SALT WATER FRESH WATER SOAKED SOIL MOIST EARTH WET SAND DRY EARTH DRY SAND CONCRETE

3.3 Printer, Screen and Receiver Settings

It should be noted that the settings for receiver low frequency filter can be only made in the SetUp Data Panel (3 in the control panel).

3.3.1 Form Feed for the Printer

Form Feed :

This setting is obsolete and no longer used.

3.3.2 Screen Type

This setting is obsolete and no longer used.

3.3.3 Receiver Filter

RX Filter

The receiver/plotter has a certain time constant that determine the upper frequency limit for outputting fast scalloping. The frequency where

amplitude of the bends has decreased 3dB is called the cutoff frequency. This will be expressed in radians per second (rad/s).

The AXIS110 simulates a digital low pass filter and the value of the cutoff frequency will be effected to the bend amplitudes of the analysing modes.

In static analysing modes like Fixed Point and Ground Current where the receiver speed is zero the filter value has no effect.

ICAO Annex 10 attachment C recommends a time constant depending on the speed. More information about the filter is given in appendix A1 chapter 5.

3.3.4 Character Set

Prt Chrs

This setting is obsolete and no longer used.

Blank page

4. Colour Settings

The colour settings are effecting only in the text screens and the graph diagram colours must be set changing the graph colour file content manually with

text editor.

The graph colours are coded in the file AL.009. It should be noted that curves are drawn in preset colours so changing colours carelessly the graphic screen can look very strange. For instance the background colour should not ever be chosen differently from black or white. See details in appendix A2.

4.1 Change Colours

AXIS110 is using four different colourpairs (fore/background) for :

- heading
- cursor
- text and
- data value.

Colours are changed by stepping the number-keys and you will see the effect immediately on the screen.

Colour changing number keys are as follows: Foreground colour of the heading key-1 key-2 Background colour of the heading key-3 Foreground colour of the cursor key-4 Backgroun colour of the cursor key-5 Foreground colour of the text Background colour of the text key-6 key-7 Foreground colour of the data values RESTORE all colours to the standard settings key-8 Text and Data values have the same background colour.

- NOTE:

4.2 Colour Codes

Colour selection is depending the video adapter of your computer.

For standard colour graphic adapters include the following colours choices : F ForeGround only

	U
Fore- and	BackGround
code	colour
0	Black
1	Blue
2	Green
3	Cyan
4	Red
5	Magenta
6	Brown
7	White

code colour

- 8 Gray
- 9 Light blue
- 10 Light green
- Light cyan 11
- 12 Light red
- Light magenta 13
- 14 Yellow
- High intensity white 15

5.Commands

When the settings are completed in Data Panel or you like to only delete the User's Code you will proceed by <enter> key to this screen including four commands.

(2) Language change

- (3) Save settings as the default setup
- (4) Rename Work/Graph Directories

(5) Delete the User Code

<CR> No Change



```
(F2) Language change (GB )
(F3) SAVE this as the Default setup
(F4) Rename the Work/Graph directories (F5) Delete the User Code
(F6) Save current Run/Toggle settings (F7) Default Run/Toggle settings
```

<CR> No Change



5.1 Change Language <2>

(2) Language change (UK)

The language selection is based to the language files AL10.nn, AL11.nn and AL12.nn. Where the nn extension represents the country code.

For example UK=United Kingdom, NO=Norway, ES=Spain etc.

Purpose of three language files are:

- AL10.nn Help screens for a scattering object editor
- AL11.nn Help screen called from the Control Panel
- AL12.nn All modules and functions declaring texts.

<Date> AXIS 110 - ILS LOCALISER SIMULATOR (S/N:083) <Time>

Enter the file extension country code (see list below Now:*.GB) : _

AL10	.GB	AL10	.N	AL10	.FIN	AL10	.F
AL10	.\$	AL10	. DK	AL10	. E	AL10	.D
10571	776 Bytes	free					

Fig. SET502 Language selection of the SetUp

The command <2> opens the screen where you can see all the AL10.nnn files available.

On the first row you are asked to enter the extension part (=country code) and then press <enter>. If the country code exists you can see your selection in the (2)-command row. If you do not want to change the language just hit <enter>. NOTE: You must press <3> to save the selection.

5.2 Save Configuration <3>

(3) SAVE this as the Default setup The <3> will save configuration permanently into the file AL.001 as the new Default SetUp and the program will return to the Control Panel with the new configuration settings.

5.3 User Code Deletion <4>

(4) Rename the Work/Graph directory The <4> will let you change the names, maybe matching another language.

5.4 User Code Deletion <5>

(5) Delete User Code

The <5> will clear the AL.001 file that contains the user code. This will disable the usage of AXIS110 software. Before doing the deletion the AXIS110 will ask

"Are you sure Y/N ?".

Pressing the Y key (or any other language affirmative letter) the deletion will take place and the AXIS110 execution will be halted. Any other key will return the program to the Control Panel.

This will prevent others from using the software as well as enabling you to enter a new User Code if you are given a new access level.

Use this before entering a new user code with higher access, as this is the only way of preparing for re-entering the user code.

5.6 No Change

Table of Content

1. Brief description of the utilities
2. Antenna Array Designer
2.1 Description
2.2 Basic Data Entry
2.3 Data Accepting
2.4 Array Naming
2.5 Array Saving
2.5.1 List Array feeds <2>
2.5.2 Save the Antenna Array <3:
2.5.3 Back to the Control Panel <

UTL Utilities

														 								 	 	 						 	1	
																						 	 	 							3	3
																						 	 	 						 	3	3
																						 	 	 							4	ŀ
																						 	 	 							5	5
																						 	 	 							6	5
																						 	 	 							7	,
																						 	 	 							7	,
<	3	3	>	>					•	•	•				•	•		•				 	 	 		-					7	,
	<	<	(2	;	F	2	>	>		•				•	•		•				 	 	 		-					7	,

1.Brief description of the utilities

This section includes description of the utilities which is called by <4> in the Control Panel.

An opening screen is a menu showing the utilities available.

<Date>

Select utility

(F2) Antenna System Designer

Fig. UTL101 The menu of the utilities

Selection is made by function keys shown in the screen. If any other keys are pressed, you will return to the Control Panel.

(2) Antenna Array Designer This utility is for fast LOC-antenna design.

AXIS 110 - ILS LOCALISER SIMULATOR (S/N:000) <Time>

2. Antenna Array Designer

2.1 Description

The Antenna Array Designer is an utility submodule of the AXIS110 that helps you to design a new antenna array.

The AADesigner utility is an automatic process allowing fast design of an antenna array.

The array design can be made with either user defined feeds or computed Dolph-Chebychev feeds.

Due to the automation process the Antenna Array Designer has limitations as well as it assumes a number of things.

array with any text editor.

When using the AADesigner the design process must proceed sequentially step by step.

It consists of four steps called

- 1. Basic Data Entry
- 2. Data Accepting
- 3. Array Naming and
- 4. Array Saving

After the design of all system parameters, you will be given the option of saving the new system or just return to the Control Panel.

NOTE: An Antenna Array can always be designed in the Control Panel by modifying the present array and then save it by <7>. However, in the Control Panel you can not add antenna elements. If you are familiar with ASY-files you can write your own antenna

2.2 Basic Data Entry

The Antenna Array Designer asks you in the first phase some questions

- the number of SBO and CSB antenna elements
- element spacing, given in meters or lambda
- feeds distribution type.

<Date> AXIS 110 - ILS LOCALISER SIMULATOR (S/N:000) <Time>

Antenna System Design Module

Enter number of antennas in the array SB0 < 12> :Enter number of antennas in the array CSB < 12> :Enter element spacing (lambda) (F2)Meter < 0.75> :(F2) Chebychev feeds <CR> User definedEnter sidelobe level (14 - 99dB)SB0 < 35> :Enter sidelobe level (14 - 99dB)CSB < 35> :(F2) Dual Frequency <CR> Single < 0> :

NOTE: Only half system [FLY LEFT SIDE] is entered...

Fig. UTL201 The Antenna Array Designer Basic Data Entry

During this step the antenna array designer assumes :

- # the array is symmetrical both sides of the centreline, therefore only the FLY LEFT side of the array is entered
- # enter the number of antenna elements radiating SBO and CSB separately
- # in case of an odd number of antennas the center antenna must be entered separately
- # the elements in the array are equi spaced
- # in case of odd number of elements the distance between center and the center pair will be a half of the nominal distance
- # for chebychev distribution the default side lobe level for SBO and CSB is 35dB
- for user defined distribution the defaul values of each elements are SBO =10 and CSB =100.
- # default values for SBO and CSB phase is -90 and 0 respectively
- # for two-frequency systems the CLR-array will be promted with zero feed amplitudes and must be filled in manually by the user.

2.3 Data Accepting

In the data accepting step the all calculated data values are shown one by one. If you accept the value press <Enter> otherwise enter the new value before <En-

ter>.

The data is asked in the following substeps:

1.	Dist	tance	from	arı	ray	cent	er	(
2.	SBO	Ampli	tude	(ક	of	MAX	CSB)
3.	SBO	Phase	9					
4.	CSB	Ampli	tude	(용	of	MAX	CSB)

5. CSB Phase

μ

Be careful accepting data because you cannot step backwards. NOTE:

Below is shown the accepting substep 1 when twelve elements antenna array is designed.

<date></date>		AXIS 110 - ILS LOC
Distance	from	array center (m)
Antenna Antenna Antenna Antenna Antenna Antenna	1 2 3 4 5 6	<pre><-11.219> : < -9.180> : < -7.140> : < -5.100> : < -3.060> : < -1.020> : </pre>

Data accepting substep 1 of the Antenna Array Designer Fig. UTL202

y center (m)

CALISER SIMULATOR (S/N:000) <Time>

2.4 Array Naming

After accepting / correcting the parameters the AADesigner ask you to identify your array. You have to enter

- 1. System name
- 2. Antenna element type
- 3. File name



Fig. UTL203 Antenna Array Naming

(1) System name

There are 21 characters space to make a description of your new antenna array design. This description is shown in the Control Panel during the file load process started by <7>.

(2) Antenna element type

Enter the first letter according to the desired element type.

Available types are :

(I) - isotropic (H) - Dipole (half lambda) (D) - Dipole with reflector (L) - Log Periodic Dipole (Normarc) (W) - Log Periodic Dipole (Wilcox) (F) - Frame (Th-CSF) (V) - V-Dipole (CLR)

(3) Name of ASY-file

Enter any name with maximum eight letters. Do not type the ASY extension as the AADesigner will make it for you.

If the file name already exists on the disk, you will be prompted

Are you sure (Y/N)

in case you will overwrite the existing file with new one.

2.5 Array Saving

Last but not least step of the designer-process is to save the new array.

The Antenna Array Designer gives you three possibilities

- 1. (2) List Array feeds
- 2. (3) Save the Array
- 3. <CR> Return to the Control

2.5.1 List Array feeds <2>

(2) List Array feeds

installed.

	<date></date>		AXI	S 110 -	- ILS	LOCALIS	SER S	IMULATOF	R (S∕	N:000>	<time></time>
ILS	ILS for Document ILS for Document										
Ant	Distm	SBOA	SBOP	CSBA	CSBP	SBOA	SBOP	CSBA	CSBP	CDI	C-CDI
1 ·	-11.22	1.14	-90	17.23	0	0.00	0	0.00	0	0.OuA	0.0uA
2	-9.18	3.03	-90	31.06	0	0.00	0	0.00	Ø	0.OuA	0.0uA
3	-7.14	5.13	-90	51.41	0	0.00	0	0.00	Ø	0.0uA	0.0uA
4	-5.10	6.17	-90	72.51	0	0.00	0	0.00	Ø	0.0uA	0.0uA
5	-3.06	5.13	-90	90.04	0	0.00	0	0.00	Ø	0.OuA	0.0uA
6	-1.02	2.00	-90	100.00	0	0.00	0	0.00	Ø	0.0uA	0.0uA
7	1.02	2.00	90	100.00	0	0.00	0	0.00	Ø	0.OuA	0.0uA
8	3.06	5.13	90	90.04	0	0.00	0	0.00	Ø	0.OuA	0.0uA
9	5.10	6.17	90	72.51	0	0.00	0	0.00	Ø	0.OuA	0.OuA
10	7.14	5.13	90	51.41	0	0.00	0	0.00	Ø	0.OuA	0.OuA
11	9.18	3.03	90	31.06	0	0.00	0	0.00	Ø	0.0uA	0.OuA
12	11.22	1.14	90	17.23	Ø	0.00	Ø	0.00	Ø	0.0uA	0.OuA

Hit any key to continue... (F3)Print (F4)Print & Form feed

Fig. UTL204 Typical list of the dual frequency 12 element antenna array designed by using the Dolbh-Chebychev distribution.

NOTE: The AADesigner does not compute CLR signals.

2.5.2 Save the Antenna Array <3>

(3) Save

By selecting save by hitting the <3> the same happens as in list selection except the file is saved first before displaying it on the screen.

2.5.3 Back to the Control Panel <CR>

<CR> Control Panel Return to the Control Panel.

This command displays the antenna feeds on the screen and allows you to make a hard copy. After that it returns to the Control Panel with new antennna array

UTL-7

Blank page

Scattering Object Editor

Table of Contents

1. Description
2. Data Entry
2.1 Type of the scattering object
2.2 Forward Distance of the sheet of
2.3 Sideways Distance (Sdw)
2.4 Length of the sheet or the wire (
2.5 Height of the sheet or diameter
2.6 Bottom Height of the sheet or the
2.7 Rotation Angle (Rot)
2.8 Tilt angle of the sheet or numbe
2.9 Reflection Factor
3. Editing Objects
3.1 Modify Data
3.2 Commands
3.2.1 (2) Add
3.2.2 (1) Copy
3.2.3 (3) Delete
3.2.4 (4) Remove
3.2.5 (5) Sort
3.2.6 <cr> CTRL Panel</cr>
4. Modeling a tailfin

	1
	2
	2
r the wire (Fwd)	3
·····	3
_at)	4
of the wire (Hat)	4
e wire (Btm-Hat)	5
	6
of wires (Tilt).	6
	7
	8
	8
	8
	8
	 8
	q
••••••	a
	3 ۵
	10
• • • • • • • • • • • • • • • • • • • •	. 10

1.Description

The scattering objects are simulated with a rectangular sheets simulating vertical walls of buildings or aircraft tailfins that might reflect, diffract and shadow the illuminated signal.

The scattering object editor is invoked by the <8> key enabling to insert, view or modify the simulated reflection objects.



Fig. SCA101 The input parameters of each scattering object.

The AXIS110 can handle upto the sixteen objects at a time.

If there are already objects entered in the system the scattering object editor will show a list of the present objects allowing to see or modify any of these. If there are no objects in the system this editor proceeds automatically to object entry.

Rotation - 2 ~

2. Data Entry

There will be nine parameters to describe each sacttering object. At entry each parameter will be presented with a simple drawing as a guide.

The default value is shown inside the angle brackets.

To keep this value just press <Enter> otherwise enter a different value and press <Enter> to proceed to the next data entry.

Note that these entries can be edited afterwards.

The data inputs of the scattering objects are :

- 1. Type of the scattering object
- 2. Forward distance
- 3. Sideways distance
- 4. Length
- 5. Height. For wires this will be the wire diameter
- 6. Bottom height
- 7. Rotation angle
- 8. Tilt angle. For wires this will be the number of wires in the section
- 9. Reflection factor

2.1 Type of the scattering object

The AXIS110 simulates two types of scattering objects, sheet and wires.

Selection of scattter type is made by <2> or <3>. All other keys will return the program execution to the point, where the scattering object was

called.



Fig. SCA201 Screen for selecting type of the scattering object.
2.2 Forward Distance of the sheet or the wire (Fwd)

The forward distance of the scattering object is the distance between the midpoint of the object and the antenna array measured along the centreline.

NOTE: If the entered distance is zero the entry is cancelled.



Fig. SCA202



Fig. SCA203 Data entry screen for FWD of the scattering wire

2.3 Sideways Distance (Sdw)

The sideways distance of the scattering object is the lateral distance between the midpoint of the object and the array centreline. Positive value means that the sheet is situated on the "FLY LEFT"-side (150Hz) from the centreline and the negative value represent the "FLY RIGHT"-side.



Fig. SCA204 Help screen for the sideways distance.

Data entry screen for FWD of the scattering sheet

2.4 Length of the sheet or the wire (Lgt)

The default value of the length is 10 m for the sheet and 100m for the wire.

Length of sheet	
(Alt-2) E	nter scatter objects from list
	← Length →
TT	1 L L L L L L L L L L L L L L L L L L L
	Reflecting sheet

Fig. SCA205 Help screen for the length of the reflecting sheet.

If the sheet is a tailfin or fuselage, use "Alt-2" to select sizes for known aircrafts. When fuselage and tailfin are choses as a pair, the offset distance (in meters) of the fuselage is shown as FU-xx.

Length	→	

Fig. SCA206 Help screen for the length of the scattering wire.

2.5 Height of the sheet or diameter of the wire (Hgt)

The default height is 10 m for the sheet, and diameter of each wire is 0.01m.

Height of she	et	
	↑ Height	
TT		
	Reflecting	g sheet

Fig. SCA207 Help screen for the height of the reflecting object.



Fig. SCA208 Help screen for the height of the reflecting object.

2.6 Bottom Height of the sheet or the wire (Btm-Hgt)

The bottom heigth of the scattering object. Default value is zero, meaning the object stays on the ground. In case of simulating the aircraft tailfins or the beam of the building crane the sheet should be lifted from the ground by setting the bottom height accordingly.



Fig. SCA209 Help screen for the bottom height of the object.



Fig. SCA210Help screen for the height of wire above ground.NOTE:Btm-Hgt cannot be set to a lower value than zero meaning the object
base is on the ground.

2.7 Rotation Angle (Rot)

The rotation angle of the scattering object is the horizontal angle between the object and the centreline. The clockwise rotation is entered as a positive value and the negative value represents the counterclockwise rotation according to geographical directions.



Fig. SCA211 Help screen for the rotation angle.

2.8 Tilt angle of the sheet or number of wires (Tilt)

The tilt angle parameter is presenting the vertical angle in the case of sheet and in the case of wire the number of wires is entered.

The tilt angle of the scattering sheet is the vertical angle between the object and the perpendicular to the ground. Positive tilt if the top is tilted towards the 90Hz side when the rotation angle is 0° .



Fig. SCA212 Help screen for the tilt angle.



Fig. SCA213 Help screen for the number of wires.

2.9 Reflection Factor

The reflection factor is the ratio between incident and reflected rf-signal. The factor depends on the material of the object. Generally, the better conductivity and smoothness of the material the higher factor should be used.



Fig. SCA214 Help screen for the reflection factor.

A metallic grid with mesh width smaller than 0.1 wave lengths (0.3m) can be a continuous surface. For wider grid or uneven surfaces made of concrete or glass, the reflection factor could be set between $0.5 \dots 0.1$.

Tailfins and fuselages

A tailfin or fuselage can be selected for some preset aircraft using "Alt-2" and PgUp or PgDn keys, where the length, height and bottom height are shown in the window. After each tailfin, a fuselage for the same aircraft follows. If both are loaded, the fuselage must be offset with xx meters, given in the window.



Fig. SCA215 Tailfins and fuselage for some preset aircrafts.

The file containing these dimensions are found in the SCATT.EN file in the AXIS directory. This file can be edited using a Notebook editor, as it has the format of a TXT file. Be careful to align all decimal points in the three columns.

3. Editing Objects

If there are object(s) in the system a list of the present objects will be displayed. At the bottom is shown the commands of the editor.

<date></date>	AXI	S 110 -	ILS LOO	ALISER	SIMULATOF	R (S∠N:	047)	<time></time>
List of s	scatter ob	jects		Offse	t all she	ets		(Alt-F8
0bj Type 1: (S) 2: (S)	Fwd 411.0 - 481.0 -	<mark>Sdw</mark> 322.0 247.0	<mark>Lgt</mark> 50.0m 45.7m	<mark>Hgt∕d</mark> 1.8m 1.5m	Btm-Hgt 26.5m 23.2m	Rot -16.0° -11.0°	Tilt∕# 0.0° 0.0°	Rf1 0.50 0.50

Fig. SCA301 The screen of the Scattering Object Editor.

3.1 Modify Data

To modify any data of the object, use the arrow keys to highlight the data and use <PgUp>, <PgDn> or <Ins>, keys to change the value of the data in the same way as in the Control Panel.

3.2 Commands

There are six commands for the list:

(1) Copy	add a new object.
(2) Add	copy the highlighted object.
(3) Delete	erase the highlighted object.
(4) Delete all	remove all objects.
(5) Sort	sort the objects
<cr> CTRL Panel</cr>	exit

3.2.1 (1) Copy

Copy command is used to copy the highlighted scattering object. This is a quick way to add another similar object to the model. After copying, adjust the necessary parameters such as forward and sideways distances and then Sort the objects (5) in the end.

3.2.2 (2) Add

Add command is used to add one more scattering object. When this command is executed, the program jumps to the data entry as described earlier.

3.2.3 (3) Delete

Delete command is used to delete one object from the present object list. Before executing this command move the cursor up or down to the row that will be deleted. Then hit the <3> key and the line will be deleted.

NOTE: After deletion there is no fast way to restore the object.

3.2.4 (4) Delete all

Remove command will remove ALL OBJECTS without WARNING.

3.2.5 (5) Sort

Sort command is used to put the present object list in the forward distance order. NOTE: Sorting is done automatically when entering the scattering object.

3.2.6 <CR> CTRL Panel

Pressing the <Enter> key it will terminate the editor and the AXIS110J will return to the location where it was activated.

3.2.7 Offset sheets together.

A quick way to move combined sheets is using these keys when having the graph on screen. The keystrokes move the objects instantly.



Holding the Alt key:

- U and I will shift the position in forward direction. ٠
- H and K will shift the position in sideways direction
- B and N will shift the height ٠
- J will display the offset coordinates ٠

Alt-0 (zero) will cancel the offset.

Fig. SCA 302 The keystrokes to be used for moving combined sheets together.

SCA-7

4. Modeling a tailfin

To model a tailfin, a tapered one, into a rectangular plate, a few things should be considered.

The incoming signal strength increases along the height of the tailfin due to the lobing of the horizontal polarized ILS signal.

The scattered field at the upper part of the tailfin will yield lower lobes than the rest of the fin, radiating a stronger field in low elevation angles.

This creates a double effect, where the received scattered field at low angles will increase with the tailfin height in the power of between 2 and 3. It is therefore more important to emulate the upper part of the tailfin than the lower part.

The plate model (sheet) should therefore be made according to figure SCA401. The plate model should have the same height as the tailfin, but the width should be determined at about 2/3 of the tailfin height.





PLY Playback Screen files

Table of Content

1. Description
2. Command Screen
2.1. Show directory quick selection
2.2. Start show
2.3. Screen files deletion
2.4. Set your own show directory
25.Make directory label
2.6. Make a new show directory
2.7. Exit
3. Speed Control of the slide show
•

AXIS 110 ©NANCO Software

					•			•	•	•									•	• •							•	•	•	•																1
	_				_		_												_	_								_		_													_	_		2
				•				•	•									1		•																Ì	•						•			2
•	•	• •	•	•	•	• •	•	•	•	•	• •	•	•	•	•	• •	•	•	•	• •	• •	• •	•	•	•	•	•	•	•	•	•	• •	• •	• •	•	•	•	• •	•	•	•	• •	•	•	•	S
																																														3
																																														Λ
•	•		•	•	•	• •	•	•	•	•	• •		•	•	•	• •		•	•	• •	• •		•	•	•	•	•	•	•	•		•	• •	•	•	•	•	• •	1	•	•	• •	•	•	• •	-
																																														4
			_		_					_																2	4																			
•	•	• •	•	•	•	•••	•	•	•	•	•••	•	•	•	•	•••	•	•	•	•	•••	• •		•	•	4	4	•																	,	_
•	•	•••		•	-			•	•	-	•••		•	•	•	•••		•	•		•••		-	•	•	-	4		•	-							-				-			•	5	5
•	•	•••	•	•	•		•	•	•	•	• •		•	•	•	••	•	•	•	• •	•••	•••	•	•	•		4	•	•	•	•	• •	•••			•	•		•	•			-	•	5	5
•	•	• •	•	•	•		•	•	•	•	• •		•	•	•	•••	•	•	•	•••	•••	• •	•	•	•		4 •	•	•	•	•	• •	• •		•	•	-		•	•	•	• •	•	•	5	5
•	•	•••	•	•	•		•	•	•	-	•••		•	•	•	•••		•	•		•••	•••	•	•	•	- - -	4	•	-	-	-	•••	•••		•	•			•	•	-	•••	•	•		5 5 5
•	•		-	•	-		•	•	•	-	• •		•	•	•	• • • •		•	•		•••	•••	•	•	•	-	4	•	-	-	-	•••	•••		-	•			•	•	-		•	•		5556
•	-	• •	-		-		-		•	-	•••	-	- - -		•	 	-		- - -	• · • ·	• • • •	• •	-			2	4	•	-	-	-	•••	•••		-	•			•	•	-		-	•		5 5 5 6

1.Description

Playback Screen files option is used to show previously computed and saved graph screens in Black & White.

After a number of graphic screens have been saved on the disk, they can be seen like a slide show by this Playback option.

By computing and saving several screens with increasing change in a feed or mechanical parameter, one gets a useful animation tool for showing the total impact of gradually increasing errors when they are replayed as a movie. It can also be used to show the difference between two or more very close looking graphs to compare the impact of a new parameter. Use the PgUp/PgDn keys to switch between the graphs.

When the graphic screen is selected Black & White, the <4> Save function is enabled allowing to save the screen as a file on the disk to the selected directory. The files will be named AXL0.BAS, AXL1.BAS, AXL2.BAS etc. automatically. The default directory is "SHOW\".

When the playback is started by the "<2> Show" command, all screen files of the selected directory will be played back in the same order as saved. The show will repeat displaying the screen files from the first to the last one until any key is hit.

AXIS 110 ©NANCO

2.Command Screen

Before starting the playback screen show you may select another directory for the screen files.

Note: The chosen directory remains selected as long as you run the AXIS 110 and all saved graphic screens will be saved to this directory.

There are eight commands available in the Command Screen of the Playback Screen files:

- 1. PgUp/PgDn Show directory quick selection
- 2. <2>Show Start show.
- 3. <4>Delete all Screen files deletion.
- 4. <5>Other directory Set your own show directory
- 6. <7>Description Write your own directory label
- 7. <8>Make directory Make a new directory
- 8. <CR>Return Exit

<Date> AXIS 110 - ILS LOCALISER SIMULATOR (S/N:000) <Time>

Playback Screen files

Show directories: Select by PgUp/PgDn

Files directory => SHOW\

(F7) Description Default Directory

(F2)Show (F4)Delete all (F5)New directory (F6)To DOS (CR)Return

Fig. PLY201 Playback Screen files command screen

2.1. Show directory quick selection

Show directories: PgUp/PgDn

Using the keys <PgUp> and <PgDn> can scroll directories from SHOW1\ through SHOW50\.

If the selected directory does not exist a warning will aks you to create it by pressing the (8)key.

<date></date>	AXIS	110 -	I LS	LOCAL
Playback Sc	reen fi	les		
Show direct	ories:	Select	by 1	Palln∕P
Files direc	tory	=> SI	HOW8	N .
(F7) Descri	ption		his (direct

(F2)Show (F4)Delete all (F5)New d

Fig. PLY202 The selected directory does not exist

2.2. Start show

(2) Show

When a directory is selected the show can be started by the <2> key. If the first screen file (AXL0.BAS) does not exist in the selected directory, the user is warned of "No Files" and the AXIS 110 will return to the Main menu.

AXIS 110 - ILS LOCAL <Date>

: SHOW8N Files directory No screen files available...

hit any key...

Fig. PLY203 There are no screen files in the selected directory

AXIS 110 ©NANCO

Software

ISER	SIMULATO	R (S∕N:	000)	<time></time>	
gDn					
ory (does not e	exist -	(F8) to	make	
irect	tory (F6)	To DOS	<cr>Re</cr>	turn	

SEW STUDIATON (25/M-000) /// ///

2.3. Screen files deletion

(4) Delete all

This command is used to delete all screen files and the directory label in the selected directory. Before deletion the directory content is displayed and the AXIS 110 will ask

Are you sure (Y/N) ?

Pressing the <Y> key the deletion will take place. Any other key will return the program to the Main menu.

Note: This command will delete only the screen files and labels for the AXIS 110 (AXLnn.BAS).

<1	Date>	AXIS	110 - ILS	LOCALISER	SIMULATO	R (S∕N:	000>	<time></time>
Are You	ı Sure (Y∕N)?						
AXLØ AXL14 AXL2 AXL7 AXL12 399933	.BAS .BAS .BAS .BAS .BAS .BAS 344 Bytes f	AXL1 AXL15 AXL3 AXL8 AXL8 AXL6 ree	- BAS - BAS - BAS - BAS - BAS - BAS	AXL11 AXL16 AXL4 AXL9	. BAS . BAS . BAS . BAS . BAS	AXL13 AXL17 AXL5 AXL10	- BAS - BAS - BAS - BAS - BAS	

Fig. PLY204 Deletion of the screen files

2.4. Set your own show directory

(5) New directory

This command is use to select the user's screen files directory.

The user is asked to enter a name of directory as follows

Enter new directory <CR>=Default ->

Type the name of your directory and press <Enter>. If just <Enter> is pressed the AXIS 110 will set the default screen files directory as "SHOW\".

Note: If the directory does not exist, it can be created by the <8> key.

2.5. Make directory label

(7) Description

Any directory may have an optional label containing a 21 character description of the saved files. This could be a specific airport name or anything that will remain the user of the content. The label text can be changed anytime by using the (7) key and typing the new text. This label will be deleted if all files are deleted by the (4) key.

2.6. Make a new show directory

(8) Make directory

When a non existing directory name has been selected, a warning will be shown. Use the (8) key to create this directory. If not created the directory name will automatically be set to "SHOW\".

2.7.Exit

<CR>Return

Press <Enter> to return to the Main menu.

AXIS 110 ©NANCO

Software

3. Speed Control of the slide show

While the slide show is running you can adjust the speed by using the - or + keys. On the left hand side of the screen you can see \pm sign which is as a simple speed-gauge. The higher the position, the faster the speed. Default speed is maximum so the \pm sign is shown in the highest position.

Any other key will freeze the display and at the bottom of screen will appear the help row.

In the freezed state you can

- look at each screen by stepping the <PgUp> or <PgDn> keys
- invert the screen by the <l> key for screen capture etc.
- quit the playback show by the <Esc> key.

Any other key will continue the show.



Usage: ± Speed [PgUp]Step Back [PgDn]Step Ahead (F2)Invert (F10)Quit

Fig. PLY301 The screen with help row at the bottom when the slide show is stopped.

Table of Content

1.	Description
2.	Data Screen
	2.1 Numeric data (1)
	2.2 Toggles (2)
	2.3 Commands (3)
3.	The Data entry
	3.1 The range to circle
	3.2 Level
	3.3 Start angle
	3.4 Stop angle
	3.5 Angle step
	3.6 Receiver speed
	3.7 Scale Center line
	3.8 Graph text
4.	Toggles
	4.1 (A)mplitude
	4.2 (D)isplay
	4.3 (E)rase
	4.4 (I)ncr x
	4.5 (P)arameter
	4.6 (M)ultiple
	4.7 (R)eceiver
	4.8 (C)rs / Clr
5.	Commands
	5.1 (2)Change
	5.2 (3)Text
	5.3 (4)FSD
	5.4 (6)Excel
	5.5 (Esc)Menu
	5.6 <cr>Continue</cr>
6.	Table Output
7.	Graphic Display
	7.1 The Graphic diagrams
	7.1.1 CDI-diagram
	7.1.2 Amplitude Diagram
	7.1.3 Phase Diagram

ORB Orbit Cross Over Mode

•				•	•					•	•	•	•	•	•	•	•	•	•	•	•	•			•	• •					•	•	•	•				•	•									1	
																																																2	,
					_																		_	_										_					_				_	_				2	
											•											•									•	•															•	ר כ	2
•		•	•	•	•	• •		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•			•	•			•	•	•	•	•	•	• •	•	•	•	•		•••	•			• •	•	•	с 2	,
•	• •	•	•	•	•	• •	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •	•	•	•	•	•	•	•	• •	•	•	•	•	• •	•	•	•	•	• •	•	•	ں ۸)
• •	• •	•	•	•	•	• •	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •	• •	•	•	•	•	•	•	•	• •	•	•	•	•	• •	•••	•	•	•	• •	•	•	4	•
•	• •	•	•	•	•	• •	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •	• •	• •	•	•	•	•	•	•	• •	•	•	•	•	• •	•••	•	•	•	• •	•	•	4	
•	• •	•	•	•	•	• •		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •	• •	• •	• •	•	•	•	•	•	• •	•	•	•	• •	• •	• •	•	•	•	• •	•	•	5	
•					•					•	•	•	•	•	•	•	•	•	•	•	•	•			•	• •						•	•	•				•	•								•	5	
																																																5)
																																																5	,
																						•									•															-	•	5	
•		•	•	•	•			•		•	•	•	•	•	•	•	•	•	•	•	•	•			•	•			•		•	•	•	•		•	•	•	•			•			•••	•	•	5	
• •	• •	•	•	•	•	• •		•		•	•	•	•	•	•	•	•	•	•	•	•	•			•	•			•		•	•	•	•	• •	•	•	•	•		•••	1	1		• •	•	•	5	,
• •	• •	•	•	•	•	• •	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •	• •	•	•	•	•	•	•	•	• •	•	•	•	•	• •	•••	•	•	•	• •	•	•	с С	
•	• •	•	•	•	•	• •	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •	• •	•	• •	•	•	•	•	•	• •	•	•	•	•	• •	•••	•	•	•	• •	•	•	6)
•	• •	•	•	•	•	• •		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •	• •		• •	•	•	•	•	•	• •	•	•	•	•		•••	•	•		• •	•	•	6	į
•••			•	•	•	• •		•		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •					•	•	•	•	• •	•	•	•	•		•••	•	•	•	• •	•	•	6	,
•					•															•	•												•	•														6)
																																																6	í
_				_						_																					_			_													_	6	
•		•	•	•	•			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•			•	•			•	•	•	•	•	•		•	•	•	•			•				•	•	7	,
•	• •	•	•	•	•	• •		•		•	•	•	•	•	•	•	•	•	•	•	•	•			•	•			•••		•	•	•	•	• •	•	•	•	•		•••	•			• •	•	•	' 7	,
• •	• •	•	•	•	•	• •	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •	•	•••	•	•	•	•	•	• •	•	•	•	•	• •	•••	•	•	•	• •	•	•	7	,
• •	• •	•	•	•	•	• •	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •	•	•	•	•	•	•	•	• •	•	•	•	•	• •	•••	•	•	•	• •	•	•	1	
•	• •	•	•	•	•	• •	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •	• •	• •	• •	•	•	•	•	•	• •	•	•	•	•	• •	•••	•	•	•	• •	•	•	8	;
•••	• •	•	•	•	•	• •		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •	• •		• •	•	•	•	•	•	• •	•	•	•	•	• •	• •	•	•	•	• •	8	8		
•					•					•	•	•	•	•	•	•	•	•	•	•	•	•				• •						•	•	•				•	• •								8		
																																															8		
_				_	_					_											_	_				_								_					_								8		
•				•	•					•	•										•	•									•	•	•	•			•										ر ۶	2	
•		•	•	•	•	• •		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•			•	•				•	•	•	•	•	• •	•	•	•	•			1	1		•••	•	Ċ	, 0	
• •	• •	•	•	•	•	• •	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •	•	•	•	•	•	•	•	• •	•	•	•	•	• •	•••	•	•	•	• •	•	•	0	'
• •	• •	•	•	•	•	• •	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •	• •	•	• •	•	•	•	•	•	• •	•	•	•	•	• •	•••	•	•	•	• •	•	•	9	
•	• •	•	•	•	•	• •	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •	• •	•	• •	•	•	•	•	•	• •	•	•	•	•	• •	•••	•	•	•	• •	•	1	0)
•	• •	•	•	•	•	• •		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •	• •	• •	•	•	•	•	•	•	• •	•	•	•	•	• •	• •	•	•	•	• •		1	0	
•		•	•	•	•	• •		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		• •			•	•	•	•	•	•	• •	•		•	•	• •		•	•	•			1	0	
•																																															1	2	,
																																															1	3	5

7.2 Functions	;
7.2.1 (B)lack & White to Colour Selector	
7.2.2 (I)nvert the display	
7.2.3 (3) Printout	
7.2.4.(4) Graph Saver14	
7.2.5 (8) Scattering Object Editor 14	ŀ
7.2.6 (8) Offset all Scattering Sheets together 14	ŀ
7.2.7 Curve Tracer	;
7.2.8 Add clearance	;

1.Description

The Orbit Mode simulates a circular movement in a given sector across the course line at a defined distance from the antenna system.



Fig. ORB101 The Orbit mode

With the Orbit Mode you can study different parameters like CDI (or DDM), SBO and CSB amplitude and phases as well as the Beam Bend Potential.

AXIS 110 ©NANCO Software



2. Data Screen

The Data Screen is divided into three main parts

- 1. The numeric data
- 2. The toggles and
- 3. The commands.



(-(F10) Playback Screen files: (SHOW\)

<CR> ->

Fig. ORB201 The Data Screen of the Orbit mode

2.1 Numeric data (1)

The numeric data include the parameters used for the orbit computation

Range to circle	Distance from the antenna array to the orbit
Level	The height of the orbit (only in 3D mode)
Min. Az angle	The start azimuth angle
Max Az angle	The stop azimuth angle
Increment	The step or increments along the orbit.
Receiver speed	The speed of the aircraft / receiver in knots.
Scale Center	The graph display center in uA or %DDM.
Full Scale	The graph display full display in \pm uA or %DDM.
Screen text	The text line displayed on the graph screen

2.2 Toggles (2)

The toggles	includes the settings for the
(A)mplitude	Selection betwee
(D) isplay	Selection betwee
(E) rase	Selection betwee
(I)ncr x	Select the step in
(P)arameter	Selection for the
(M)ultiple	Selection for mu
(R)eceiver	Select receiver type
(C)rs/Clr	Selection for Cou

2.3 Commands (3)

The commands in	clude utilities for da
(2)Change	Activate the nur
(3)Text	Entry for the tex
(4)FSD	Entry for the Y-s
(6)Excel	Enables an Exc
	Note: This com
	(D)isplay toggle
(Esc)Menu	Return to main
<cr>Continue</cr>	Starts the orbit

Orbit Cross Over Mode

- the output form of the computation en % and dB en graph and table en old and new data
- increment
- displayed parameter
- ulti radius orbits

ourse or Clearance

lata entry and software control imeric data entry xt line to be shown on the graph -scale setting (Full Scale Deflection). cel readable file to be generated nmand is seen and enabled only when the is selected for TABL. menu computation

ORB-3

3. The Data entry

The data entry is started by <2> change command. It allows changing one or more items.

3.1 The range to circle

Range to circle (2-> m) < 6>: (11112m)
(3) Multiple runs

The range represents the radius of the orbit where the center point is in the middle of antenna array.

This input allows to run up to 6 orbits at user-specified distances.

The default value is one run at a distance of 6NM (11112m). Press "2" to change unit from Nautical Mile (NM) to meters (or feet).

If multiple orbits is wanted press <3> and enter the number of runs and after that the range (radius) of each run. The default level of each orbit is corresponding to an aircraft on a 3° glide path angle along an approach.

<date></date>	AXIS	110	- ILS	LOCALIS	SER	SIMU	LATOR	(\$/N:047)	<time></time>
Orbit Cross	_Over								
Range to ci	rcle	(F2 -)	> m>	<	6	> :		(F3)Multiple	runs
Number of r Range to ci	uns (1 rcle	- 6) (m)	<	11112>	. '	(1)	: 3		
Range to ci	rcle	(m)	<	11112>	: •	4000			
Range to ci	rc le	(m)	<	4000>	: :	2000			

Fig. ORB301 Data Entry for multiple range of orbit



Fig. ORB302 Data Entry in the Orbit mode.

3.2 Level

<444>: Level (m)

(Only in 3D mode) The level is a barometric altitude in meters above the ground level at the antenna system. The default level is the aircrafts height if following a 3° glide path angle down to the threshold. The height f 444m correspons to a distance of 11112m (6NM). The earth curvature is taken into account.

3.3 Start angle

(°) Min. AZ angle

The start angle of the orbit is called minimum azimuth angle and measured from the array center in degrees. The default value is -50°.

3.4 Stop angle

Max AZ angle (°) < 50>:

The stop angle of the orbit run is called maximum azimuth angle is measured from the array center in degrees. The default value is 50°.

3.5 Angle step

Increment (°) <0.50>:

The angle step increments to be used in the calculations. The default value is 0.5 °. Use a smaller value (Press the I-key on the toggle panel) if reflection objects are present. The increment should some times be changed as there may be an interference with the increment and the bend frequency creating strange oscillating variations.

The total number of plots is limited to the remaining free memory and should normally be kept to less than 400.

3.6 Receiver speed

Receiver speed (kts)

The aircraft speed combined with the receiver/plotter frequency response will influence on the smoothening of the curve. Low Pass filter time delay will also yield a sideways shift of the course line and the sectors.

See appendix A1 for details on the low pass filtering effect.

3.7 Scale Center line

Graph Scale Center line (uA) <0>:

The Scale Center line is the value of the center line of the graphic screen. The default value is 0.

3.8 Graph text

Description Enter new Text

Allows to enter the text that should go along with the graph.

AXIS 110 ©NANCO Software

<-50>:

< 0>:

old text

4. Toggles

The toggles will change some computing output settings.

Press the key shown in brackets to execute the function.

4.1 d(B) or %

Toggles the amplitude scale between % and dB.

% Linear scale

dB Logarithmic scale 10dB/div.

4.2 (D)isplay

Selects between graph and table output.

TABL Table output

GRAPH Graph output

4.3 (E)rase

This toggle will erase an earlier calculated data from the memory

- OK means there are no DATA from the last computation area in the memory. A new curve may now be computed.
- DATA means the memory still contains the last results, and the curve may be displayed again with altered full scale deflection (FSD) or another parameter.
- Note: You cannot restore erased data.

4.4 (I)ncr x

Reduce the increment of the current one in order to increase the resolution. Use this toggle when there are short bends on the curve.

- 1 Increment step is as set
- $1/_{2}$ Increment step is reduced by 2 (double resolution)
- $1/_{4}$ Increment step is reduced by 4 (quadruple resolution)

4.5 (P)arameter

Selects the displayed parameter like CDI, Amplitudes (CSB, SBO), Beam Bend Potential and Phase.

The simulator works normally in 2-dimensional mode where the antenna heights above ground are not considered. When reflection objects are present, the vertical radiation diagram is important, and the simulator will automatically be set to 3-dimensional mode.

When showing amplitudes, the levels are referred to the peak CSB level at the course line, which is set to 100% in the 2D mode. However, in 3D mode, the amplitude levels are depending on the height of the receiver due to the vertical lobing factor. It is recommended to use the dB scale for amplitudes whenever in 3D mode.

CDI The CDI/DDM diagram shows sectors, course line, linearity, clearance and false courses. Use the Left/Right arrow keys to bring a cursor along the curve. In the upper left-hand part of the

	screen, the current azi
	cursor position are disp
	In 2D mode the Beam
	order to examine syste
CDI+	SDMCDI/DDM and SDM cu
	0CDI line. Read SDM
	by using arrow keys <l< td=""></l<>
Amp	I Shows the SBO and the
CSB	Shows the CSB curve.
SBO	Shows the SBO curve.
bbp	Shows Beam Bend Po
BBP	Shows magnified Bear
	(20*SBO)
PHA	Phase curves show the
	orbit. Normally the curv
	180° of jumps.
Note:	Ampl, CSB and SBO param
	dual frequency systems.

4.6 (M)ultiple

Selects the output between single or multi range orbit.

Use the <3> key first time a multiple curve diagram shall be computed.

(2)	There is only one rang
YES	Multi range orbits will
NO	Only one orbit is seen
	Note: If many rar

4.7 (R)eceiver

Selects the type of receiver in the CDI/DDM processing. Some modern receivers will divide the received DDM with the MOD SUM (SDM) in order to compensate if the ILS modulator on ground changes its SDM. This algorithm may yield low DDMs in some portions of the azimuth coverage.

Theoretic	DDM is computed
	approach infinite.
Perfect	Ideal receiver. DD
BEND 34A	Bendix RIA 34AF.
COLL 700	Collins ILS 700
COLL 720	Collins ILS 720, sa

4.8 (C)rs / Clr

Selects the output between Course and Clearance. This toggle is only shown when a dual frequency system is selected.

CRS	Course selected
CLR	Clearance selected.

AXIS 110 ©NANCO Software

Orbit Cross Over Mode

- imuth angle and the CDI/DDM value for the played.
- Bend Potential (BBP) is also displayed in ems for sensitive areas.
- urves together. SDM will be 40% along the values in azimuth direction with the cursor Left/Right>.
- ne CSB curves together.

otential with 100% as full scale (2*SBO) m Bend Potential with 10% as full scale

e SBO/CSB phase relationship along the ve is not continuous but makes a number of

neters will also show clearance curves for

- If more than one curve was selected in the previous calculation, make the next calculation multiple by the <M> key. Otherwise only one curve will be computed.

 - ge entered. be displayed

If many range are loaded the first radius will be seen.

ed directly from SBO and CSB. Values may

DDM is limited to 40% (MOD SUM).

same as Bendix RIA 35

5. Commands

5.1 (2)Change

The change command allows to change the numeric data values

5.2 (3)Text

This command enables a quick entry for a text row displayed on graph.

5.3 (4)FSD

[FSD: (±) 800, 400, 200, 100, 50, 25, 12, 6 (uA)]

The default value in the Orbit mode is ±800uA for the full vertical scale, but can be changed to any indicated values. Move the cursor with <Left-Arrow> and <Right-Arrow> keys and press <Enter>.

5.4 (6)Excel

This command enables an Excel format file to be saved with the computed data.

Note: The (D)isplay toggle must be selected as a TABL in order to invoke this function.

5.5 (Esc)Menu

Return to Main menu.

5.6 <CR>Continue

Press <Enter> to start the computation.

6. Table Output

The Table output gives the list of deviation with all the signal amplitudes and phases. The last columns with clearance signals are only filled when a dual frequency is used.

If the Display-toggle is selected as a TABL the computed results will be displayed as a list of the computed values. This will also enable an Excel readable file to be saved on the disk if the (6) command key is pressed.

Before the execution of the list it is asked if the user want to take the results to the printer.

Hardcopy of Results ? (y) or <SPACE>

Enter Y (or another letter if the language is not English) if the results should be printed out.

The display will stop while the screen is full and the user is asked to hit any key to continue. That will be repeated as long as the all computed results are shown.

The list includes the following parameters:

(x)	Azimuth an
DDM(%) /CDI (uA)	Course dev
SDM(%)	Sum of Dep
CSB	Course CS
SBO	Course SB
Phase	Course Pha
C-DDM(%) / C-CDI(u	A) Cleara
C-CSB	Clearance
C-SBO	Clearance
C-Phase	Clearance

<pre> <date></date></pre>		AXIS	110 - I	LS LOC	ALISER S	IMULATOR	<s n:00<="" th=""><th>0)</th><th><time></time></th></s>	0)	<time></time>
whit Chose	Ουργ								
(x)	DDM (%)	SDMC2) CSB	SBO	Phase	C-DDM (2)	C-CSB	C-SBO	C-Phase
-7.50	29.1	40.0	0.9	3.8	163.1°	291.0	146.4	21.3	0.0°
-7.00	29.7	40.0	8.4	3.4	5.20	295.3	136.8	20.2	0.0°
-6.50	29.7	40.0	13.7	0.9	66.0°	299.9	127.0	19.0	0.0°
-6.00	29.7	40.0	9.1	6.2	134.9°	304.7	116.9	17.8	0.1°
-5.50	34.8	40.0	19.2	15.8	20.1°	309.3	106.9	16.5	0.1°
-5.00	49.2	49.2	69.5	28.1	6.5°	313.2	97.1	15.2	0.1°
-4.50	48.5	48.5	152.1	42.0	3.6°	315.8	87.6	13.8	0.1°
-4.00	40.9	40.9	268.5	56.0	2.5°	315.8	78.5	12.4	Ø.2°
-3.50	32.6	40.0	416.5	68.0	1.9°	311.8	70.2	10.9	0.2°
-3.00	25.9	40.0	589.0	76.0	1.6°	301.7	62.6	9.4	0.3°
-2.50	20.3	40.0	774.6	78.5	1.4°	282.9	56.0	7.9	0.4°
-2.00	15.6	40.0	958.7	74.4	1.2°	252.8	50.4	6.4	0.4°
-1.50	11.3	40.0	1124.8	63.5	1.10	208.8	45.9	4.8	0.5°
-1.00	7.4	40.0	1257.1	46.3	1.1°	150.2	42.6	3.2	0.5°
-0.50	3.6	40.0	1342.4	24.4	1.0°	78.9	40.7	1.6	0.6°
0.00	0.0	40.0	1371.8	0.0	188.6°	-0.0	40.0	0.0	172.70
0.50	-3.6	40.0	1342.4	24.4	181.0°	-78.9	40.7	1.6	180.6°
hit any	key								

Fig. ORB601 The typical screen for table display results of the orbit mode

ngle in degrees

viation in uA or %

pth in Modulation

B-amplitude

. BO-amplitude

ase between CSB and SBO

ance deviation in % or uA

CSB-amplitude

SBO-amplitude

Phase between C-CSB and C-SBO

7. Graphic Display

The result of the orbit calculation is shown in graph when the (D)isplay toggle is selected as GRAPH.

7.1 The Graphic diagrams

The graphic diagrams of the Orbit mode are three main type depending on the toggle (P)arameter:

- 1. CDI-diagram,
- 2. Amplitude diagram and
- 3. Phase diagram.

7.1.1 CDI-diagram

Grid scales and lines

ILS-system for Docum



Fig. ORB701 The CDI-graph scales and grid lines of the Orbit mode

 Vertical scale is displayed as a FSD-value and a Ctr-Value. The plus and minus FULL SCALE DEFLECTION (FSD) measured in CDI or DDM of the entire screen. Normally this is 800uA (80%DDM) with 100uA (10%DDM) for each large tick on the scale. The Center value (Ctr) of the vertical scale. Normally this is 0uA, but it can be set to any value in order to zoom in on certain areas of the curve.

- 2. orbit, normally $\pm 50^{\circ}$.
- 3. ±35°.
- The maximum DDM = CSB MOD SUM (40%/387uA) lines. 4. A "theoretic" receiver may pass these lines but the "perfect" and other emulated types will never exceed this value.
- 5. The frame showing ±75uA and ±150uA at the azimuth angles corresponding to the full and half Course Sector settings on the Control Panel. The Ideal curve should be a straight line between the lower lefthand corner and the upper right-hand corner.

Parameter values



- Fig. ORB702 The readings found in the Orbit graph
- 1. The following set and computed values are found on the graph :
 - @: 10000m (on the left hand upper corner) the distance from the antenna to the lateral orbit plane
 - CL: 0.0uA (on the left hand lower corner) the position of the course line
 - CS: 4.965° (on the right hand lower corner) the course sector angle in degrees.

AXIS 110 ©NANCO Software

For SDM (Sum Depth of Modulation) the center axis (0 CDI) is 40% modulation. Use the cursor <Left/Right> keys to read values. Horizontal scale is the azimuth value of the start and stop point of the

The ICAO limits for minimum DDM in the sectors between CS and

2. The curve show the CDI as a function of azimuth angle. To see the numeric CDI value from a given azimuth angle on the graph use the Left/Right arrow keys to select the desired azimuth angle. Note: Only the computed points on the curve are displayed - intermediate values must be interpolated by the user. In 2D mode the

BBP will also be displayed.

3. The finally computed azimuth angles at CDI values from -150uA to +150uA in 75uA steps (-2.483° through +2.483°).

7.1.2 Amplitude Diagram



(F1)B&W (F2)Invert (F3)Print (F4)Save <-Values-> <SPACE>CLR

Fig. ORB703 A CSB/SBO amplitude diagram at 100m distance

The Amplitude diagram shows the SBO and CSB together. For two frequency systems the clearance signals will be shown by hitting the <SPACE BAR>. The Left/Right keys will bring a cursor along the curve.

In the upper left hand part of the screen, the current azimuth angle, amplitude and BBP are displayed for the cursor position.

Use the <Up/Down> arrow keys to jump to another curve.

To measure the sidelobe level, capture ratios etc., use the dB option for the amplitude. By pressing the "0" (zero) key at a given cursor location, the current amplitude is set to 0 dB as reference. Subsequent measurements are now relative to the chosen point. Repeat the "0" key to toggle off the relative mode.

7.1.3 Phase Diagram

The SBO/CSB RF-phase is an important part of the DDM calculations. It can be visualised by selecting "Phase" from the (P)arameters. In the following case the cursor has been used to measure the computed phase. Move the cursor by the <Left/Right> keys to a reference point an press the "0" (zero key). Then move the cursor along the curve to measure the relative values.



(F1)B&W (F2)Invert (F3)Print (F4)Save <-Values-> <SPACE>CLR

Fig. ORB704 this distance.

7.2 Functions

The functions of the	graph display are
(B)&W	Black&White to C
(I)nvert	Display invert the
(4)Save	Save a B&W gra
(8)Scatter	Scattering Object
<-Values->	Curve Tracer
<space>CLR</space>	Add Clearance

A typical Course phase diagram at 100m distance. Note there is not always a 180° phase shift between the lobes at

> **Colour Selector** e colours for cut&paste purposes aph for later play back t Editor

> > **ORB-13**

7.2.1 (B)lack & White to Colour Selector

(B) &W

This function is used to toggle the graph between colours and black & white.

The key will turn the graph into black background and white lines. Repeat-

ing the key will restore the colour display.

7.2.2 (2) Display Inverter

(I) nvert

This function will invert the colours of the display. In the colour display the colours will be changed to their complementary-ones.

7.2.3 (3) Printout

This function is obsolete and no longer used.

7.2.4. (4) Graph Saver

(4) Save

Note: This function is enabled and displayed only when the screen is selected as black & white.

The Graph Saver is used to save the graphic screen to the disk on a selected SCREEN or SHOW directory. The names of the files will be generated automatically and the first save is named as AXL0.BAS, second AXL1.BAS, third AXG2.BAS and so on. Before saving, go to the Playback Main Menu item and select the wanted directory. See section PLY.

The saving format is the basic-language BSAVE/BLOAD mode enabling the fastest Load and play back in the AXIS 110.

7.2.5 (8) Scattering Object Editor

(8)Scatter

Note: This function is enabled and displayed only when at least one scattering object is entered.

This function starts the scattering object editor in a same way as in Control Panel allowing to modify scattering objects. The detailed description is given in SCA-section.

7.2.6 (8) Offset all Scattering Sheets together

non visible

Offset the positions of all sheets in X(fwd), Y(sdw) and Z(hgt) coordinates together. This is useful when moving a complex object that is built up of several sheets.

7.2.7 Curve Tracer

<- Values ->

This function is used to show the exact value along the curves. The point on the curve is shown with a small square (cursor) and can be moved by using the <Left> or <Right> arrow keys, while the value of the selected parameter and the distance will be displayed in the upper left hand part of the graphic screen.

With <Left> and <Right> arrows the cursor is moving with one computed step increment (selected in data panel) while holding the <Ctrl> key, the steps will be 10 times larger.



Fig. ORB705 The frame shows the azimuth angle, SDM and BBP in μ A and % at the cursor location.

7.2.8 Add clearance

<SPACE>CLR

Press the <Space> if you want to see clearance signals in the same graph.

Note: This function is enabled and displayed only for dual-frequency systems.

For using the cursor to measure the values along the curves, use the <Up/Down> arrow keys to select the wanted curve for side lobe level etc. The following measurement of the capture ratio was done in this way:

1. Move the cursor to the center of the COURSE CSB curve so it stays on the peak.

2. Press "0" (zero) for making relative measurements

3. Use the <Up/Down> keys to move the cursor to the CLR CSB curve. The computed value (19.29dB) can be read in the field shown in the figure ORB 706.



(F1)B&W (F2)Invert (F3)Print (F4)Save <-Values-> <SPACE>CLR

Fig. ORB 706 Using the cursor to measure the computed Capture Ratio (The amplitude ratio between the Course and Clearance CSB signals on the center line).

Table of Contents

1.Description
2.Data Panel
2.1 Numeric data (1)
2.2 Toggles (2)
2.3 Commands (3)
3.Data Entry
3.1 Approach Elevation Angle
3.2 Threshold Distance
3.3 Threshold Crossing height
3.4 Runway Height
3.5 Stop End
3.6 Approach Azimuth Angle
3.7 Approach Start Point
3.8 Approach End Point
3.9 Approach steps
3.10 Receiver Speed
3.11 Receiver Filter
3.12 Graph Centreline
3.13 Textline into the Graphic
4.Toggles
4.1 d(B) or %
4.2 (C)AT Limit
4.3 (D)isplay
4.4 (E)rase
4.5 (G)raph dir
4.6 (I)ncr x
4.7 (X)scale
4.8 (O)rigin Xsc
4.9 (P)arameter
4.10 (S)ense
4.11 (V)iew
4.12 (N)ormalized
5. Commands
5.1 (2) Change
5.2 (3) Text
5.3 (4) FSD
5.4 (6) Excel
5.5 (Esc) Menu
5.6 Continue <cr></cr>

APP Approach mode

 1
 2
 2
 3
 3
 4
 5
 6
 7
 8
 8
 8
 .8
 8
 8
 8
 8

AXIS110J User's Manual

6. Table display	9
7. Graphic Display	10
7.1 Graphic Diagram	10
7.2 Functions	10
7.2.1 Black&White to Colour Selector	11
7.2.2 Display Inverter	11
7.2.3 Printout	11
7.2.4 Graph Saver	11
7.2.5 Scattering Object Editor	11
7.2.6 Curve Tracer	11
1.Description

The Approach Mode simulates a movement along the approach path towards the landing point on the runway and further on to the antenna array.

The approach path follows the given elevation angle until the height of 4m above the runway is reached, passing the threshold at 15m. From this point a constant height of 4 m is maintained. It should be noted that flying out on the backbeam the height will also be 4m. The threshold crossing height (normally15m) and the height above runway (normally 4m) can be changed to other values.



Fig. APP101 Approach mode

The approach mode will show how the course line and sector will change along an approach path for given errors in the antenna array. It will also indicate where and how bends will occur due to one or more scattering objects in the terrain model. In some cases there will be interesting to see how the amplitudes of CSB and SBO will change alobg the flight path.



2.Data Panel

The data panel shows the values to be used in the approach mode.

The data panel consists of three main parts

- 1. the table of numeric data,
- 2. the toggle panel and
- 3. the commands.

Approach on course Er	
	ase Data for new run
 F2) Elevation angle 3.00° Threshold Dist. 3007m Thr. Crossing hgt 15m Height above RWY 4m Stop End distance 300m Theo FWD position 0m Sideways offset 0m Track Azimuth 0.00° (0.0uA) Track Start Dist 11007m (5.9NM L) Track End Dist 1m Increment Step 50m Receiver speed 105kts Receiver filter 2.0rad/s (2.1 @ 105) F72 Scale Center : 0µA F44 Full scale ±: 50µA 	Toggles d(B) or Z (C)at Limit NO (D)isplay GRAPH (E)rase OK (G)raph dir + (I)ncr x 1 (X)-Scale km (O)rigin Xsc THR (P)arameter CDI (S)ense 90† (U)iew R&S (N)ormalize YES

Fig. APP201 The data panel of the approach mode

2.1 Numeric data (1)

The numeric data shows the the values to be used in the computation. The numeric data can be changed by the (2) change command.

Here is a brief description of the table of the numeric data:

Elevation angle	Vertical angle of the approach path
Threshold Dist.	Distance between the LOC-array and the landing
three	shold
Thr. crossing hgt.	The height of the downward extended glidepath above
three	shold
Runway height. The	height of the horisontal portion of the path above the
RW	(
Stop End Dist. Dista	ance between the LOC-array and the runway stop end
Track azimuth Horis	sontal angle of the approach path seen from the array
Start Distance The	start point of the approach from the antenna array
End Distance The	end point of the approach from the antenna array
Increment step The	step distance along the approach
Receiver speed The	speed of the receiver for low pass filtering
Receiver filterTher	eceiver low pass filtering setting as radians/s
Scale center The	scale center of the graph
Full Scale The	full scale of the graph

2.2 Toggles (2)

The toggles are used to make toggle type selections.

The toggle panel in	cludes the following
d(B) or %	Select amplitude
(C)at Limit	Add bend limit lin
(D)isplay	Selection betwee
(E)rase	Erase the old cor
(G)raph dir	The approach dir
(I)ncr x	A reduction facto
(X)-Scale	Select distance s
	the thresolh.
(O) rigin Xsc	Selects Threshol
	the X (distance) s
(P) arameter	Selects the displa
(S)ense	The direction of t
(A) dd	Add Runway and
(N) ormalized	Same amplitude

2.3 Commands (3)

The commands start the function or control the program execution.

(2) Change	Change one or n
(3)Text	Enter text line to
(4) FSD	Change the Y-sc
(6)Excel	Generate an Exc
	Note: This comm (D)isplay toggle i
(Esc)Menu	Return to menu
<cr>Continue</cr>	Starts the Approa

- g toggles:
- es in dB or in % on the graph
- nes to the graph
- en graph and table
- mputed curve from memory
- rection on the graph
- or of the increment step 1/2 or 1/4.
- scale in meters, feet or Nautical Miles from
- Id or the localiser antenna as the origin of scale.
- ayed parameter CDI or Modulus
- the Y-axis of the graph 90Hz up or down
- d scattering objects to the graph
- along the entire flight path
- nore data items
- be displayed with the graph.
- cale (Full Scale Deflection).
- cel readable file
- nand is seen and enabled only when the is selected into the Table

ach mode computation.

3.Data Entry

The numeric data are entered by the (2) command allowing to change one or more items. The present value is always shown between angle brackets. Enter new value from the keyboard or press <Enter> to keep the present value.

<date> AXIS</date>	110 - ILS	LOCALISER	SIMULATOR	(S/N:047)	<time></time>
Approach on course			Eras	e Data for	new run
<pre>(F2)Elevation angle Threshold Dist. Thr. Crossing hgt Height above RWY Stop End distance Theo FWD position Sideways offset Track Azimuth Track Azimuth Track Start Dist Increment Step Receiver speed Receiver filter</pre> (F7)Scale Center : (F4)Full scale ±: (F3)Description	3.00° 3007m 15m 4m 300m 0m 0.00° (11007m (1007m (105kts 2.0rad, 0µA 50µA	0.0uA) 5.9NM L) ⁄s (2.1 (4 ((0) (1) (1) (1) (1) (1) (1) (1) (1) (1) (1	Togg (B) or % (D) at Limit (D) isplay (D) rase (D) raph dir (D) raph dir (D) raph dir (D) raph dir (D) rase (D) rigin % (D) rameter (D)	les NO GRAPH OK t 1 km THR CDI 90† R&S YES

Fig. APP301 The screen for approach data entry

3.1 Approach Elevation Angle

Elevation Angle (°) < 3>:

The default value is 3 degrees. The run follows the Glide path angle down until 4m above the runway passing the threshold at 15m, and from there maintains a constant height of 4m along the runway towards the antenna system.

3.2 Threshold Distance

Threshold Distance (m) < 3006> :

Enter the actual distance from the localiser antennas to the threshold. The preset value is the theoretical value based on the course sector width.

NOTE: If flying out on the backbeam, the height will always be 4 m, or the height selected in 3.4.

3.3 Threshold Crossing Height

Thr. crossing hgt (m) < 15> :

Enter the desired crossing height of the downward extended glide path. This height is normally 15m.

3.4 Runway height

Runway height (m) < 4> :

Enter the desired height above the runway on the horisontal portion of the flight path after passing the threshold. This height is set to 4m as default but can be set to any value less than the threshold crossing height in 3.3.

3.5 Stop End

Stop End d	distance	(m) <
------------	----------	-------

Enter the actual distance from the localiser antennas to the stop end.

3.6 Approach Azimuth Angle

(°) Track azimuth

This is the Azimuth Angle relative to the runway centreline, normally identical to the localiser Courseline of 0 °. Positive angles are in clockwise direction according to the geographical convention.

The Azimuth angle has the reference point at the center of the antenna array.

3.7 Approach Start Point

Start Distance (m)

The beginning of the run masured from the antennas. Default start distances 8 km plus the threshold distance, to include point A at 7408 m (4NM) from THR.

<

3.8 Approach End Point

End Distance (m)

This is the end distance of the approach run. Default is 1m from the antenna array.

<

3.9 Approach steps

Increment Step (m)

<

The decrement distance of the run. Default is 50 m.

This step should be smaller to show bendpatterns with short bendlengths. Use the I-key in the toggle panel to shorten the increment. $\frac{1}{2}$ (25m) or even $\frac{1}{4}$ (12.5m) are better values when reflection objects are present.

<

3.10 Receiver Speed

Receiver speed (kts)

The receiver speed in knots.

3.11 Receiver Filter

Receiver filter (rad/sec)

The receiver frequency response will infuence on the smoothening of the curve. The filter response is normally 2-5 rad/sec. See Appendix A1 for details.

3.12 Graph Centreline

Graph Scale Centreline (uA) <

The center axis of the graph might be offset to the average deviation value at the approach azimuth angle in order to increase the resolution.

Approach Mode

300> :

<

0> :

11006> :

1> :

50> :

105> :

2.0> :

0> :

<

3.13 Textline into the Graphic

Description Enter new Text >:

Enter the text that should go along with the graph.

4.Toggles

The toggles allow quick changes to some of the often used settings. Press the key shown between the brackets to execute the function. If the language is not English, the text and the letter within brackets should be different and the command will respond to the new letter.

4.1 d(B) or %

Select the amplitude graph scales in dB or in %, where 100% is the nominal full value in the two-dimentional space on the center line

NOTE The dB-toggle is only effective in amplitude graphs

4.2 (C)AT Limit

Show the bend limits (95%) for Cat I, II and III

NOTE this toggle will only effect the graph

4.3 (D)isplay

Selection for the display-mode of the computed results.

GRAPH	graphical output
TABL	table output

4.4 (E)rase

Selection for erasing the earlier computed data.

OK	the data in the memory has been erased and a new curve may
	now be computed

DATA the memory still contains the last results, and the curve may be displayed again with altered toggle settings.

4.5 (G)raph dir

Selection for the displayed direction of the graphic curve.

- ← direction will be from right to left (default)
- \rightarrow direction will be from left to right
- NOTE this toggle will only effect the graph

4.6 (I)ncr x

Reduce the increment to 1/2 or 1/4 of the current one in order to increase the resolution when there are short bends on the curve.

Increment is same as set in table of numeric data
 Increment is divided by two representing double resolution
 Increment is divided by four

4.7 (X)scale

Selection for distance measurement unit used in x-scale. Distances on the graph are from the threshold. A top line on the graph shows the distances from the antennas in km, and threshold in both km and NM.

scale is shown in Kilor
scale is shown in Naut
scale is shown in feet
this toggle will only effect the

4.8 (O)rigin Xsc

Toggle start point of the X-scale between the Threshold and the Antenna system.

4.9 (P)arameter

The simulator works normally in 2 dimensional mode where the antenna heights above ground are not taken into account. When reflection objects are present, the vertical radiation diagram is important, and the simulator will automatically be set to 3 dimensional mode.

CDI	The CDI/DDM curv. U
	cursor along the curve
	shows the current dist
Ampl	Shows the SBO and the
CSB	Shows the CSB curve
SBO	Shows the SBO curve.
bbp	Shows Beam Bend Po
BBP	Shows Beam Bend Pot
PHASE	Shows the SBO/CSB p

4.10 (S)ense

Selection for the sense direction.		
90 ↑	Fly Right will be in the	
90↓	Fly Right will be in the I	
NOTE	this toggle will only effect th	

4.11 (V)iew

Show runwa	y, x-scale distance and sc
NO	Nothing added to the g
RWY	Runway is drawn in sca
R&S	Runway and scattering
SCAT	Scattering objects with
NOTE TI	he View-toggle is only effe

meters itical Miles (actually kilofeet)

he graph

e the Left/Right arrow keys to bring a In the upper left hand part of the screen, ance and the CDI/DDM value. In CSB curves together.

otential with 100% as full scale (2*SBO) tential with 10% as full scale (20*SBO) phase relationship along the path.

upper part of the graph lower part of the graph be graph

catter objects to the graph graph

ale

objects are drawn a circle at the center

ective in the graphs

APP-7

4.12 (N)ormalized

Selection how amplitude information should be displayed

- **YES** Curve will have the same amplitude at all distances. Variations is caused by lobing factors or multipath.
- **NO** Curve will show the normal decay due to power dilution at greater distances. This is the actual signal strength variation measureed in practice. The relation between the two curves is E=E*1000/Distance.

5. Commands

5.1 (2) Change

The Change command is used to modify the values of the numeric data used in the computation. See chapter 3 Data Entry of this section.

5.2 (3) Text

Quick command to enter text into the graph.

5.3 (4) FSD

Graph Full Scale Deflection

[FSD: (±) 800, 400, 200, 100, 50, 25, 12, 6 (uA)]

Default value in this mode is ± 50 uA on the full vertical scale, but can be changed to any of the indicated values. Move the cursor with the Left-Right

arrow keys and press <CR>. This setting has no effect when (P)arameter is set to Amplitude, CSB, SBO or Phase.

5.4 (6) Excel

Enables an Excel format file to be saved with the computed data. The data will be delimited by TAB's. Enter the name of the data file including an extension .XL or .txt for the Excel to read it properly.

NOTE: The display toggle must be set to TABL in order to invoke this function.

5.5 (Esc) Menu

Function key <Esc> returns the program execution into the main menu.

5.6 Continue <CR>.

Starts the approach mode calculation.

6. Table display

If the Display-toggle is selected as a TABL the computed results will be showed as a list of the parameter values.

This will also enable an Excel readable file to be saved on the disk if the <6> command key is pressed.

Before the execution of the list it is asked if the user want to take the results to the printer.

Hardcopy of Results ? (y) or <SPACE>

Enter Y (or another letter if the language is not English) if the results should be printed out.

The display will stop while the screen is full and the user is asked to hit any key to continue. That will be repeated as long as the all computed results are shown. The list includes the following parameters:

(x)	Distance from the a
CDI	Course deviation in
CSB	Course CSB-amplit
SBO	Course SBO-amplit
Phase	Course Phase betw
C-CDI	Clearance deviatior
C-CSB	Clearance CSB-am
C-SBO	Clearance SBO-am
C-Phase	Clearance Phase b

	<date></date>		AXIS 1	10 - I	LS LOCAL	ISER SIMULA	TOR (S	/N:000>	<time< td=""></time<>
	_								
Ar	proach on	course	0°						
	(x)	CDI (µA)	CSB	SBO	Phase	CCDI(µA)	C-CSB	C–SBO	C-Phase
	2507.00	-0.3	12.7	0.0	234.30	-38.3	0.8	0.0	228.20
	2457.00	Й.6	13.1	ดิด	11.00	115.7	Й.6	0.0	19.30
	2407 00	-1 Ñ	13.4	ดีดี	155.50	-83.6	1.1	ดีดี	164 30
	2357 00	Å 5	13.8	ดัด	200.30	47 3	à â	0 1	283 50
	2307 00	-1 1	14 1	0.0	112 80	-109 2	1 2	0.1	140 60
	2307.00	5.P	14 5	0.0	200 20	_00.2	A 0	0.1	246.60
	2237.00	0.0	14.5	0.0	400.0	-70.4	0.7	0.1	440.0-
	2207.00	-2.3	14.9	0.0	120.60	-153.7	1.5	0.1	151.6°
	2157.00	U. 9	15.3	0.0	326.20	-333.7	0.5	0.2	236.90
	2107.00	-5.4	15.8	0.0	189.2°	-182.2	2.2	0.2	185.2°
	2057.00	-1.8	16.2	0.0	72.1°	-245.4	1.6	0.3	144.8°
	2007.00	0.6	16.7	0.0	337.20	-572.3	0.9	0.3	201.40
	1957.00	-3.6	17.2	0.0	267.99	-242.2	2.1	0.3	208.80
	1902.00	-5.8	12.2	ดิด	227.50	-205.3	2.6	0 .3	198.40
	1857 00	-4 4	18 3	ดัด	219 20	-182 0	24	0 2	198 20
	1907 00	_1 5	10.0	0.0	240 80	-122.0	1 6	0.1	217 00
	1007.00	-1.5	10.0	0.0	240.0-	-122.3	1.0	0.1	217.J ⁻
	1757.00	-0.6	17.4	9.9	240.6	-63.3	1.4	9.1	220.5
	1707.00	1.0	20.1	0.0	332.80	241.2	0.5	0.1	301.30
	hit any	key to	return.	••					

Fig. APP601 A typical screen for the table display

antenna array in meters

- ιuA
- tude
- tude

ween CSB and SBO

- n in uA
- nplitude
- nplitude
- between C-CSB and C-SBO

e

7. Graphic Display

When the Display-toggle is selected as a GRAF the computed results will be showed as a graphic diagram.

7.1 Graphic Diagram

The graphic diagram includes all information that is set in data panel.

Below the centreline is shown the letters (A, B, C, T) presenting the ILS-points specified in ICAO Annex 10.

Additionally on the bottom row there are six functions available for handling the graph result.

ILS-system for Docum

roach on course El: 3.00°	Az: 0	0.0°	Sdw:	0	m			CDI
			FSD) ±	50µA	Ctr=	0µA	HX15 1.
FLY RIGHT (-)								
								
	,		L					
······	·1/·····	£	3 .,		4		··6·····	
	≪u4f\},	ŶŔZŇŧ	<u>+</u> /	inte.		محدور، ما دب س		. <u></u>
	···· B·····	X	-		· · · · · · · · · · · · · · · · · · ·			••••••A
		·····	·					
			L					
FLY LEFT (+)								
								
			ł		R	X 4.5	rad/s	105kt:

(F1)B&W (F2)Invert (F3)Print (F4)Save (F8)Scatter <-Values->

Fig. APP701 The typical graphic diagram of the approach mode for the CDI parameter with two reflecting objects.

7.2 Functions

The functions of the graph display are

(1)B&W	Black&White to Colour Selector
(2)Invert	Display invert the colours for cut&paste purposes
(4)Save	Save a B&W graph for later play back
(8)Scatter	Scattering Object Editor
<-Values->	Curve Tracer

7.2.1 Black&White to Colour Selector

(B) &W

This function is used to toggle the graph between colour and black&white. The -key will turn the graph into black background and white lines. Repeating the -key will restore the color display.

7.2.2 Display Inverter

(I) nvert

This function will invert the display. It also operates in colour display changing the colours to their complementary ones.

7.2.3 Printout

This function is obsolete and no longer needed.

7.2.4 Graph Saver

(4) Save

The save-function is used to save the graphic screen to the disk on the SCREEN directory. The names of the files will be generated automatically and the first save is named as AXL0.BAS, second AXL1.BAS, third AXL2.BAS and so on.

The saving format is the basic-language BSAVE/BLOAD mode enabling the fastest Load and play back in AXIS110J.

NOTE: black&white.

7.2.5 Scattering Object Editor

(8) Scatter

This function allows you modify the objects. After editing the program will return to the current mode ready for a new computation. Detailed description of this utility is given in the SCA-section.

7.2.6 Curve Tracer

<- Values ->

This function is used to show the exact value along the curves. The point on the curve is shown with a small square (cursor) and can be moved by using the <Left> or <Right> arrow keys, while the value of the selected parameter and the distance will be displayed in the upper left-hand part of the graphic screen.

With <Left> and <Right> arrows the cursor is moving with one computed step increment (selected in data panel) while holding the <Ctrl> key, the steps will be 10 times larger.

This function is enabled only when the screen is selected as

ILS-system for Docum Approach on course El: 3.00° Az: 0.0



(F1)B&W (F2)Invert (F3)Print (F4)Save (F8)Scatter <-Values->

Fig. APP702 Distance and parameter reading of the cursor location.

The curve tracing function includes also the automatic point loader for bend analysing.

This feature is utilized in the following way:

1. Find a maximum, middle or minimum point on a bend section and press the 0 (zero) key. The distance will now read zero because this point is now set as a reference.

After this a further move of the cursor will display the relative distance from the reference point.

- 2. Move the cursor either a full, half or quarter bend cycle and then press
 - 1 (one) for full cycle or
 - 2 (two) for half cycle or

4 (four) for quarter cycle (most accurate)

This will load the bend distance/length combination into the bend analyser module.

3. Make two or three entries repeating 1) and 2) and then return to the MENU (use the <Enter> key and then <Esc>). Select Bend Analysing mode (mode 8) and press <Enter> several times to proceed directly to the graphic display. The crossing of the hyperbolic lines will show where the bends might have their origin.

Table of Contents

1. Description
2. Data Panel
2.1 Data of the position of the point(
2.2 Data of Error (2)
2.3 loggles (3)
2.4 Commands (4)
3. The Data Entry
3.1 Position of the point(s)
3.1.1 Approach Elevation Angle.
3.1.2 Threshold Distance
3.1.3 Forward Distance
3.1.4 Sideways Distance
3.1.5 Height of the Receiving Poin
3.2 Error Source and Type
3.2.1 Error Source
3.2.2 Error Type
3.2.2.1 SBO-signal Error
3.2.2.2 Antenna Element Error
3.3 Error range
3.3.1 Start Value of the Error
3.3.2 End Value of the Error
3.3.3.Increment Step of the Error.
3.3.4 Scale Center
4. Toggles
4.1 (A)mplitude
4.2 (D)isplay
4.3 (E)rase
4.4 (I)ncr x
4.5 (N) Points
4.6 (P)arameter
4.7 (C)rs/Clr
5. Commands
5.1 (2)Change
5.2 (3)Text
5.3 (4)FSD
5.4 (5) Errors
5.5 (6)Excel
5.6 (Esc)Menu
5.7 <cr>Continue</cr>

FIX **Fixed Position mode**

	1
	2
nt(s) (1)	2
	2
	2
	3
	3
	4
	4
· · · · · · · · · · · · · · · · · · ·	1
,	т 4
	4
	5
	5
oint	5
	5
	5
	5
	6
	6
٦r	6
	7
	1
	7
	7
)r	7
	7
	1
	8
	8
	8
	ß
	0
	Ø
	8
	8
	9
4	ں م
· · · · · · · · · · · · · · · · · · ·	U
)
10)
)
10	•
۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰	,
1L	-
1	0
	0

AXIS110J User's Guide

6. Table display	11
7. Graphic Display	12
7.1 Graphic Diagram	12
7.2 Functions	13
7.2.1 Black&White to Colour Selector	13
7.2.2 Display Inverter	13
7.2.3 Printout	13
7.2.4 Graph Saver	13

1.Description

The Fixed Position mode simulates the signals in one or two position while a feed parameter is varied between selected limits. This will demostrate how susceptible the course line and the course sectors will be to errors in the different antenna elements or signal components.

This mode is excellent to compare the far field and near field response to possible errors in the antenna system to examine the monitor and the ground check points sensitivity.



Fig. FIX101 Fix

Fixed Position mode with the far field and the near field points.



2. Data Panel

The data panel is divided into four main parts :

- 1. the data of the position of the fixed points,
- 2. the data of the error simulation
- 3. the toggle panel
- 4. the commands.

<pre></pre>	TOR (S/N:000) <time></time>
Fixed Position	Erase Data for new run
Point No. 1Point No. 2(F2)Forwards10000100Sideways0(0.0°)0(0.0°)Set 3D mode for height settings(F5)Antenna Number6 (- & +)Parameter No.6 (Phase)MIN Error(°) : -90MAX Error(°) : 5(°) : 5(°) : 5(°) : 5(°) Scale Center: 0µA(°) : 50µA(°) : 50µA	Togglesd(B) or %%(D) isplayGRAPH(E) raseOK(I) ncr x1(N) Points2(P) arameterCDI(S) ense901(C) rs/ClrCRS

(-(F10) Playback Screen files: (SHOW\)

<CR> −>

Fig. FIX201 The data panel of the fixed position mode

2.1 Data of the position of the point(s) (1)

The fixed point(s) is detemined by forward, sideways and height position measured from the center of the antenna array.

The value of the numeric data can be changed by (2)Change command.

Point No. 1	Point No. 2
Forward	Forward distance of the point along the centreline
Sideways	Sideways distance of the point
Height	Height of the point (Only in 3D mode)

2.2 Data of Error (2)

Data of error determines the error source, the error type and the error range as well as the size of the error step increment. These values can be entered by <5>Error command.

Antenna Number	Antenna element
Parameter No.	Error source / parameter
MIN Error	Error start value
MAX Error	Error stop value
Incr Step	Error step
Scale Center	Graph display center
Full Scale	Graph display full scale
Description	Text line displayed on graph diagram

2.3 Toggles (3)

The toggles consists of the set of fixed value parameters/settings that can be changed by toggling the key allocated to the toggle (letter inside the

brackets).

(A)mplitude	Selection betwee
(D)isplay	Selection the out
(E)rase	Selection betwee
(I)ncr x	Factor for step va
	resolution
(N) Points	Selection the nur
(P)arameter	Select the display
(C)rs/Clr	Selection betwee

2.4 Commands (4)

The commands are executed by Function keys and are effecting the program execution or allow to enter some numeric data directly.

(2)Change	Change the posi
(3)Text	Enter a text line
(4)FSD	Change the Y-so
(5)Errors	Change the erro
(6)Excel	Enable to save r
(Esc)Menu	Return to main n
<cr>Continue</cr>	Run the fixed po

en percent (%) and decibel (dB) tput form between graph and table en old and new computing result alue to be used to increase the computing

mber of points between one or two lyed parameter en Course and Clearance signals

sition data of the point(s) to be displayed on the graph diagram scale (Full Scale Deflection) or source and error parameters results to the Excel readable file. menu

osition calculation

3. The Data Entry

The data is entered by Function key command allowing you enter all numeric data needed for fixed position computation.

The present value of the data is shown between angle brackets. If you accept the shown value just press <Enter> to go on to the next data entry. Otherwise enter the new value and press <Enter>.

The Data Entry can be divided into four phases

- 1. Position of the points
- 2. Error source and type
- 3. Error range
- 4. Graphic display scale.

3.1 Position of the point(s)

First step of the data entry is made by <2> key to enter the position of the fixed points. If only one point is selected by N-toggle the entry includes only one point.

<date></date>	AXIS	110 -	ILS I	LOCALISE	SIM	ULATOR	(S/N:000)	<time></time>
Fixed Posit	ion							
TIXEU TUSIL	1011							
Elevation a	nale	(0)		< 3)				
Threshold D	list_	λ'n		30075	-			
THE SOUCE OF					-			
Point No.	1 (Far H	ield?						
Forwards	(m)		<	10000>	. :			
Azimuth Ang	le (°)	(F2))Dist	Ϟ < 0 Σ	• =			
Height	(m)			<385.33>	• =	<	385.33>	
Point No.	2 (Near	Field)	_					
Forwards	(m)		. <	100>	• =			
Dist from C	lourse Li	ine (F2)Angi	1 < 0>	• =			
Height	(m)			< 2>	• =	<	4.00>	

Fig. FIX301 Position of points Data entry screen for fixed points, where point 1 SDW is entered as angular and point 2 SDW as metric.

3.1.1 Approach Elevation Angle

Elevation Angle (°) < 3>:

The default value is 3 degrees. The run follows the Glide path angle down until 4m above the runway passing the threshold at 15m, and from there maintains a constant height of 4m along the runway towards the antenna system.

3.1.2 Threshold Distance

Threshold Dist. (m) < 3007> :

Enter the actual distance from the localiser antennas to the threshold. The preset value is the theoretical value based on the course sector width.

NOTE: If flying out on the backbeam, the height will always be 4 m.

3.1.3 Forward Distance

Forwards (m) <10000> :

The longitudinal distance between the receiver point and the antenna array along the course line. This value must be positive.

3.1.4 Sideways Distance

The lateral distance of the receiver point can be entered either as metric or angular value.

Dist from Course Line (2) Angl < 0>:

The sideways distance between course line and the receiver point in meters. Negative values on the FLY LEFT side.

If <2> key is pressed a new input line will appear allowing you enter angular value.

Azimuth Angle (°) (2)Dist

The sideways angle from the center point in degrees. Negative values on the FLY LEFT side. Zero means that the point is on the centreline. If <2> key is pressed a new input line will appear allowing you enter metric value.

3.1.5 Height of the Receiving Point (Only in 3D mode)

Height (m) < 457>:

Height of the receiving point measured from the antenna array ground level. This value must be always positive. This parameter is only available if 3D mode is selected in the Control Panel

3.2 Error Source and Type

Second step of the data entry includes the error source and type selection. First selection is the error source and then the error type. The data entry of the error is started by <5> key.

3.2.1 Error Source

<date></date>	AXIS 110	- ILS	LOCALISER	SIMULATOR	(S/N:000)	<time></time>

Item No. to be change	ed
SBO Error (Ø) Antenna Number (1	- 12 >
Item No. to be chang	ged (0 - 12)
Error source can be the ment.	he SBO-signal fe
Fig. FIX302 Data	screen for the err

Press <0> key (number zero) for the SBO-signal selection or the number of the

st < 0>:

< 6> :

ed from transmitter or one antenna ele-

ror source selection

antenna element where an error is wanted to simulate.

3.2.2 Error Type

The error type options depends on the error source selection.

3.2.2.1 SBO-signal Error

<Date> AXIS 110 - ILS LOCALISER SIMULATOR (S/N:000) <Time>

Item No. to be changed
SBO Error (0)
Antenna Number (1 - 12)
Item No. to be changed (0 - 12) < 6>:0
1 - SBO Ampl
2 - SBO Phase
Parameter No. (1 - 2) < 1>:

The error parameters in case of SBO-signal error are amplitude and phase.

Fig. FIX303 Data Entry Screen for SBO-error parameters

Enter 1 (one) for the amplitude and 2 (two) for the phase.

<Date> AXIS 110 - ILS LOCALISER SIMULATOR (S/N:000) <Time>

```
Item No. to be changed
SBO Error (0)
Antenna Number (1 - 12)
Item No. to be changed (0 - 12) (0):6
1 - SBO Ampl
2 - SBO Phase
3 - CSB Ampl
4 - CSB Phase
5 - Ampl
6 - Phase
```

Parameter No. $(1 - 6) \langle 1 \rangle$:

3.2.2.2 Antenna Element Error

In case of Antenna Element Error there are six error parameters available.

Fig. FIX304 Data entry screen for antenna element error

Enter a number from 1 to 6 according to the error type.

NOTE: Selection 5 (amplitude) and 6 (phase) will be changed both SBO- and CSB-signal.

3.3 Error range

<date></date>	AXIS	110 -	- ILS	LOCAL
Fixed Positio	on			
MIN Error MAX Error Incr Step	(dB) ((dB) ((dB) (-10 10 1))> :)> : > :	(0)
draph scale	, Genter.	IIII V	un z ·	
Third step of entry for max	the num x and mir	eric d	ata er ʿas w	ntry is t ell as tl

Fig. FIX-305 Data entry for the error range

NOTE : For amplitude errors, enter the error in deciBel's. For phase errors, enter the error in degrees.

3.3.1 Start Value of the Error

MIN Error [dB] < -10>:

The MIN error is the start value of the error simulation and the value shall be less than MAX error.

3.3.2 End Value of the Error

MAX Error [dB] < 10>: The MAX error is the end value of the error simulation and the value shall be more than MIN error.

3.3.3.Increment Step of the Error

INCR. Step [dB]

The INCR.Step is the value of the calculation step.

NOTE: The value must be a positive number.

3.3.4 Scale Center

Scale Center offset (uA)

The scale center can be offset to zoom in small changes around any deviation value.

<

ISER SIMULATOR (S/N:000) <Time>

:

the error range selection that includes the the error increment step.

1>:

< 0 > :

4.Toggles

There are seven toggles in the fixed position mode allowing you quickly change some of the often used settings.

Pressing the key shown between the brackets will execute the function.

4.1 d(B) or %

Selection for the amplitude diagrams (CSB or SBO) y-axis unit

8 Amplitudes will display in percent

dB Amplitudes will display in deciBel

4.2 (D)isplay

Selection for the output of the computed results.

- GRAPH Computed result will be displayed in graph form
- TABL Computed result will be displayed in table form

4.3 (E)rase

Selection for erasing the earlier computed data.

- or the old data in the memory will be erased and a new curve may now be computed
- **DATA** the memory still contains the last results, and the curve may be displayed again with altered toggle settings.

4.4 (I)ncr x

Selection for the x-axis increment factor during computation.

The factor will decrease the selected increment step in order to increase the resolution of the curve.

- 1 Resolution will be as selected
- 1/2 Double resolution
- 1/4 Resolution will increase by four

4.5 (N) Points

Selection for the number of fixed points

- 1 One fixed point will be handled
- 2 Two fixed points will be handled

4.6 (P)arameter

Selection for the parameter to be displayed in graph diagram

- CDI UA or % DDM
- s+c SBO- and CSB-amplitude
- сsв CSB-amplitude
- sво SBO-amplitude
- PHA the phase

4.7 (C)rs/Clr

Selection for the displayed signal of the graphic only for dual frequency systems. Course signal CRS Clearance signal CLR

NOTE : The Display toggle in TABL will display both CRS- and CLR-signals.

5.Commands

There are seven commands in Fixed Position Data Panel that is used to control the program execution or to allow to enter numeric data.

5.1 (2)Change

Change command allows you change the position data of the fixed point(s).

5.2 (3)Text

Quick command to enter text line to be shown in graph diagram

5.3 (4)FSD

Quick command to set the full vertical scale setting into graph.

5.4 (5)Errors

<5>Errors command allow you enter the data for the error simulation including the error source, the error type and the error range and step.

5.5 (6)Excel

This command enables an Excel readable file to be saved with the computed data.

NOTE: The display toggle must be set to TABL in order to invoke this function.

5.6 (EscMenu

Exit from fixed position mode into main menu.

5.7 <CR>Continue

Starts the Fixed Position mode calculation.

6. Table display

If the Display-toggle is selected as a TABL the computed results will be showed as a list of the parameter values.

This will also enable an Excel readable file to be saved on the disk if the <6> key is pressed.

Before the execution of the list it is asked if the user want to take the results to the printer.

Hardcopy of Results ? (y) or <SPACE>

Enter Y or <SPACE> if the results should be printed out. The display will stop while the screen is full and the user is asked to hit any key to continue. That will be repeated as long as the all computed results are shown.

The list includes the following parameters:

VARIABLE	Error parameter
CDI	Course deviation
CSB	Course CSB-amp
SBO	Course SBO-amp
Phase	Course Phase be
C-CDI	Clearance deviat
C-CSB	Clearance CSB-a
C-SBO	Clearance SBO-a
C-Phase	Clearance Phase

	<date></date>		AXIS	110 - II	LS LOCAL	ISER SIMULA	ATOR (S	/N:000>	<time></time>
	1 D	•							
r1X	ea Positi	LON							
	(x)	CDI (µA)	CSB	SBO	Phase	CCDI(µA)	C-CSB	C–SBO	C-Phase
	-90.00	-19.6	289.2	3.0	215.6°	-100.7	56.9	12.7	103.4°
	-85.00	-19.1	293.5	2.9	213.6°	-109.6	54.6	12.2	104.7°
	-80.00	-18.5	297.6	2.8	211.7°	-119.2	52.2	11.6	106.1°
	-75.00	-17.8	301.6	2.7	209.90	-129.4	49.8	11.0	107.7°
	-70.00	-17.0	305.5	2.5	208.20	-140.2	47.4	10.4	109.40
	-65.00	-16.1	309.2	2.4	206.6°	-151.7	44.9	9.7	111.20
	-60.00	-15.2	312.7	2.2	205.10	-163.9	42.3	9.1	113.30
	-55.00	-14.2	316.0	2.1	203.70	-176.6	39.8	8.4	115.7º
	-50.00	-13.2	319.1	1.9	202.40	-189.8	37.2	7.7	118.4°
	-45.00	-12.2	322.0	1.8	201.40	-202.9	34.7	7.0	121.5°
	-40.00	-11.0	324.6	1.6	200.5°	-215.4	32.2	6.2	125.0°
	-35.00	-9.9	326.9	1.5	199.80	-225.9	29.8	5.5	129.20
	-30.00	-8.7	328.9	1.3	199.50	-232.6	27.6	4.8	134.0°
	-25.00	-7.6	330.6	1.1	199.60	-232.4	25.5	4.0	139.70
	-20.00	-6.4	332.1	1.0	200.5°	-221.2	23.6	3.2	146.30

<date></date>		AXIS 1	L10 – II	S LOCAL	ISER SIMULA	TOR (S	/N:000>	<time></time>
xed Posit:	ion							
(x)	CDI (µA)	CSB	SBO	Phase	CCDI (µA)	C-CSB	C–SBO	C-Phase
-90.00	-19.6	289.2	3.0	215.6°	-100.7	56.9	12.7	103.4°
-85.00	-19.1	293.5	2.9	213.6°	-109.6	54.6	12.2	104.7°
-80.00	-18.5	297.6	2.8	211.70	-119.2	52.2	11.6	106.1°
-75.00	-17.8	301.6	2.7	209.9°	-129.4	49.8	11.0	107.7°
-70.00	-17.0	305.5	2.5	208.2°	-140.2	47.4	10.4	109.4°
-65.00	-16.1	309.2	2.4	206.6°	-151.7	44.9	9.7	111.20
-60.00	-15.2	312.7	2.2	205.1°	-163.9	42.3	9.1	113.30
-55.00	-14.2	316.0	2.1	203.7°	-176.6	39.8	8.4	115.70
-50.00	-13.2	319.1	1.9	202.4°	-189.8	37.2	7.7	118.4°
-45.00	-12.2	322.0	1.8	201.4°	-202.9	34.7	7.0	121.5°
-40.00	-11.0	324.6	1.6	200.5°	-215.4	32.2	6.2	125.0°
-35.00	-9.9	326.9	1.5	199.8°	-225.9	29.8	5.5	129.20
-30.00	-8.7	328.9	1.3	199.5°	-232.6	27.6	4.8	134.0°
-25.00	-7.6	330.6	1.1	199.6°	-232.4	25.5	4.0	139.70
-20.00	-6.4	332.1	1.0	200.5°	-221.2	23.6	3.2	146.30
-15.00	-5.1	333.2	0.8	202.4°	-194.7	22.1	2.5	153.9°
-10.00	-3.9	334.0	0.6	206.1°	-149.7	21.0	1.7	162.30
hit any	key to p	return.						

Fig. FIX601 The typical screen for table display results of the Fixed Position mode in case of the antenna element phase error

- in uA
- plitude
- plitude
- etween CSB and SBO
- tion in uA
- amplitude
- amplitude
- between C-CSB and C-SBO

7. Graphic Display

When the Display-toggle is selected as a GRAF the computed results will be showed as a graphic diagram.

7.1 Graphic Diagram

The graphic diagram includes all information that is set in data panel.

The second row of the screen shows the location(s) of the fixed position(s) where (curve no.1 shown in white and no.2 in yellow)

- F: forward position
- S: sideways position and
- H: height
- NOTE: If another language is used the three letters above will automatically changed to the correspondance letters.

Additionally on the bottom row there are four functions available enabling to handle the graph result.



Fig. FIX701 The typical graphic diagram of the fixed position mode for the antenna element phase error.

7.2 Functions

The functions of the graph display are(B)&WBlack&White to Colour Selector(I)nvertInvert the display colours for cut&paste purposes(4)SaveSave a B&W graph for later play back

7.2.1 Black&White to Colour Selector

(B) &W

This function is used to toggle the graph between colour and black&white. The -key will turn the graph into black background and white lines. Repeating the -key will restore the color display.

7.2.2 Display Inverter

(I) nvert

This function will invert the display colours. It also operates in colour display changing the colours to their complementary ones.

7.2.3 Printout

This function is obsolete and no longer in use.

7.2.4 Graph Saver

(4) Save

This function is used to save the graphic screen to the disk on the SCREEN directory. The names of the files will be generated automatically and the first save is named as AXL0.BAS, second AXL1.BAS, third AXL2.BAS and so on.

The saving format is the basic-language BSAVE/BLOAD mode enabling the fastest Load and play back in AXIS110.

NOTE: This function is enabled and displayed only when the screen is selected as black&white.

Blank page

BND Bend Analysis mode

Table of Contents

1.Description
2.Analysing process
3.Data Entry
3.1 Approach Elevation Angle
3.2 Distance to Threshold
3.3 Track Azimuth Angle
3.4 Option Selection
3.5 Analyse Bends Option
3.5.1 Number of Bend Points .
3.5.2 Distance to Bend Center
3.5.3 Bend Wavelength
3.6 Make Bend Option
3.6.1 Position of Object
3.6.2 Distance(s) where bends
3.7 Data Screen
4.Commands
4.1 (2)Change
4.1.1 Stop End distance
4.1.2 Projection Level
4.1.3 Max Distance on graph X
4.1.4 Min Distance on graph X-
4.1.5 Sideways Offset
4.2 (3)Text
4.3 (Esc)Menu
4.4 <cr>Continue</cr>
5.Graph Diagram
5.1 Graphic Screen
5.2 Position Adjustments
5.2.1 Projection Level
5.2.2 Y-shift
5.2.3 Minimum Distance
5.2.4 Maximum distance
5.3 Functions
5.3.1 Black&White to Colour Section 5.3.1 Black&White 5.3.1 Black&White to Colour Section 5.3.1 Black&White 5.3.1 Black&
5.3.2 Display Inverter
5.3.3 Printout
5.3.4 Graph Saver
6.Example
-

		1
	2	
	4	
	4	
	4	
	4	
	4	
	5	
	5	
	5	
	5	
	6	
	6	
are computed	6	
	7	
	8	
	8	
	8	
	8	
scale	8	
scale	8	
	9	
	9	
	9	
	9	
	10	
	10	
	10	
	11	
	11	
	11	
	11	
	12	
lector	12	
	12	
	12	
	12	
	13	
	10	

1.Description

The Bend Analysis mode includes two options

- 1. Analyse Bend and
- 2. Make Bend

Analyse Bend option is used for finding the possible origin of the reflection.

The Analyse Bend option will analyse the bend wavelengts and their position along the flightpath which can be seen in the flight measurement record to find the possible origin of the reflection object(s) as intersections of hyperbolic lines plotted on a horisontal surface.

The projection level on which the hyperbolic lines are drawn can be elevated to any height to be able to find high reflection objects.

The Make Bend option is used for tutorial purposes and is a reverse process to Analyse Bend option.

The Make Bend option is started with entering the known location of the reflecting object. The theoretical bend wavelengths are then computed at some selected distances. These points will be converted into hyperbolic lines in order to give analysing experience when the answer is known.

2. Analysing process

The first step in analysing bend from an approach on a given elevation angle is to select some periodic-like bends at different distances.

As the bend length vary along the approach path, momentary values must be found. Use only a quarter or half bend wavelengths from the curve to determine the distance as exact as possible. Convert the fractional bendlength to one wavelength at this distance by multiplying it by four or by two.



Fig. BND201 Bend Center and Length determination

The bend length corresponds to an angle between the direct and incident reflected signal given by

 $\alpha = \cos^{-1}(1 - \lambda / \text{Bendlength})$ (BND01)

when approaching towards the localiser.

This angle represents the opening angle in a cone, whose intersection with the terrain gives the geometrical solution for the possible origin of the scattering object.

angle of the reflected signal, and project this angle on a map as two or three hyperbolic lines.



Fig. BND202 The hyperbolic lines are generated when projecting three length.

Reflection object analysis might often show two solutions to point out of the origin of the reflected signals. To determine which one of these two points is real one, another approach should be tracked a little off course line. The real point will then stay, while the image point will apparently move its location compared to the first solution.

By using the <2> Make Bends option, bend lengths can be computed for different distances when the coordinates of a selected reflection object are entered.

This analysing method works fine where there is only one major object producing the scattering signals. For cases where several objects are in question, a complex interference pattern will occur for the bends, and this method may fail to find a real solution to the problem.



cones on the ground plane from three different positions. The opening angle of the cone is given by the bend wave-

3.Data Entry

The present value is always shown between angle brackets. Enter new value from the keyboard or press <Enter> to keep the present value.

<date> AXIS</date>	110 - I	LS LO	CALISER	SIMULATOR	<s n:000=""></s>	<time></time>
Bond Analusia						
Bena Hnalysis						
Annroach Elevation	Angle	(9)	<	3>:		
Approach Elevation Threshold distance	Angle	(°)	< < 30	3> : 07> :		

Fig. BND301 First part of data entry of BND

3.1 Approach Elevation Angle

Approach Elevation Angle (°) < 3>:

The simulated track follows this descend angle down to threshold (next entry), and then continues 4 m above the runway surface.

3.2 Distance to Threshold

Threshold distance < 3007>:

The distance computed in the Control Panel based on the selected course sector angle. However, this Threshold distance entry can be set to any value greater than zero.

3.3 Track Azimuth Angle

Track Azimuth Angle (°) < 0>:

The tracking direction referred to the center of the antenna system.

3.4 Option Selection

(2) Make Bends << CR> = Analyse Bends:

Press the <2> for Make Bend option or <Enter> for Analyse Bend option.

NOTE: The data entry is branching according the selected option.

3.5 Analyse Bends Option

Data entry for analyse bend option are the data of bend from the approach curve. Firstly the number of bendpoints is entered. Then the distance and the length of

every bend are entered.

<date></date>	AXIS	110	- 11	LS LO	CA
Bend Analysis					
Approach Elev	ation	Angl	e	<u>(°)</u>	
Threshold dis Track Azimuth	tance Angl	е		(•)	
(F2)Make Bend	s	<cr></cr>	Ana	alyze	B
Number of Ben	d-Poi	nts (6 ma	ax)	
Point No. 1 Distance to B Bend Waveleng	end C th	enter		(m) (m)	
Point No. 2 Distance to B Bend Waveleng	end C th	enter		(m) (m)	

Fig. BND302 Data entry for Analyse Bends Option

3.5.1 Number of Bend Points

< 3>: Number of Bend Points (6 max)

Enter the number of bend points from a flight inspection approach curve to be entered. The next two items will be repeated for each point.

3.5.2 Distance to Bend Center

Distance to Bend Center (m) <

The distance from the antenna center to the midpoint of the selected bend point on the flight inspection curve.

3.5.3 Bend Wavelength

Bend Wavelength (m)

<

Measure only a fraction of the bend, as their bendlength will vary even over one single bend wave length. Usually a quarter of a bend wave length is picked on the graph. Multiply the measured value by four to convert it to a full wave length for the entry.

0>:

0>:

3.6 Make Bend Option

Data entry for make bends option are entered as :

- 1. the position info of the object and
- 2. distance(s) where the bends will be computed.

3.6.1 Position of Object

Position of object entries are the forward distance, the sideways distance and the height of the object.

<date></date>	AXI	S 110 -	ILS LOCAL	SER SIMULA	TOR (S/N:000)	<time></time>
Bend Anal	ysis					
Approach Threshold Track Azi	Elevatio distanc muth Ang	n Angle e le	(°) (°) (3> : 3007> : 0> : 		
(F2)Make	Bends	<cr> A</cr>	nalyze Bei	nds		
Enter the Forward Sideways Height	positio Dist. Dist.	n of the (m) (m) (m) (m)	object re < < <	elative to 0> : 2 0> : 2 0> : 2 0> : 2	Localiser 500 50 0	
Fig. BND3	03 Pos	sition of C	bject Data	Entry for M	lake Bend Optior	1
Forward	Dist.	(m)	<	0>:		
	Foward of measure	distance is d along th	s the longit ne centrelir	udinal distai ne.	nce from the loca	lliser array
Sideways	Dist.	(m)	<	0>:		
	Sideways	s distance e on the	e is the late 90Hz(FLY	eral distance RIGHT) side	e from the centrel e.	ine. Positive
Height		(m)	<	0>:		
	Height of	f the obje	ct measure	ed from the	ground level.	
3.6.2 Dista	nce(s)	where	bends	are com	puted	
The AXIS1 you enter z	10 is ask zero dista	ting for th Ince or th	e distance e maximur	s where the n number of	bens shall be co 6 distances are	mputed until entered.
<date></date>	AXI	S 110 -	ILS LOCAL	ISER SIMULA	TOR (S/N:000)	<time></time>
Enter dis	tance wh	ere Bend	s shall b	e computed		

Distance	(1)	<	4500>	:	
Distance	(2)	<	4000>	:	
Distance	(3)	<	3500>	:	3000
Distance	(4)	<	0>	=	Ø

Fig. BND304 Four distances where bends are computed in Make Bends Option.
3.7 Data Screen

be displayed.

<date></date>	AXIS	110 -	ILS	LOCAI
Bend Anal	ysis			
Point No. 1 2 3	Distance 2500m 168m 1500m	Bend	l Leng 306m 545m 72m	yth
Threshold Stop End Projectio Max dista Min dista Sideways Descripti	distance distance n Level nce on X nce on X offset on	Scale Scale ILS-sys	3007) 300) 2500) 0) 0) stem 3	m m m m for]

(F2)Change (F3)Text (F10)Menu (CR)Continue

Fig. BND305 Data Screen in Bend Analysis mode

In the bottom row of the screen there are the commands available in this mode.

Data Screen is showing entered (analyse option) or calculated (make bend option) bend points and the numeric data which shows how the computed result will

LISER SIMULATOR (S/N:000) <Time>

Docum

4.Commands

4.1 (2)Change

This command is used to change graph settings including

- 1 Stop End distance
- 2. Projection level
- 3. Max distance
- 4. Min distance and
- 5. Sideways offset

<Date> AXIS 110 - ILS LOCALISER SIMULATOR (S/N:000) <Time>

Bend Analysis

Stop End distance	<	300>	:	
Projection Level	<	0>	:	
Max distance on X Scale	<	2500>	:	
Min distance on X Scale	<	100>	:	
Sideways offset	<	0>	:	
-				

Fig. BND401 Data Entries <2> command

4.1.1 Stop End distance

Stop End Distance < 300>:

The runway stop end distance from the localiser array. Default value is 300m.

NOTE: This value is only for the runway drawing on the graph.

4.1.2 Projection Level

Projection level < 0>:

The hyperbolic lines should be projected on to a level corresponding to the height of the reflection object. Cut and try with different levels when the origin of the object is known in order to gain experience in using this feature.

NOTE: In the graph screen the + and - keys are used for level shift.

4.1.3 Max Distance on graph X-scale

Max distance on X-Scale <3000>:

The graph display maximum scale along the distance axis.

NOTE: In the graph screen the <*PgUp>* and <*PgDn>* keys are used for level shift.

4.1.4 Min Distance on graph X-scale

Min distance on X-Scale < 0>:

The Graph display starting point of the distance axis.

NOTE: In the graph screen the \leftarrow and \rightarrow keys are used for level shift.

4.1.5 Sideways Offset

Sideways offset of the track.

NOTE: In the graph screen the - and ⁻ keys are used for level shift.

4.2 (3)Text

This command is used to enter description text into the graph.

Description :

Enter the label text to be printed on top of the graph.

4.3 (Esc)Menu

Use the <Esc> key to escape to the Menu if desired. The <Esc> will stop executing and escape from anywhere in the program to a higher level.

4.4 <CR>Continue

<Enter> key will start the bend analysis computation.

5.Graph Diagram

5.1 Graphic Screen

The result of computation is the hyperbolic curves which represents the line on the projection level where the origin of the bends can be situated.

Every bend-distance will have its own curve and in case of the common "bend source" object the curves will be crossing each other. How to find the origin of the bends is described in chapter 6 example.

5.2 Position Adjustments

$[\pm \uparrow \downarrow \rightarrow \leftarrow PgUp PgDn]$

There are four adjustable position parameters in graph :

- 1. Projection level (<+> , <-> keys)
- 2. Y-offset adjustment (< \uparrow > , < \downarrow > keys)
- 3. Minimum distance (<->> , <-> keys) and
- 4. Maximum distance (<PgUp> , <PgDn> keys)

When pressing any positioning key the program execution goes to the adjustment mode and in the middle of the upper part of the graph there will appear the warning text

```
<Position is adjusted - Press CR to ReDraw>
```

Upper right hand corner will show the parameter and its value that is adjusted except the case when projection level is adjusted.





5.2.1 Projection Level

We can change the projection level of the hyperbolic lines, so they are drawn on an imaginary horisontal plane at a selected height above the surrounding ground level. We are normally selecting a level that corresponds to the center of the reflection objects that can be found in the given area.

Proj. level : 10m

Using the + or - key will alter the projection level while in the graphic screen to ease the cut and try procedure of determining the location of a scattering object.

5.2.2 Y-shift

[±

ן ↑↓

The Up/Dn arrow keys will move the center up or down.

Upper left hand corner of the screen is shown the name and the value of the parameter

Y shift : 20m

The value of the parameter is stepped by <Up/Dn-arrows> and the text field is shown the value as long as you hit <enter> for redraw or another position keys.

5.2.3 Minimum Distance

→←]

The Left/Right-arrow keys can be used to change the minimum distance of the graph to zoom in on the crossing of the hyperbolic lines.

Upper left hand corner of the screen is shown the name and the value of the parameter

Begin : 300m

The value of the parameter is stepped by <Left/Right-arrows> and the text field is shown the value as long as you hit <enter> for redraw or another position keys.

5.2.4 Maximum distance

gUp PgDn]

The <PgUp>,<PgDn> keys can be used to change the maximum distance of the graph to zoom in on the crossing of the hyperbolic lines.

Upper left hand corner of the screen is shown the name and the value of the parameter

End : 4000m

The value of the parameter is stepped by <PgUp>,<PgDn> keys and the text field is shown the value as long as you hit <enter> for redraw or another position keys.

5.3 Functions

The functions of the graph display are

(B)&W	Black&White to Colour Selector
(I)nvert	Display invert the colours for cut&paste purposes
(4)Save	Save a B&W graph for later play back

5.3.1 Black&White to Colour Selector

(B) &W

This function is used to toggle the graph between colour and black&white.

The -key will turn the graph into black background and white lines.

Repeating the -key will restore the color display.

5.3.2 Display Inverter

(I) nvert

This function will invert the display. It also operates in colour display changing the colours to their complementary ones.

5.3.3 Printout

This function is obsolete and no longer in use.

5.3.4 Graph Saver

(4) Save

The save-function is used to save the graphic screen to the disk on the SCREEN directory. The names of the files will be generated automatically

and the first save is named as AXL0.BAS, second AXL1.BAS, third AXL2.BAS and so on.

The saving format is the basic-language BSAVE/BLOAD mode enabling the fastest Load and play back in AXIS110.

NOTE: This function is enabled only when the screen is selected as black&white.

6.Example

From the centreline approaching curve we have found the following bends.

BendCenterDistance	Bendlength
2500m	318m
2000m	174m
1500m	74m

Entering these values into the AXIS110 bolic curves.

The all curves are crossing at FWD=550m and SDW=250m to the each side of the centreline. The points are marked by shadowed circle and square.



g. BND601 The hyperbolic lines when projecting three cones after flying along the courseline. The ambiguity for the solution is shown by circle and a square. Either of them indicate the origin of the bends.

To solve the ambiguity of having two solutions, a new approach is made at 2 degrees azimuth giving the bends as follows:

BendCenterDistance	Bendlength
2500m	275m
2000m	151m
1500m	65m

Entering these values into the AXIS110 Bend Analysis we will have three hyper-

The resulting hyperbolic lines will now give two new crossing points of which one will be identical to one of the analysis result in the centreline.



Fig. BND602 The hyperbolic lines when approaching at 2° azimuth angle.

The circle shadowed point has remained at the same location as in fig.BND601 while the square point has moved.

The circle shadowed point will be the real object, while the other point (square shadowed) has "moved" presenting the non-existing image object.

SNS Sensitive Area mode

Table of Contents

1. Description
2. Data Panel
2.1 Numeric data (1)
2.2 Scattering Object Data (2)
2.3 Toggles (3)
2.4 Commands
3. Data Entry
3.1 Scattering Sheet (8)
3.2 Scan Area data (1)
3.2.1 Start Distance
3.2.2 Stop Distance
3.2.3 Longitudinal Step
3.2.4 Scan Width
3.2.5 Lateral Step
3.3 Display data (2)
3.3.1 Length of the X-axis
3.3.2 Stop End of the Runway
3.3.3 Taxiway Location
3.4 Receiver Position or Track (3)
3.4.1 Cat I Entry, Receiver Location
3.4.1.1 Forward Distance
3.4.1.2 Sideways Distance
3.4.1.3 Height
3.4.2 Cat II and III Entry, Receiver
3.4.2.1 Start Distance
3.4.2.2 Stop Distance
3.5 (2)Basic data
3.5.1 Elevation Angle
3.5.2 Threshold distance
3.5.3 Receiver Speed
3.5.4 Bends
3.5.4.1 Static Bends
3.5.4.2 Limit of Dynamic Bends
3.6 Text on Diagram
4. Toggles
4.1 (A)dd
4.2 (C)AT
4.3 (E)rase
4.4 (O)rientation

	. 1
	.2
	.2
	3
	. כ ג
	. J
	.4
	. כ
	.5
	. 6
	. 6
	. 6
	. 6
	.7
	.7
	7
	7
	. /
	. 1 7
	. /
	. 8
tion	. 8
	. 8
	. 9
	. 9
er Track	. 9
	. 9
	. 9
10)
	10
	10
	10
	10
· · · · · · · · · · · · · · · · · · ·	11
ds	11
·····	11
······	12
	12
	12
	12
······	13
	. •

	10
4.5 (S)catter	13
4.6 (W)orst-Case	13
4.7 (Y)axis scan	13
5. Commands	14
5.1 (8) Scattering Sheet	14
5.2 (1) Scan Area	14
5.3 (2) Display	14
5.4 (3) RX Position or Track	14
5.5 (2)Change	14
5.6 (3)Text	14
5.7 (4)Bend limit	14
5.8 (9)! Size as table	14
5.9 (Esc)Menu	14
5.10 <cr>Continue</cr>	14
6. Computed Result	15
6.1 Graphic Display	15
6.2 Functions	16
6.2.1 Black&White to Colour Selector	16
6.2.2 Display Inverter	17
6.2.3 n/a	
6.2.4 Graph Saver	17
•	

1.Description

This module is a tool for finding the border of the sensitive area where a given object (like a taxing aircraft) will produce bends of a pre-determined amplitude on the LOC signals. The objective is to advise the airport authority in establishing movement restrictions for vehicles, taxing aircrafts, lifting cranes, de-icing equipment etc for a given runway.

ICAO Annex 10 limits the maximum bend amplitude to 15uA down to ILS point C for CAT I, and to 5uA between ILS point B and the IRD (threshold) for CAT II. For CAT III the limits are similar as for CAT II with addition 5uA down to ILS point D, widening linearly out to 10uA at point E. This will be the total in a bend budget consisting of the geometric sum of the static bends from fixed installations and the dynamic bends from moving objects.

For moving objects moving at random one should not allow more than 4uA bends for the next aircraft for landing. This is based on the need to establish a lower limit for unknown and less controlled disturbances than Annex 10 allows as maximum.

This software has set 4uA as a default value for all categories, but this can be changed directly by using the 4 key and entering the wanted value. For search-ing for the limits og the first signs of disturbances, one often uses a limit of 2μ A.

The AXIS110 will simulate the tailfin of a moving aircraft or any other metallic construction, move it around and optionally rotate it to find the worst-case orientation in producing the greatest bend amplitude along the selected receiver flight path or fixed location.

We have divided this computation into a fixed position and four moving paths of different lengths. The term "Track Rx Pt C" is therefore rather a simulation of a far field monitor than a flying aircraft. For actually simulating the disturbances measured by the next aircraft operating in Low Visibility Procedures (LVP), the Track Rx should be set to A-B. This is the approach segment between the Outer and Middle markers, also referred to as Zone 2 in Annex 10. ICAO specifies minimum 2NM remaining distance before threshold when the previous aircraft exits the sensitive area.

2.Data Panel

The screen consists of four main parts

- 1. Numeric data
- 2. Scattering Object data
- 3. Toggles
- 4. Commands.





2.1 Numeric data (1)

Numeric data shows the values to be used in the computation. The numeric data is divided into five group and can be changed by <1>,<D>,<R>,<2> and <4> keys.

(1) Scan

Scan areais the area where the sheet is moved around

Begin	the longitudinal start from the LOC-array
End	the longitudinal stop from the LOC-array
X-inc	the longitudinal step increment
Width	the maximum lateral distance of the scan area
Y-inc	the lateral step increment

(D)isplay

Display data determines the scale and background figure of the display including the graph x-scale and the position of the Stop-End and Taxiway

X-scale	the maximum longitudinal distance
Stop-End	the runway stop end distance from the LOC-array the lateral distance
TaxiW	between the runway and taxiway. Dist <101m will remove it.

(R)eceiver position / track

The contents of RX-data is depending on the (T)rack Rx toggle. In the Pt C the RX position is fixed whereas in the others the RX is moving.

For Pt C	
Fwd	the longitudinal di
Sdw	the lateral distan
Hgt	the height above
For A-X (whe	re X is B, C, T or E
Start	the tracking start
Stop	the tracking stop
	Note:The track w
	sion down to 4m
	height to the stop

(2) Calculation parameters

These parameters determine the receiver path as well as the maximum allowa- ble bends.

Elevation ang.	the elevation ang
Threshold dist	the landing thres
Receiver speed	the receiver
Static bends	the maximum be
Limit of bend	the maximum all
Text	the text line going

2.2 Scattering Object Data (2)

Scattering object is	a movable sheet to
Length	the length of the
Hgt	the height of the
Btm-Hgt	the height of the
Rot	the rotation angle
Tilt	the tilt angle of th
Refl	the reflection fac

2.3 Toggles (3)

There are seven toggles in the sensitive area mode allowing you to change the setting of the parameters effecting the graph computation

A)dd	selection for what iten
T)rack Rxselec	tion of receiver locatio
E)rase	old computed sensitiv
O)rientation	the sensitive area bor show the sheet orient
S)catter	selection of scattering
W)orst-Case	the sheet rotation step
Y)-axis scan	sideways scanning m

istance from the LOC-array ice from the LOC-centreline the landing threshold

distance from the LOC-array distance from the LOC-array vill follow the glide path downward extenabove the runway and maintains 4m p distance if A-E is selected.

gle of the tracking path of the RX shold distance from the LOC-array r speed in knots ends from fixed objects lowable bends of the scatter sheet ig along with the graph

- to be used for computation
- sheet
- sheet
- sheet bottom edge above the ground
- le of the sheet
- he sheet
- ctor of the sheet
- ms are added into the graph display
- on or track path
- ve area data erasing
- rder type (border can be a continuous line or tation)
- g sheets
- p for finding the worst case
- ode selection

2.4 Commands

There are nine command in the Data Panel allowing the data entry or control the program execution

Fig. SNS202 Commands in the data panel of the Sensitive Area mode

(8) Sheet size and orientation

(1)Scan area, beginning and end distances

(D)isplay area, and select taxiway on map or not

(R)eceiver position

(2) Elevation and other data

(4) Bend amplitude Y-scale

(3) Text to describe the model

(6)Save data as XL? file - give file a name

(9)! Se a X-Y table of the sensitive area

(Esc)Return to menu

<CR>Starts the Sensitive Area computation

3. Data Entry

Numeric data entry is divided into five parts as follows

- 1. the scattering sheet,
- 2. the scanning area,
- 3. the display data,
- 4. the RX position / track and
- 5. the basic data.

The numeric data is entered by a key shown between brackets allowing to present value.

3.1 Scattering Sheet (8)

The scattering sheet is entered by <8> key or by (S)catter toggle.

the aircraft. One (S)catter toggle option is called FREE and this can be set by <8> key.

The <8> key will open the Scattering Object Editor so that the position of the object can not be entered. See details from SCA-section.

WARNING: All other scattering objects will be removed.

<date></date>	AXIS	S 110 -	ILS LO	CA
Sensitive Are	a			
(F8) Length 10.0m	Hgt 10.0r	Btm-Hg n 0.0	t Rot m Ø ^o	T
(1) Scan : Be	gin ØØm	End X	-inc W	id 50
(2) Display	: }	-scale	Stop-	En
(3) RX positi	ion :	Fwd	Sdw	H
(F2)Elevation	ang]	3293m Le	Um 3.00°	3
Threshold Receiver	l dist speed	tance 1	3007m 105kt	s
(F4)Limit of (F3)Descripti	bend ion		4.0μΑ	
(F2)Change (I	'3)Te>	ct (F9)	(F10)	Мe

Fig. SNS301 Data area for scattering object

to a greater than zero.

Simulating the building cranes can be set in a similar way. The beam height will

- change the value of the numeric data. The present value is always shown between angle brackets. Enter new value from the keyboard or press <Enter> to keep the
- The (S)catter toggle will load preprogrammed sheets representing the tailfins of



- nu <CR>Continue (SHOW\)
- The default scattering sheet is 10m wide and 20m high based on ground level.
- For aircraft tails the sheet should be lifted from the ground by setting the Btm-Hgt
- be approximately 1-2m, the length could be 20 50m and the Btm-Hgt 10 40m. The horisontal rotation of the sheet can be set to a certain value, but is not neces-

sary if the Worst-case toggle is used. Note that a positive value rotates clockwise.

The tilt option is not much used in establishing the sensitive area.

The reflection factor option may be used if the object does not have a smooth metallic surface.

A metallic grid with mesh width smaller than 0.1λ (0.3m) can also be considered to be a smooth reflecting surface. For wider grid or uneven surfaces made of concrete or glass, the reflection factor could be set to values between 0.5 - 0.95.

3.2 Scan Area data (1)

The scan area data entry is selected by the <1> key (number one).

The scan area determines the area where the scattering sheet is moved while the

<Date> AXIS 110 - ILS LOCALISER SIMULATOR (S/N:000) <Time>

T:3007m C:3293m B:4057m A:10415m

Scan area

Scan begin dist	(m) {	100> :	
Scan stop dist	(m) {	3500> :	
X — increment	(m) {	50> :	
Scan width	(m) {	500> :	
Side Increment	(m) {	10> :	

bend calculation is made in the position (or track) of the receiver.

Fig. SNS302 Data Entries for the Scan Area

NOTE: Entry for the scan area data is disabled if the memory already includes the earlier computed data (Erase-toggle=DATA).

3.2.1 Start Distance

Scan begin dist (m) < 100> :

The longitudinal distance from LLZ-array where the scan starts.

3.2.2 Stop Distance

Scan stop dist (m) < 3500> :

The longitudinal distance from the LLZ-array where the scan is stopped even if the sensitive area extends. If the sensitive area extends beyond this distance, the end tips of the area line will have a small circle attached to them. At the bottom of the the graph the texr "Non-completed" will appear.

NOTE: Stop distance must be greater than start distance.

3.2.3 Longitudinal Step

X - Increment (m) < 50> :

The test process moves the scattering object longitudially (forward) with this increment (X-inc). The default step is 50m.

3.2.4 Scan Width

Scan width (m) < 500> :

The maximum lateral distance of the scan even if the sensitive area extends outside this distance.

NOTE: This value must be increased if the boarder of the sensitive area seems to extend beyond this width wider on the graphs.

3.2.5 Lateral Step

Side Increment (m) < 10> :

The test process moves the scattering object laterally (sideways) with this increment (Y-inc). The default step is 10m.

3.3 Display data (2)

The display data includes the x-axis range of the graph and the position of the runway and the taxiway. The Add-toggle can select whether the runway and the taxiway should be shown on the graph.

The display data entry is selected by the <2> key (number two).

<date></date>	AXIS	110 -	I LS	LOCAI
 Graph distan Display X-ra Stop End d Taxi way d	ces nge ist ist	(m) (m) (m)	< : < :	3500> 300> 183>

Fig. SNS303 Data Entry for Display Settings

3.3.1 Length of the X-axis

Display X-range (m) < 3500> : The maximum longitudinal distance from the LOC-array that will be shown in the graphic diagram.

3.3.2 Stop End of the Runway

Stop End dist (m) < 300>: The runway stop end distance from the LOC-array. NOTE: Other end of runway is determinated by the threshold distance.

3.3.3 Taxiway Location

Taxi way dist (m) < 183> : The lateral distance between the runway and the taxiway center. Default value is 183m = 600feet.

NOTE: Setting the distance to the taxiway less than 100m will omit the taxiway on the graph.

Sensitive Area

LISER SIMULATOR (S/N:000) <Time>

: : =

3.4 Receiver Position or Track (3)

Data entry for the receiver is selected by 3-key (three) and is depending on the selected track options selected by the Track-toggle. In case of Pt C the AXIS110 is using a fixed receiver position. This may if the height is lowered, represet the far field monitor. In the other options the computation is made by moving the receiver position (track) along the glide path downward extension down to 4m above the runway and maintained till stop distance.

The first line of the entry screen is showing the calculated distances of the ICAO Annex10 ILS-points.

<date></date>	AXI	S 110 -	ILS LOCAL	ISER SI	MULATOR	(S/N:047)	<time></time>
T:3007m	C:3293m	B: 4057	m A:1041	5m			
Receiver Receiver Receiver Receiver	location Fwd dist Sdw dist height	(m) (m) (m)	< 3293> < 0> < 30.01>	:	(Height	: 30.01m)	
Receiver	track						
Receiver Receiver	start stop	(m) (m)	<pre>< 10415> < 4057></pre>	1			

Fig. SNS304 Data Entry for Receiver position / track

NOTE: Entry for the receiver data is disabled as long as the memory has the earlier computed result (Erase-toggle=DATA).

3.4.1 Track Entry, Pt C Receiver Location

The default values of the receiver location represent the ILS point C.

NOTE: If the threshold distance has been changed after a computation has been made, the receiver forward distance should be changed. The new forward distance (to point C) will be suggested but not set when proceeding through the data entries.
If only the forward distance has been changed, the height must be set so it corresponds to the glidepath angle if outside the threshold distance. The new height will be suggested but not set.

3.4.1.1 Forward Distance

Receiver Fwd dist (m) < 3292> :

The receiver fwd distance is the longitudinal distance from the LOC-array.

3.4.1.2 Sideways Distance

Receiver Sdw dist (m) <

The receiver sideways distance is the lateral distance from the localiser centerline.

3.4.1.3 Height

Receiver height

The receiver height is the height above the landing threshold.

NOTE: The value between brackets is the calculated height of the ILS point C with a selected elevation angle.

3.4.2 Track Rx, Receiver Track

The receiver will start at ILS pt A and follow the extended glidepath angle (elevation angle) downwards passing the threshold at 15m height. The receiver will continue in a straight line down to 4m above the runway surface and remain at this height along the runway down to ILS point E.

NOTE: A threshold distance change will alter the receiver track. default values for the selected threshold distance.

3.4.2.1 Start Distance

(m) < 10415> :Receiver start

The receiver start is the start distance of the track measured from the LOC-array. Default value is ILS point A, but can be set to any positive value greater than the stop distance.

3.4.2.2 Stop Distance (selectable)

Receiver stop (m) < 4056>: The receiver stop is the stop distance of the track measured from the LOC-array. These are the default options when pressing the T-key:

- Pt A B A normal track range for Low Visibility landings. Preferred setting.
- Pt A C
- Pt A T

0> :

(m) < 30.01>:

If the threshold distance has been changed after a computation, the receiver track values can be changed to represent the default values by pressing the T-key (Track-toggle) three times. This will set the

A test track down to Cat I specification. Will overdo a real case.

A test track down to Cat II minima. Will overdo a real case

Pt A - E A test track down to Cat IIIB minima. Will largely overdo a real case

NOTE: Only the first Track Option (Pt A-B) represents the conditions during Low Visibility Procedures. The next aircraft should be no closer than 2NM from THR when the previous aircraft exits the Sensitive Area.

3.5 (2)Basic data

The basic data entry is activated by <2>key.



Fig. SNS305 Data Entry for the basic value.

3.5.1 Elevation Angle

Elevation Angle (°) < 3>:

Elevation angle of the receiver track (normally 3°).

NOTE: If the elevation angle is changed the receiver track settings should be changed accordinly.

3.5.2 Threshold distance

Threshold Dist (m) < 3006>:

The longitudinal landing threshold distance from the LOC-array.

NOTE: If the threshold distance is changed the receiver position / track settings should be changed accordinly. Setting a threshold distance less than 1200m will omit the taxiway on the graph.

3.5.3 Receiver Speed

Receiver speed (kts) < 105> :

The objective for finding the sensitive area is to ensure acceptable signal quality for the aircrafts using the ILS during approach and landing. The receiver speed should therefore be set to the lowest speed used for instrument rated aircrafts at the particular runway.

Default speed is set to 0kts (knots = nautical miles/h) to simulate static measurements.

Typical speed settings :

Ground test vehicle 60km/h = 32kts. (Do not mix up mph) Aircraft from 90kts to 150kts.

NOTE: The receiver/plotter frequency response (rad/s) can be set in the Control Panel by using the <3>-key. See SET-section.

3.5.4 Bends

The bends are composed of static and dynamic bends.

The default bend limits are the maximum allowed amplitudes when there are no present static bends on the site. This is hardly true in practical cases, and the value of the present static bends caused by fixed installations must be taken into account.

The maximum bend limit will be the geometric sum of the static and the dynamic bends.

3.5.4.1 Static Bends

Static bends (uA) 0> : <

The bend amplitude caused by fixed installation on the site.

NOTE: It should be remember that all fixed reflection objects are removed in Sensitive Area mode.

3.5.4.2 Limit of Dynamic Bends

Limit of bend (uA) < 4> :

The maximum allowed dynamic bend amplitude caused by the moving scatter object on the simulation. Also the command <4> allow to enter this limit.

The dynamic bend limit will be:

DynBend = $\sqrt{MaxBend^2}$ - StatBend²

MaxBend = maximum allowed bend amplitude where StatBend = static bend amplitude (from fixed objects)

NOTE: Maximum bend value is normally set to 4μ A, but 2μ A will be used if the very limit of the smallest disturbances shoud be mapped.

3.6 Text on Diagram

Description :

Enter new Text >:

Entry for the description string to be shown on the graph.

(SNS01)

4.Toggles

4.1 (A)dd

NO	Only the dotted grid with 100m per square and the solid grid
	with 500/1000m per square is shown in the graph.
	The musicular with a taxin and a drawn and the granth

- RWY The runway with a taxiway is drawn on the graph.
- (m) The distances along the x-axis is displayed in the graph.
- R&m Both the runway and the distances are shown.
- NOTE: The taxiway distance less than 100m or having a threshold distance less than 1200m will omit the taxiway oh the graph.

4.2 (T)rack Rx

This toggle is used to set the track options for different test conditions.

- Pt C The receiver is positioned in ILS point C. The Bend Limit is set to 4uA by default.
- A-B The receiver follows a track from ILS point A to point B
- A-C The receiver follows a track from ILS point A to point C
- A-T The receiver follows a track from ILS point A to point T, also named the ILS Reference Datum Height (IRD or RDH). The Bend Limit is set to 4uA.
- A-E The receiver follows a track from the ILS point A to the ILS point E. The Bend Limit is set to 4uA, widening linearly out to 10uA between ILS point D and point E.
- NOTE: The second Track Option (A-B) represents the case when operating under Low Visibility Procedures. For computing the sizes for sensitive areas in Cat II & III conditions, this will be the correct setting. The subsequent settings where the end point is closer to the runway than Pt B are for testing the theortical effect on the signals in the specified usable tracks for Cat I, I and III.

4.3 (E)rase

- OK means there are no DATA from the last computed sensitive area in the memory. A new area may now be computed.
- DATA means the memory still contains the last result, and the area may be displayed again with altered range or runway/distance labels.
- NOTE: If the memory contains the last result the data entry for scan area and rx position are disabled.

4.4 (O)rientation

- YES the sensitive area.
- NO displays the border of the sensitive area.
- NOTE: been set.

4.5 (S)catter

A ready made set of scattering sheet sizes for some aircraft tails like MD80, B737, B747 and B767.

The file SCATT.UK contains these objects. The user may add with a text editor any number of new objects to this file by following the rows and columns used for the present ones.

For other sizes this toggle must be set to FREE-option and use <8> to enter the scattering object.

4.6 (W)orst-Case

This toggle is used to set the sheet rotation step for testing through a number of horisontal orientations (rotation) to produce the largest bend amplitude for a current scattering sheet location.

The increment options are 45°, 30°, 10°, 5°, 2° and NO.

Repeat pressing the W-key to set the rotation increment.

NOTE: rotation angle to 90°.

4.7 (Y)axis scan

- FULL ScanWidth for every forward step.
- FAST Limit has been reached.
- NOTE: single frequency systems.

displays the worst case sheet orientation along the border of

This toggle cannot be activated unless the Worst-Case toggle has

For dual frequency systems it has been found that the worst case is mainly 90° and therefore this time consuming worst-case orientation testing could be eliminated. Instead press the <8>-key and set the

scan will force the scatter sheet to be moved sideways out to the

scan will scan outwards only until the first occurance of the Bend

FULL-option will take a lot of computing time, but is necessary for

FAST-option is only recommended for dual frequency systems when the receiver has a certain speed. The pitfall with FAST scan is that it will not look for other possibilities of obtaining the bend limit outside the first occurance. as is often the case for single frequency systems

5.Commands

5.1 (8) Scattering Sheet

The <8> key is used to set scattering sheet values of the Scatter-toggle FREE-option.

5.2 (1) Scan Area

This commad is activated by the <1> key (number one) allowing to enter or change the scan area settings.

Note: This command cannot be activated if there is a computed result in the memory. In this case you have to erase the memory content first by Erase-toggle.

5.3 (2) Display

This command is activated by the <2> key (number two) allowing to enter or change the graph range or the location of the runway and the taxiway.

5.4 (3) RX Position or Track

Press the <3> key (number three) to activate this command which allows you enter or change the receiver data values.

Note: This command cannot be activated if there is a computed result in the memory. In this case you have to erase the memory content first by Erase-toggle.

5.5 (2)Change

The <2> command allows you enter or change the basic data values.

5.6 (3)Text

The <3> is used to enter text line (description) to be shown on graph.

5.7 (4)Bend limit

The <4> is used for fast setting of the maximum bend limit.

5.8 (9)! Table for X-Y values of SA size

The <9> gives the size of the Sensitive Area as a table of X-Y values on one side of the centre line.

5.9 (Esc)Menu

Exit from Sensitive Area mode and go back to the main menu.

5.10 <CR>Continue

<Enter>-key will start the Sensitive Area computation.

6.Computed Result

The result of the sensitive area computation is shown always in the graph form. Due to the time-consuming computation a cursor is moving down the graph to show the present location of the scattering object. At any time, the computation can be stopped by the <Esc> key. There is also CDI-tone available by the <9> key. This function operates as an on/off-switch.

The sensitive areas may sometimes have quite a different shape from what one might expect. There is a significant difference between single and dual frequency systems in that the latter will be concentrated in narrow simple shaped area while the single frequency system has a complex looking near field area.

The area size will also increase with the ILS operational category as the receiver will follow a longer track to test the scattering.

The part of the area closest to the threshold is very dependent on the aircraft speed and the receiver / plotter frequency response. For no speed (static measurements) the close distance to the receiver and the side lobes from the scattering sheet will cause this area to widen out. Using say 96kts speed on the receiver, the bends in this area will be strongly filtered out due to the short bend wavelength and hence the high bend frequency observed.

6.1 Graphic Display

nsitiu	e Area	- 4	1 1.6¥A	[CA]
				····· · · · · · · · · · · · · · · · ·
		· · · · · · · · · · · · · · · · · · ·		····.
117	500			<u> </u>
. L.L.C. :				······································
·	· ┤ <mark>╴</mark> ┊╴╴┊╸			

Fig. SNS601 Typical Sensitive Area result for the Cat II dual frequency localiser with 2uA static bends. The scattering object is B747 and rotating 30° steps.



ert (F3)Print (F4)Save

The graphic display consists of a dotted grid with 100m per square and a solid grid with 500/1000m per square. Other shown items are depending on the data and toggle settings.

is i	iti	Vē	e f	ì r	ea	-	-		4	.6,	ΡÂ				C	CA	T	II		tı	rac	:k	E	3:	4	05	7m	1	E:	3	00	7m]	
•••		••••					•••	• • • •		<u>.</u>			:	} · · · ·		:				· · · ·							· · · ·	· · · ·			ΠÂ)	as	110
										Į				ļ						 							ļ	ļ					
										ļ																					ļ		
-	-	_	_		-	+	-		_	-	\vdash	-	-	-	-		_						-				-	-	-	-			
					÷		•••	• • • •		 	•••••			 									 				 	 			····		
								••••																									
Lİ	Z	, ,	.,,	,5	<u> </u>	į.,	2		<i>.</i> /) / ·	ľ.(e	<u> </u>)) 	17	1	.5	у N . 	УГ <u>-</u>			2.0)			Z	.5	(3.0	9	(kr
Ļ	ìì	ú			į.	÷	ġ	1	ļ	į.	+-	į –	į.	į.	i.	İ.	È	÷	ļ	ļ			İ T		ļ	Ļ	İ T	İ T	; ; _		h	L.	Ļ
		<u>}</u>	5	5.5	÷,	÷,	5			<u>.</u>			-																				
	····		_		-	-	-			-	F		<u>;</u>	<u>3 \</u>	<u>• •</u>	77	<u>–</u>								. 		-	-		-			
Î					1	1				1				1													1	1					
						-								_																			
-					÷	÷		••••					÷																		ļ		
			••••		÷		•••	••••																			· · · ·	· · · ·			····		
	100	m/	∕d ُ	iυ	•	-	•••	••••		÷.,	- Fas	t	si	de	sc	an	· • • •	:		<u>.</u>			<u>.</u>		 :	RX		4.	5r.	/s		105	kts

(F1)B&W (F2)Invert (F3)Print (F4)Save

Fig. SNS602 Same as fig. SNS601 but toggle Orientation is switched ON. The dashed line shows the rotation angle of the taifin of the B747.

6.2 Functions

The functions of the graph display are

(B)&W	Black&White to Colour Selector
(I)nvert	Display invert the colours for cut&paste purposes
(4)Save	Save a B&W graph for later play back

6.2.1 Black&White to Colour Selector

(B) &W

This function is used to toggle the graph between colour and black&white.

The -key will turn the graph into black background and white lines.

Repeating the -key will restore the color display.

6.2.2 Display Inverter

(I) nvert

This function will invert the display. It also operates in colour display changing the colours to their complementary ones.

6.2.3 Printout

This function is obsolete and no longer in use.

6.2.4 Graph Saver

(4) Save

The save-function is used to save the graphic screen to the disk on the SCREEN directory. The names of the files will be generated automatically, and the first save is named as AXL0.BAS, second AXL1.BAS, third AXL2.BAS and so on.

The saving format is the basic-language BSAVE/BLOAD mode enabling the fastest Load and play back in AXIS110.

NOTE: This function is enabled only when the screen is selected as black&white.

This page is intentionally left blank.

Table of Contents

1. Description
2. Antenna-array
3. Reflection Plane
4. The scattering objects
4.1 The Rectangular Sheet
4.2 The Wire Section
4.3 Scattering models
4.3.1 Reflection
4.3.2 Diffraction
4.3.3 Shadowing
5. The low pass filter

Appendix A1 Localiser Model

•	•	•			•	•	•	•	•	•	•	•	•	•	•								•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		Ċ	1
																																														2
																																													•	R
•	•				•	•	•	•	•	•	•	•	•										•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •		ر ۸
•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •	1	4
•					•	•		•													 			•																						4
																																														4
•	•				•	•	•	•	•	•	•	•	•					1		1			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•••		;
•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •	1	4
																					 																								4	4
																																														1
•	•				•	•	•	•	•	•	•	•	•	•	•	•	•	1	•	1			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •		•
•					•	•	•	•	•	•	•	•	•								 		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•							5
																																													(6
•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	٠	٠	•	٠	٠	٠	•	•	•	•	•	•	•	•	•	•	•	•	•	• •		U

1.Description

The AXIS 110 Software is a mathematical model of a localiser consisting of

- a localiser antenna system,
- a reflection plane,
- optional scattering sheets and
- a receiver lowpass filtering.

Changes in any of these three parts can be done, and the software will simulate the signals at given points in the three-dimensional space around the model, computing

- the CDI (Course Deviation Indicator) in uA or %DDM
- amplitude in % or dB
- phase

*

- bend origin lines
- ground current levels
- sensitive areas

and print out either a table or display a graph.

It should be noted that no mathematical model can fully simulate a real situation. A model is always compromised between accuracy, amount of input data and calculation time.

Adverse terrain like high hills, buildings and metal constructions will most likely cause bends on the signals due to reflections or diffraction of the course and/or clearance signals into the approach path and coverage sector.

This model will be of reasonable accuracy to predict the impact of scatters from buildings and aircraft tailfins along the taxiways. It is designed for following purposes:

- *
- ing it.
- sites.

to find the sensitive area around a specific localiser system in order to restrict taxing aircrafts movements during instrument landing. to examine the effect of planned buildings or constructions in order to make a qualified recommendation for approval or disapproval of erect-

to learn what impact different antenna systems will behave in different airport environments. For procurement situations, this may also form a check on the manufacturers claim of system performance. For possible arguments that might occur in this context, it should be noted that no mathematical model can fully simulate a real situation, and that the manufacturer probably has long and qualified experience in modelling

2.Antenna-array

Antenna-array radiation pattern calculation is based on the individual antennaelement radiation.

The effects of mutual impedance or shadowing IS NOT calculated by the LOCmodel of the AXIS110, whereas the mechanical orientation and the feeded signals (amplitude and phase) will be calculated with high accuracy.

The input parameters for every element are

- type of element,
- height,
- sideway distance,
- azimuth turn,
- signal components (CRS/CLR CSB, SBO and phase)
- amplification and
- phase.

The horizontal radiation pattern is based on an approximation formula. Every type of antenna element has own formula and formed so that the error in \pm 80 ° azimuth angles is less than 5 % compared to the original one.

3.Reflection Plane

The radiation pattern is also affected by the ground plane under and in front of the antenna named reflection plane.

The model assumes that the reflection plane is a homogeneous and straight. Parameters for reflection plane is forward and sideways slope and the type of

Parameters for reflection plane is forw ground.

The reflection plane is taken care as a image antennas always when computation is selected for 3D-mode.

Note: When any scattering object is entered the AXIS110 switch on the 3Dmode automatically.

The model DO NOT calculate the effect of the geographical geometry but it assumes the surroundings of the airport is flat.

4. The scattering objects

The LOC-model can simulate two types of scattering objects

- 1. Rectangular sheet and
- 2. Wireline sections.

4.1 The Rectangular Sheet

Vertical conducting sheets are used to model (simulate) the walls of buildings facing the localiser antennas and the runway. Back walls in the shadow of the direct localiser signal ARE NOT simulated.

Also aircraft tailfins or any metallic construction can be simulated by using rectangular sheets positioned and oriented in the three dimensional space.

4.2 The Wire Section

A section of parallel wires can be simulated. The wires behave slightly different than the sheet in that they have a near cylindric free space re-radiation diagram.

4.3 Scattering models

Scattering calculation is devided into reflections and diffractions.



Fig. A1-401 The scattering object

4.3.1 Reflection

The maximum reflection occurs mainly in the optical specular angle. A number of sidelobes occur simular to the function $k^*sin(x)/x$, where k and x depend on the length and height of the sheet.

The re-reflection from ground between the sheet and the receiver is set to 95% as we assume flat airport surface.

4.3.2 Diffraction

Depending on the horisontal rotation angle of the sheet, an even stronger diffracted signal with sidelobes will arise behind the sheet along the extended line from the transmitter to the sheet.

The Physical Optics mathematical model uses the Fresnel-Kirchhoff diffraction integral to compute the scattered signal in the three dimentional space around the

sheet.

Reflection from a smooth rectangular area is computed as a phase shifted diffraction from an equivalent transformed aperture (Babinets principle).

Assuming far field conditions where the distance >> sheet size and antenna aperture, large surfaces are not broken down into smaller ones as one will obtain the same result with a big one.

For near field conditions, large sheets should be devided into smaller pieces by defining smaller sheets standing side by side or stacked on top of each other, making up a similar area.

The Fresnel-Kirchhoff diffraction integral:

$$\mathsf{E}_{\text{SCAT}} = \frac{jA}{2\lambda} \iint \frac{\cos\Theta_i + \cos\Theta_e}{\mathsf{R}_i \mathsf{R}_e}$$

- Where: A - incident signal amplitude at the sheet center,
 - R_i- incident signal path,
 - R₂ emanent signal path,
 - Q incident angle to the sheet normal,
 - Q_e emanent angle from the sheet normal.

The reflection/diffraction will emanate from the center of the sheet.



Scattering object

Fig. A1-402 object.

4.3.3 Shadowing

The direct signal will not pass through the sheet. Only the diffracted signal from the sheet center will be received behind it. This will cause the CDI/DDM value to be constant in the shadow region as there will be only one signal source with a fixed SBO/CSB ratio. Dividing the sheet into two adjacent half sheets will correct this problem.

 $j(R_i + R_i)$ (mod-401) ds е

The scattering geometry for incident and emanent signals. The double integration is made over the area of the scatter

5. The low pass filter

The receiver and/or plotter has a certain upper frequency limit for outputting fast scalloping. The frequency where the amplitude of the bends has dropped 3dB will be the cutoff frequency. This will be expressed in radians per second:

 $\omega_0 = 2\pi f_0$ rad/s (mod-501)

The software has a digital low pass filter to simulate this, and the default value is set to 5 rad/s as a measured average of available plotters. Modern plotters might have up to 15 rad/s so it is recommended that the user adjust this value according to the actual equipment. Use the <3>-key in the Control Panel to change the default setup.

If the receiver/plotter output specifies a certain Time Constant (τ), the conversion to rad/s will be as:

$$\omega_0 = \tau^{-1} \qquad (\text{mod-502})$$

ICAO Annex10 Volume I attachment C recommends a time constant of 50/V seconds, where the ground velocity in kts, og 92.6/V seconds where V is the velocoty in km per hour. For 105 kts, this will be 0.48 s, corresponding to approximately 2 rad/s response in the receiver.

For static measurements, where the receiver speed is set to 0kts, the receiver response setting has no effect on the output. For ground measurements, the vehicle normally drives along the runway centreline at 60km/h, which corresponds to 32kts, corresponding to 0.64 rad/s.

To convert ω (rad/s) into frequency: Freq (Hz) = $\omega/2\pi$

For aircraft simulations, the speed may be set in the range of 90 - 150kts. For conservative results with less filtering, use the speed of the slowest aircraft operating on the particular runway.

note: (100kts = 185km/h).

ICAO Annex10 Volume I attachment C recommends 96kts or 105kts as landing speed for testing the ILS..
).1	1.0	10
		6dB (3dB/

Low Pass Filter response ω o

Fig. A1-501 The digital filter response in the frequency domain where the

cutoff frequency is shown for 10 rad/sec (1.6Hz) and the asymptotic cutoff 6 dB/octave or 20 dB/decade.



This page is intentionally left blank

Table of Contents

1. Directory structure
2. Description of Files
3. The file AL.INI
4. The file AL.RUN
5. The file AL.009
6. Files *.ASY
7. The file AL12.UK

Appendix A2 Files in the AXIS110

																																									1	
																																									2	2
			_																												_										3	3
•					•	•	•	•	•	•	•	•															•	•		-	-				•	•					2	1
•	• •		•	•	•	•	•	•	•	•	•	•						•	•	•	•	•	•	•	•	•	•	•	•	•	•			•	•	•	•	• •		•	F	5
•	• •		•	•	•	•	•	•	•	•	•	•						•	•	•	•	•	•	•	•	'	•	•	'	•	•	•	••	•	•	•	•	• •		•	7	7
•	• •	•	•	•	•	•	•	•	•	•	•	•										•	•	•	•	•	•	•	•	•	•	• •	•••	•	•	•	•	• •		1	, c	,
•	• •	• •	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	• •	•	•	•	•	• •	• •	•	C)

1. Directory structure

In the single user version of the AXIS110 the installation will generate three directories as follows:

1. homedir\AXIS\

This is the main directory including all files necessary to run the AXIS110.

- 2. homedir\AXIS\WORK\ The directory for system files
- 3. homedir\AXIS\SHOW\ The directory for saved screens

Note: homedir is the path where the AXIS110 has installed

Appendix 2 Files in the AXIS110

2.Description of Files

After installation, the AXIS directory contains the following files:

AL.001	The Access file that contains the registration code and enables running the software. This file will be changed the first time you run the software and entering the user code.
	To disable this file, run the 3 key Setup and "DELETE YOUR ACCESS CODE" from the MENU. This will prevent others from using the software, as well as enabling you to enter a new USER CODE if you are given a new access level.
AL.INI	Contains the standard localiser setup on the Control Panel when starting the software. Each of the network users have their own file in their user area for separate setups. The 5 key will fetch this setup at the Control Panel. To change the content of this file permanently, run the 3 key Setup, or use an Editor to modify it. See chapter 3 of this appendix for the content.
AL.RUN	Contains the last values you were running, including all error settings, and all reflection objects. There as a separate file for each user in the network version. The 6 key will retrieve these data at the Control Panel. See chapter 4 of this appendix for the content.
AL.004	Contains the current parameters for start, stop and increment values in Orbit and Approach mode. The last used values can be saved in the AL.004 file in the Control Panel Setup <3> key.
AL.009	Contains the codes for graphic screen colors. See chapter 5 of this appendix for the content.
AL10.UK	Help screen figures for scattering objects with text lines
AL11.UK	Help screens for using the keys.
AL12.UK	All text lines in the software divided into sections.
!A110.NEW	The text file containing information of the new features or changes given to each version.
*.ASY	Contains the parameters of the antenna array
A110.EXE	The MAIN file.

3.The file AL.INI

Comments are written *italics* and do not appear in the file.

[AXIS 110 R43]	Software ID and Release n
Default setup	Text to be displayed
NMS06.ASY	Default antenna system
15011404010704	Color F/B Heading, I
12	Screen Type (9=EGA, 12=
0	Model: 2D (0) or 3D (1)
0	Notused
0	20 (0) or 40 (1) channels
110.30	RF Frequency (MHz)
0.00	Forward Slope
0.00	Sideway Slope
4	Reflection Plane Type (see
2.0	Receiver/plotter response i
I	Not used
UK	Language file extension
CDI	Display in uA (DDM for %)
Meters	Distances in meter (Feet)
WORK	Select top name of directo
SHOW	Select top name of directo
[End of AL.INI]	

Reflection plane code 1 - PERFECT 2 - SALT WATER 3 - FRESH WATER 4 - SOAKED SOIL 5 - MOIST EARTH 6 - WET SAND 7 - DRY EARTH 8 - DRY SAND 9 - CONCRETE

Appendix 2 Files in the AXIS110

number

g, F/B Cursor, F/B Screen, Data 12=VGA)

ee below) e in rad/s

ctory for storing files ctory for screen save files

4.The file AL.RUN

The file AL.003 is the System SetUp file including all data that is entered from Control Panel.

The structure of the file comprising of three to five parts beginning with the headline in square brackets.

Comments are written *italics* and do not appear in the file.

[AXI ILS- 1 0 110. 0. 4	S 110 F system 30 0000 0000	R54] for Docum Image Expand Freq Fsl Ssl Rpl	Softwa Site de 2D (0) 20 (0) d	re ID and R scription m or 3D (1) m or 40 (1) cha	elease num ax 21 chara odel annels	nber acters						
[Ant	[Antenna System]											
NM35	24 12el	. Dual										
12		Number of	element	s								
LL		Course & (Clr elem	ent type								
0	_	Ant # include	ed in the S	BO Att [3.3	8.5]							
4.0	0	Course see	ctor									
2.9	0	Course and	t hgt									
2.9	0	Clearance	ant hgt									
El.	Dist	SBOA	SBOP	CSBA	CSBP	C-SBOA	C-SBOP	C-CSBA	C-CSBP			
1	-11.22	4.90	-90.0	11.70	0.0	0.00	0.0	0.00	0.0			
2	-9.18	8 8.10	-90.0	23.40	0.0	0.00	0.0	0.00	0.0			
3	-7.14	12.50	-90.0	46.50	0.0	0.00	0.0	20.00	180.0			
4	-5.10) 13.20	-90.0	69.00	0.0	0.00	0.0	10.00	180.0			
5	-3.06	5 10.10	-90.0	88.10	0.0	7.00	-90.0	50.00	180.0			
6	-1.02	3.80	-90.0	100.00	0.0	18.00	-90.0	100.00	0.0			
7	1.02	2 3.80	90.0	100.00	0.0	18.00	90.0	100.00	0.0			
8	3.06	5 10.10	90.0	88.10	0.0	7.00	90.0	50.00	180.0			
9	5.10	13.20	90.0	69.00	0.0	0.00	0.0	10.00	180.0			
10	7.14	12.50	90.0	46.50	0.0	0.00	0.0	20.00	180.0			
11	9.18	8 8.10	90.0	23.40	0.0	0.00	0.0	0.00	0.0			
12	11.22	4.90	90.0	11.70	0.0	0.00	0.0	0.00	0.0			
[Err	or Para	ameters]										
E1.	Ampl	Phase	AZTurn	Height	FwdDist							

ET.	Ampi	Phase	Azrurn	Height	FWODISt
1	100.00	-2.00	0.00	0.00	0.00
2	104.00	3.00	0.00	0.00	0.00
3	100.00	-3.00	0.00	0.00	0.00

4	103.00	3.00	0.00	0.00
5	102.00	-3.00	0.00	0.00
6	100.00	-1.00	0.00	0.00
7	96.00	-4.00	0.00	0.00
8	104.00	-3.00	0.00	0.00
9	97.00	0.00	0.00	0.00
10	100.00	1.00	0.00	0.00
11	98.00	-4.00	0.00	0.00
12	102.00	1.00	0.00	0.00

[Attenuator x10 & Phaser Settings] SBOA SBOP CSBOA CSBOP CCSBA MSYNC AN

SBOA	SBOP	CSBOA	CSBOP	CCSBA	MSYNC
0	0	0	0	0	0

[Scatters]

Туре	Fwd	Sdw	Lgt	Hgt/d	Btm-Hgt	Rot	Tilt/#	Rfl
S	1000m	300m	100.Om	25.000m	0.Om	0.0ø	0.0ø	0.50
W	4000m	-300m	1000.Om	0.010m	50.0m	-45.0ø	4wire	1.00

Antenna element code

I - Isotropic, omnidirectional radiator

H - A half wave dipole without reflector

D - A half wave dipole with reflector

L - Logperiodic antenna element (LPDA) E - End Fire element (Travelling wave type)

T - Thomson CSF frame antenna with reflector.

V - V-Dipole used for clearance arrays.

0.00			
0.00			
0.00			
0.00			
0.00			
0.00			
0.00			
0.00			
0.00			
DUATT	90/150	MEMCS	
0	NORM	4.00	

5.The file AL.009

The file AL.009 contains the codes for graphic screen colors. Note that the curves are drawn in preset colors, so be careful about the background color by using only numbers between 0 and 8. Use an text editor to make custom color combinations for the graphics by changing the first number. The code below shows the standard color palette.

AXIS [Graphic Colors]

- 0 Background
- 14 Text 1
- 15 Text 2
- 9 Frame 1
- 1 Scale spare
- 15 Scales
- 11 Limit 1 12 Limit 2
- 15
- Spare 1
- 15 Spare 1

Code:

0	Black	4	Red	8	Dark Grey	12	Light Red
1	Blue	5	Magenta	9	Light Blue	13	Light Magenta
2	Green	6	Brown	10	Light Gre	en	14 Light Yellow
3	Cyan	7	Light Grey	11	. Light Cya	n 15	White

6.Files *.ASY

ASY file includes tha antenna array data and it has an extension "ASY".

[AXIS	110 R	54]							
TH-CSH	7 13el	Dual							
13		Number of	elements	(*see 1	note belo	w)			
DV		Course & C	Clr eleme	nt type					
0		Ant. through	ugh ADU A	ATT					
4.00		Course sea	ctor						
2.00		Course and	t hgt						
3.00		Clearance	ant hgt	(only v	valid if	separate	CLS ar	ray)	
El.	Dist	SBOA	SBOP	CSBA	CSBP	C-SBOA	C-SBOP	C-CSBA	C-CSBP
1	-12.10	3.26	-90.0	0.00	0.0	0.00	0.0	0.00	180.0
2	-9.90	6.84	-90.0	15.66	0.0	0.00	0.0	6.16	180.0
3	-7.70	10.35	-90.0	35.48	0.0	0.00	0.0	13.95	180.0
4	-5.50	11.62	-90.0	60.95	0.0	0.00	-90.0	23.99	180.0
5	-3.30	9.06	-90.0	86.09	0.0	6.45	-90.0	33.90	180.0
6	-1.10	3.59	-90.0	100.00	0.0	24.83	-90.0	39.36	180.0
7	0.00	0.00	0.0	0.00	0.0	0.00	0.0	248.32	0.0
8	1.10	3.59	90.0	100.00	0.0	24.83	90.0	39.36	180.0
9	3.30	9.06	90.0	86.09	0.0	6.45	90.0	33.90	180.0
10	5.50	11.62	90.0	60.95	0.0	0.00	90.0	23.99	180.0
11	7.70	10.35	90.0	35.48	0.0	0.00	0.0	13.95	180.0
12	9.90	6.84	90.0	15.66	0.0	0.00	0.0	6.16	180.0
13	12.10	3.26	90.0	0.00	0.0	0.00	0.0	0.00	180.0

If separate clearance antennas are utilized, continue the list of antennas so that the distances from the center line and the feeds are completely independent as in this example:

14	-1.50	0.00	0.0	100.00
15	0.00	0.00	0.0	0.00
16	1.50	0.00	0.0	100.00

* In this case the number of antennas in line 3 must be changed from 13 to 16. AXIS will only load the number of antennas which is listed in this line.

0.0	12.50	-90.0	40.00	180.0
0.0	0.00	0.0	160.00	0.0
0.0	12.50	90.0	40.00	180.0

7.The file AL12.EN

The text file AL12.EN has a certain format which is important to observe when translating into another language. Comments are written in this document in Italics and do not appear in the file itself but are shown for guidance. The file consists of a number of sections each headed by a text line between square brackets. These serve as identifiers for the software and must not be translated or modified. The following items are some important rules:

- 1) The line order must not be changed within each section, but the sections themselves, headed by a square bracket text, may appear anywhere in the file.
- 2) The content of the [Square Brackets] must not be changed as it serves as identifiers to the software.
- 3) Some text lines are divided into several text label parts, and each label (word) must always begin on the given position on the line.
- 4) [Mo X] type headings indicate the text in run mode number X. from the menu. E.g. [Mo 3] contains all text in the Orbit mode since Orbit is the 3rd menu item.
- 5) [To X] type headings give the text and action keys on the Toggle Panels in run mode number X. The characters between brackets e.g. the 'A' in (A)dd will automatically be the key to be pressed to execute the given function. When the toggle list is translated, this letter may be changed in the new word, and the new first charcter between brackets will now be the action key. However, the order of the listed commands must not be changed as the software will always take the first command as the 'Add' command regardless of the text language and action key it has been given. There can not be two identical first characters among the words on the same list as the software will only respond to the first one listed.
- 6) Except the first two sections (Control Panel and Menues) and the Toggle panel lists [To x], the text lines are terminated by a colon to measure a certain line length so it can match to other text lines. Where it is important that the length should not be changed at translation to another language, the line is terminated by an asterisk (*).

Note that the longest lines are not shown in their full length.

[AXIS 110 R54] English ControlPanel System Scatters Ant No. Course Signal Clearance Signal FRQ (MHz)C.Sector FWD SlopeSDW SlopeTHR Dist.Refl.Pln. SBO Ampl SBO PhaseADU Att. Ant Elmt Ant Hgts CLR SBOA CLR SBOP CLR CSBA Ant Elmt Ant Hgts Dist C/L Fwd Dist Height AZ Turn Ampl Phase SBO Ampl SBO PhaseCSB Ampl CSB PhaseON OFF: Theoretic Perfect 1=Help 2=DOS 3=Setup 4=Util 5=New 6=Last 7=File 8=Scatt 9=Ant Esc=End Jan.FebrMar.Apr.May JuneJulyAug.SeptOct.Nov.Dec. Are You Sure (Y/N)?

NO YES [Menues] MENU - Select Mode by Number or Arrow keys Playback Screen files View VLOC files OrbitCross_Over Vertical trace Approach on course **FixedPosition GroundCurrent BendAnalysis** Sensitive Area Current MODE: The Course Sector has been changed since last run! Antenna system Scatterers RX response-----Active SHOW Dir. Description **Enternew** Text HardCopy of Results? (y) or <CR> Scale center offset Scale Center : Full scale ñ: (2)Change(3)Text (5)Errors (Esc)Menu <CR>Continue Individual antenna heights adjusted - scatter computation uncalibrated... hit any key... (B)&W(I)nvert (4)Save (8)Scatter <-Values-> <SPACE>CLR points loaded (Esc) to break Carrier FLYRIGHT **FLYLEFT** Random setup tolerances Toggles Erase Data for new run RWY SCATT DIST OK DATA TABL GRAPH 3D in Quadrature SBO CSB COU CLR bbp BBP Ampl Phase SDM Current file name 'DATA.XL' <CR> or enter new Offset all sheets Forwards Sideways Upwards

V-DIPOLE ELEMENT

[Userhandling] THIS VERSION NEEDS A NEW INSTALLATION DISK...: Not Licensed for NetWork use...:

AXIS110J User's Manual

Start it in the AXIS directory.: The SoftWare has detected a change since registration....: Please re-enter the user code to enable usage.: Contact supplier for Registration Code!" Enter User Code : Incorrect PassWord: ACCESS DENIED - Contact Network Manager.: [Error messages] The Software is not installed properly!: Use the installation Diskette.: fileismissing.: Sorry-not enough memory available for this ...: Printer is not Connected to the Computer...: file has wrong format...: File Directory not Found...: A fatal error has occurred...* If necessary report the following information: along with a description of how it happened.: Program Name * Program Date * Error Number * Error Location * File Reference * Hit any key ... * Restart the program * 6-key recalls data * file is not found on Disk...:

[HotA] Ant Dist SBOA SBOP CSBA CSBP* SBOA SBOP CSBA CSBP* Hit any key to continue...:

[HotO] Computed on: Printer NOT connected or turned on.....: RF-Frq CS Fsl Ssl Thr Ground* 90/150 CLR Quadr.* 30Hzsynch* Course * Clrnce* Hgt SBO CSB ADU* Scatter object on test : tail* Lgt Hgt BtmHgt Rot Tilt Rfl.* Tested for worst case orientation in steps of : Scatter objects : Type Fwd Sdw Length Hgt/d Btm-Hgt Rot Tilt/# Rfl.* wire*

BEND Analyzing using following points on bendpattern: Pnt # Dist Bend Length *

[F2key] Type EXIT <Ù to Return to Program....:

[F3key] Getting the default settings first...: (2) Language change: (3) SAVE this as the Default setup: (4) Rename the Work/Graph directories (5) Delete the User Code: <CR>No Change: alterable items - others must be set in: ------ Rx Filter ------: This is the Setup when starting up or by pressing (5): Set new colours * Heading text/back : Cursor text/bar: Screen text/Background : Data/Restore to standard: Press <CR> to proceed.....: Enter the file extension country code (see list below Now: Language * Work directory * Graph directory *

[F4key] Selectutility: (2) Antenna System Designer:

[F7key] Kill* <CR> to select * <Esc>to cancel: Nofiles found...: Enterfilename: Enter model description : Sorry - You are not authorized to do this...: Files directory: (2)Common or <CR> Private File Library : (2)Load (3)Save (4)Kill (5)New directory: (6)MakeASY-file: Enter new directory <CR>=Default : Work directories: Select by PgUp/PgDn: This directory does not exist - (8) to make :

[F8key] List of scatter objects : Obj Type Fwd Sdw Lgt Hgt/d Btm-Hgt Rot Tilt/# Rfl*

A2-11

AXIS110J User's Manual

(2)Add (3)Delete (4)Remove all (5)Sort <CR>=CTRL Panel * Enter data for Scatter Object ## or <CR> to exit : New Object-<CR> if finished entering : <Spare>: wire* [F9key] <CR> to select antenna system :

<Esc>to cancel: No files found...:

[MO 1 Playback Mode] Files directory: Usage: ñ Speed [PgUp]Step Back [PgDn]Step Ahead (I)nvert (Esc)Quit: (2) Show (4)Delete all (5)New directory (6)To DOS <CR>Return : Show directories: Select by PgUp/PgDn : Enter new directory <CR>=Default: No screen files available...: This directory does not exist - (8) to make :

[MO 3 Orbit Mode] Range to circle : Level : Min Az angle : Max Az angle : Increment : Theo FWD position : Receiver speed : (3) Multiple runs : RX speed & filter may shift the CDI curve! : Max angle must be greater than Min angle! : ------ Please re-enter values ------ : Number of runs (1 - 6) * 3D Mode. Level *

[To 3] d(B) or % (D)isplay (E)rase (I)ncr x (P)arameter (M)ultiple (R)eceiver (C)rs/Clr

[MO4 Vertical Mode] Vertical:

[To 4] (A)mplitude (D)isplay (E)rase (I)ncrx (P)arameter (C)rs/Clr [Mo 5 Approach Mode] Elevation angle : Threshold Dist. : Thr. Crossing hgt: Height above RWY : Stop End distance : Theo FWD position: Track Azimuth : Track Start Dist : Track End Dist : Increment Step : Receiver speed : Receiver filter : Sideways offset :

[To 5]

d(B) or % (C)atLimit (D)isplay (E)rase (G)raphdir (I)ncr x (X)-Scale (O)riginXsc (P)arameter (S)ense (V)iew (N)ormalize

[Mo6Fixed Position Mode] Dist

from Course Line (2)Angl * Azimuth Angle (Ø) (2)Dist * Point No. * (Far Field) * (Near Field) * Item No. to be changed : Antenna Number : Parameter No. : MIN * MAX * Incr Step :

AXIS110J User's Manual

Forwards * Sideways * Height * Error: Elevation angle * Threshold Dist. * Set 3D mode for height settings :

[To 6]

d(B) or % (D)isplay (E)rase (I)ncrx (N) Points (P)arameter (S)ense (C)rs/Clr

[Mo 7 Ground Current Mode] Grid spacing : Start Distance : Stop Distance : Step Distance : Sideways Track :

[To 7] (D)isplay

(P)arameter (S)plit (C)rs/Clr

[Mo8BendAnalysisMode] Approach Elevation Angle : Track Azimuth Angle : (2)Make Bends <CR>Analyze Bends : Number of Bend-Points (9 max) * Point No. * Distance to Bend Center : Bend Wavelength : Distance Bend Length : Threshold distance : Stop End distance : Projection Level : Max distance on X Scale : Min distance on X Scale : Sideways offset : Samples: Proj. level * Y shift *

Begin * End * <Position adjusted - Press CR to Re-Draw> : Enter the position of the object relative to Localiser : Forward Dist. * Sideways Dist. * Height * Enter distance where Bends shall be computed : div Track AZ *

[To 8] (N)one

[Mo9Sensitive Area Mode] Scan area * Scan begin dist : Scan stop dist : X - increment : Scan width : Y - increment : Graph distances : Display X-range : Stop End dist : Taxi way dist : Receiver location : Receiver Fwd dist : Receiver Sdw dist : Height: Receiver height : Receiver track : Receiver start : Receiver stop : Elevation angle : Threshold distance : Receiver speed : Static bends : Limit of bend : (8) Length Hgt Btm-Hgt Rot Tilt Refl * (1) Scan: Begin End X-inc Width Y-inc * (2) Display : X-scale Stop-End TaxiW * (3) RX position: Fwd Sdw Hgt * (3) RX track : Start Stop * FREE FULL FAST * LLZ div pos track * Full sidescan: Fast sidescan : not completed : (2) Fast/Full (9) CDI tone :

[To9]

(V)iew (T)rack Rx (E)rase (O)rientation (S)catter (W)orst-Case (Y)axis scan (C)learance [Antennna Designer] Antenna System Design Module: <Spare line> Enter element spacing (m) (2)Wavelength * Enter element spacing (lambda) (2)Meter * Enter number of antennas in the array * (2) Chebychev feeds <CR>User defined : Enter sidelobe level (14 - 99dB) * (2) Dual Frequency <CR> Single : List Antennas fed through ADU Attenuator, : delimited by spaces. e.g. 1 2 3 10 11 12 : NOTE: Only half system [FLY LEFT SIDE] is entered...: Distance from array center (m) : SBO: CSB: CLR: Amplitude: Phase: (% of MAX CSB): Antenna: Center ant. : Example:Normarc12elDual<-Maxlength: Enter System name : (I) - Isotropic : (H)-Dipole (half Lambda): (D) - Dipole w/reflector: (L) - Log Periodic Dipole : (T) - Th-CSF Frame : (V) - V-Dipole (CLR): Antenna element Type: Current FILE name: Max 8 characters....: System file name : Antenna System Ready.....: (2) List Array feeds (3) Save <CR> Control Panel :

[Endoffile]

© NANCO

Software



AX3 Appendix 3

Definitions and Abbreviations

AXIS 110 User's Manual

0-	9	
	2D 3D	Two dimensional Three dimensiona
Α		
	A1, A2, A3	Glidepath antenna highest one.
	AAD ADU	Antenna Array De Antenna Distribut and the transmitte C-SBO) from the array.
	AF	Audio Frequency
	Ampl. ASY APP	Amplitude File extension for Approach mode s
	Ant Antenna	Antenna A physical device electromagnetic fi
	Antenna Array	A number of ante to direct the RF si RF signal into oth
	Antenna Element	A physical unit co devices, connecte
	Att. ASY AZ	Attenuation File name extensi Azimuth
	AX1AX4	Appendices of thi
В		
	BAL	Modulation balan
	BBP	Beam Bend Poter tude along the co signal in a given a line.
	BND	Bend Analysis mo
	Btm-Hgt B&W	Bottom Height (so Black & White

al

as. A1 is the lowest antenna and A3 the

esigner section of this manual tion Unit. This unit is between antenna array ter dividing the signals (CSB, SBO, C-CSB, e transmitter to the antenna elements of the

antenna system files section of this manual

e that converts a RF signal in cable into an field in space.

enna elements arranged in a group in order signal in certain directions and/or avoiding her directions.

onsisting of one or more tuned radiating ed to a single feeder cable.

ion for antenna array systems

is manual

nce. The amplitude of both navigation modu-150Hz) are equal.

ential. The maximum possible bend ampliburse line if 100% of the radiated SBO azimuth angle is reflected into the course

ode section of this manual cattering object)

AXIS 110 User's Manual

С

Capture Ratio	The ratio between the course and clearance carrier ampli- tudes.
CAT	Category
C-CSB	Clearance CSB
C-DEV	Clearance deviation.
CDI	Course Deviation Indication. The full scale of the cockpit indicator is ± 150 uA representing 15.5 % DDM.
CEGS	Capture Effect Glide Slope.
CL	Courseline
Clearance	The CSB and SBO signals that will cover the sectors out- side the coverage of the course signal in dual frequency systems. The clearance carrier frequency is normally spaced 8 kHz from the course carrier frequency. Also used for CDI values greater than ±150uA outside the course sector.
CLR	Clearance
Course	The CSB and SBO signals that will radiate with maximum signal along the localiser course line in single and dual frequency systems.
Course line	The locus of points to the runway centreline in any horizontal plane at which the DDM is zero.
C-PHI	Clearance Phase
CPN	Control Panel section of this manual
CR	Carriage Return (=Enter key)
COU	Course
CS	Course Sector. A sector in a horizontal plane containing the course line and limited by the loci of points nearest to the course line at which the DDM is 0.155.
C-SBO	Clearance SBO
CSB	Carrier and SideBands. The carrier equally modulated (20%) with 90 Hz and 150 Hz sine wave. Amplitude and phase defined as only the carrier part of CSB.
CTR	Center
CTRL panel	Control Panel
dB	deciBel
DEV	Deviation. Same as CDI
DEF	Abbreviation of this section
DEG	Degrees
DDM	Difference in Depth of Modulation. In this context defined as m150 - m90.
Dist.	Distance
Div	Division

D

E	
Elmt Extra signals	Antenna Element
F	
FRQ FSD FSL FWD FIX	Frequency Full Scale Deflection Forward Slope Forward Fixed Position mo
G	
GEN GND GP GP centreline	General Section o Ground Current m Glide Path
GP Zero GRAPH	Graphic result of the
Н	
Hgt Hyper	Height Hyperbolic path
ILS ILS Point A	Instrument Landin A point on the exte km (4NM) from the
ILS Point B	A point on the extent
ILS Point C	A point on the exte
ILS Point D	A point 4m (12ft) a (3000ft) from the t
ILS Point E	A point 4m (12ft) a (2000ft) from the s
ILS Point T	A point (normally ' ward extended str
ICAO	International Civil
ICAO Incr IRD ISO-CDI	International Civil Increment ILS Reference Da Constant Deviation

© NANCO

Software

Appendix 3

ion

ode section of this manual

of this manual node section of this manual

the analysis

ng System

tended runway centreline a distance of 7.5 ne threshold

tended runway centreline a distance of rom the threshold

tended centreline where the nominal ILS s at a height of 30m (100ft).

above the runway centreline and 900m threshold in the direction of the localizer.

above the runway centreline and 600m stop end of the runway in the direction of

15m) above the threshold where the downtraight portion of the ILS glide path passes. eference Datum.

Aviation Organisation

atum. See ILS Point T. on line. (Used in window overview graphic)

AXIS 110 User's Manual

K		
	Kill Kts	Same as delete. Knots (Nautical Miles per hour, 1.83km/h)
L		
	LAT Lgt LOC LPDA	Latitude Trace mode section of this manual Length Localiser (Previously LLZ) Log Periodic Dipole Antenna
Μ		
	M-ARRAY	
	MCU	Monitor Combining Unit
	MOD	Modulus
	Modulus	The maximum possible bend amplitude along an approach if the reflected SBO signals arrive in the worst possible phase relationship to the direct CSB signal. Also called the enve- lope of the bend pattern.
Ν		
	NULL REF	Two antennas GP type (basic type GP) where the lower antenna (A1) radiates the CSB and the upper (A2) the SBO.
0		
	Optimize	Optimized GP is the M-ARRAY system where the amplitude and phase relation is slightly adjusted so that the SBO and CSB illumination towards reflection object or dicontinuities in the reflecting plane is suppressed in order to reduce the occuring bends created by the reflecting signals.
	ORB	Orbit mode section of this manual
Ρ		
	PLY PHI PHX	RePlay the Screens section of this manual Phase
	Pos	Position
R		
	Reflection plane Refl.Pln. RPL RF	Reflection PLane Radio frequency

	RFL Rot r/s RT RTC RTS RWY RX	Reflection Object Rotation Radians per Sect Ratio Ratio CSB Ratio SBO Runway Receiver
S		
	SBO	SideBands Only. site AF phases. A sideband sum ver reference signal.
	SBOA SBOP SCA SDM	SBO Amplitude SBO Phase Scattering Object Sum of Depth of deviation of 3870 value above this will remain at the
	SDW SET Sense SIDEBAND REF SNS SSL Step Hgt	Sideway SetUp section of Which way is 90/ Two antennas Gl Sensitive Area M Sideways Slope
Т		
	TABL TaxiW Tilt THEO THR TX	Table result of th Taxiway Vertical Angle of Theodolite Threshold Transmitter
U		
V	uA	Micro Ampere

ct or reflection factor

cond

The 90 Hz and 150 Hz modulated in oppo-Amplitude and phase defined as the 150 Hz ector relative to the carrier part in the CSB

ct Editor of this manual f modulation defined as m150 + m90. A fuA or a DDM at 40% is the maximum. Any s correspond to increased SDM while DDM e maximum value.

f this manual)/150 Hz on curve SP type where Mode

ne analysis

f the scattering object

AXIS 110 User's Manual

VRT

	_	
Vertical	Irace	mode

W

W/R	With Reflector
WND	Window diagram section of this manual

Х

Xinc	Increment i x- direction (along centreline)
Xing Hgt	Crossing height.

Y

Yinc	Increment i y- direction (90 degrees on centreline)